# SHARP SERVICE MANUAL

CODE: 00ZAR5731/S1E



DIGITAL MULTIFUNCTIONAL SYSTEM

# MODEL AR-5726/5731

	CONTENTS
(	NOTE FOR SERVICING
	[1] PRODUCT OUTLINE 1-1
	[2] SPECIFICATIONS
	[3] CONSUMABLE PARTS
	[4] EXTERNAL VIEW AND INTERNAL STRUCTURE 4-1
	[5] ADJUSTMENTS
	[6] SIMULATION
	[7] SELF DIAG AND TROUBLE CODE
	[8] MAINTENANCE
	[9] FIRMWARE UPDATE
	[10] ELECTRICAL SECTION

Parts marked with " $\triangle$ " are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

# SHARP CORPORATION

This document has been published to be used for after sales service only. The contents are subject to change without notice.

# CONTENTS

#### NOTE FOR SERVICING

	1. Warning for servicingi
	2. Precautions for servicing
	3. Note for repairing/replacing the LSU i
[1]	PRODUCT OUTLINE
	1. Line of machines and options 1 - 1
[2]	SPECIFICATIONS
	1. Basic function
[3]	CONSUMABLE PARTS
	1. Supply system table
	2. Maintenance parts list
	3. Developer/Drum life end definition
	4. Production number identification
	5. Environment conditions
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE 1. External view
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE         1. External view         2. Internal structure         4 - 2
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE         1. External view       4 - 1         2. Internal structure       4 - 2         3. Operation panel       4 - 3
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE         1. External view       4 - 1         2. Internal structure       4 - 2         3. Operation panel       4 - 3         4. RSPF       4 - 4
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE         1. External view       4 - 1         2. Internal structure       4 - 2         3. Operation panel       4 - 3         4. RSPF       4 - 4         5. Sensor       4 - 5
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE         1. External view       4 - 1         2. Internal structure       4 - 2         3. Operation panel       4 - 3         4. RSPF       4 - 4         5. Sensor       4 - 5         6. Switch       4 - 5
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE         1. External view       4 - 1         2. Internal structure       4 - 2         3. Operation panel       4 - 3         4. RSPF       4 - 4         5. Sensor       4 - 5         6. Switch       4 - 5         7. Solenoid/Clutch       4 - 6
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE         1. External view       4 - 1         2. Internal structure       4 - 2         3. Operation panel       4 - 3         4. RSPF       4 - 4         5. Sensor       4 - 5         6. Switch       4 - 5         7. Solenoid/Clutch       4 - 6         8. Drive motor       4 - 6
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE         1. External view       4 - 1         2. Internal structure       4 - 2         3. Operation panel       4 - 3         4. RSPF       4 - 4         5. Sensor       4 - 5         6. Switch       4 - 5         7. Solenoid/Clutch       4 - 6         8. Drive motor       4 - 6         9. Lamp       4 - 7
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE         1. External view       4 - 1         2. Internal structure       4 - 2         3. Operation panel       4 - 3         4. RSPF       4 - 4         5. Sensor       4 - 5         6. Switch       4 - 5         7. Solenoid/Clutch       4 - 6         8. Drive motor       4 - 6         9. Lamp       4 - 7         10. Fan/Filter       4 - 7
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE         1. External view       4 - 1         2. Internal structure       4 - 2         3. Operation panel       4 - 3         4. RSPF       4 - 4         5. Sensor       4 - 5         6. Switch       4 - 5         7. Solenoid/Clutch       4 - 6         8. Drive motor       4 - 6         9. Lamp       4 - 7         10. Fan/Filter       4 - 7         11. PWB       4 - 8

# [5] ADJUSTMENTS

1. Adjustment item list 5 - 1
2. Details of adjustment
[6] SIMULATION
1. General
2. Simulation code list 6 - 3
3. Details of simulation 6 - 6
[7] SELF DIAG AND TROUBLE CODE
1. Trouble code list
2. Details of trouble code 7 - 2
[8] MAINTENANCE
1. Maintenance list 8 - 1
2. Details of Maintenance
3. Other related items
[9] FIRMWARE UPDATE
1. Firmware update procedure 9 - 1
[10] ELECTRICAL SECTION
1. Block diagram
2. Actual wiring chart 10 - 2
3. Signal list

# NOTE FOR SERVICING

This Service Manual uses some photographs to assure safe operation. Please understand the meanings of photographs before servicing.

- ▲ WARNING: If this WARNING should be ignored, a serious danger to life or a serious injury may result.
- ▲ CAUTION: If this CAUTION should be ignored, injury or damage to property could result.

# 1. Warning for servicing

- Be sure to connect the power cord only to a power outlet that meets the specified voltage and current requirements.
- Avoid complex wiring, which may lead to a fire or an electric shock.2) If there is any abnormality such as smoke or an abnormal smell, interrupt the job and disconnect the power plug.

It may cause a fire or an electric shock.

- Be sure the machine is properly grounded. Failure to ground the machine properly may result in an electric shock or fire.
   To protect the machine and the power unit from lightening, grounding must be made.
- 4) When connecting the ground wire, never connect it to the following points as it may cause an explosion, fire, or an electric shock:
  - · Gas tube
  - Lightning conductor
  - A water pipe or a water faucet, which is not recognized as a grounding object by the authorities.
  - Grounding wire for telephone line
- Do not damage, break, or stress the power cord. Do not put heavy objects on the power cord. Do not bend or pull the cord forcefully. It may cause a fire or electric shock.
- 6) Keep the power cable away from a heat source.

Do not insert the power plug with dust on it into a power outlet. It may cause a fire or an electric shock.

 Do not put a receptacle with water in it or a metal piece which may drop inside the machine.

It may cause a fire or an electric shock.

Do not touch the power plug, insert a telephone jack, perform service or operate the machine with wet or oil hands. It may cause an electric shock.

# 2. Precautions for servicing

 When servicing, disconnect the power plug, the printer cable, the network cable, and the telephone line from the machine, except when performing the communication test, etc.

It may cause an injury or an electric shock.

- 2) There is a high temperature area inside the machine. Use extreme care when servicing.
- There is a high voltage section inside the machine which may cause an electric shock . Be careful when servicing.
- Do not disassemble the laser unit. Do not insert a reflective material such as a screwdriver in the laser beam path. It may damage eyes by reflection of laser beams.
- 5) When servicing the machine while operating, be careful not to make contact with chains, belts, gear, and any other moving parts.
- Do not leave the machine with the cabinet disassembled.
   Do not allow any person other than a serviceman to touch inside the machine. It may cause an electric shock, a burn, or an injury.
- When servicing, do not breathe toner, developer, and ink excessively. Do not get them in the eyes.
   If toner, developer, or ink enters you eyes, wash it away with water immediately, and consult a doctor if necessary.
- The machine has got sharp edges inside. Be careful not to damage fingers when servicing.
- Do not throw toner or a toner cartridge in a fire. Otherwise, toner may pop and burn you.
- 10) When replacing the lithium battery on the PWB, use only the specified battery. If a battery of different specification is used, it may not be compatible and cause breakdown or malfunction of the machine.
- When carrying an electric unit or a PWB, use an anti-static (electricity) bag. Failure to do so may cause component failure or machine malfunction.

# 3. Note for repairing/replacing the LSU

When repairing or replacing, be sure to observe the following items.

- 1) When repairing or replacing the LSU, be sure to disconnect the power plug from the power outlet.
- 2) When repairing or replacing the LSU, follow the procedures described in this Service Manual.
- 3) When checking the operations after repairing the LSU, keep all the parts including the cover installed and perform the operation check.
- 4) Do not modify the LSU.
- 5) When visually checking the inside of the machine for the operation check, be careful not to allow laser beams to enter the eyes.

If the above precaution is neglected or an undesignated work is performed, safety may not be assured.

# [1] PRODUCT OUTLINE

# 1. Line of machines and options



# [2] SPECIFICATIONS

# 1. Basic function

#### A. Base engine

#### (1) Type

Туре	Desktop	

#### (2) Engine composition

Photoconductor kind	OPC drum (Drum dia. 30mm)
Copying method	Electronic photo (Laser)
Developing system	Dry, 2-component magnetic brush development
Charging system	Sawtooth charging
Transfer system	Transfer roller system
Cleaning system	Contact blade system
Fusing system	Heat roller
Toner supply method	Toner supply by front cover open
Waste toner disposal	Toner cartridge collection

#### (3) Dimensions / Weight

External dimensions (W x D x H)	OC model: 623 x 628 x 668mm RSPF model: 623 x 628 x 788mm
Occupied dimensions (W x D) (when the manual paper feed tray is extended)	898 x 628mm
Weight	About 46kg

#### (4) Warmup

Warm-up time	23 sec or less (26-sheet model) 25 sec or less (31-sheet model)
Pre-heat	Yes
Jam recovery time	About 10sec, excluding fusing warmup, toner control, etc.

Conditions: Leaving for 60 sec after door open, standard conditions, polygon stop.

#### (5) First copy time

	26-sheet model	31-sheet model
Platen	4.8 sec	4.5 sec
RSPF	9.3 sec	or less

\* Measuring conditions: When paper of A4 or 8.5" x 11" is fed from the machine tray, with the polygon rotating.

#### (6) Engine resolution

Writing resolution	600 x 600dpi
0	
Smoothing (Print)	1200dpi (equivalent) x 600dpi
<b>A 1 1</b>	
Gradation	Writing: Binary
	0

#### (7) Printable range

Max. print size	AB series: 416 x 293mm (600dpi: 9826dot x 6920dot) Inch series: 428 x 275mm (600dpi: 10110dot x 6496dot)
Void area image loss	Front/Rear: Less than 4mm Right/Left total: Less than 6mm at actual (100%) size

#### (8) Engine speed (ppm)

Tray	Paper size	26-sheet	31-sheet
Tray 1-4	A3	15	17
	B4/8.5 x 13	17	20
	A4/B5/A5/8.5 x 11/ 5.5 x 8.5/16K	26	31
	A4R/8.5 x 11R/16KR	18	24
	B5R	21	
	11 x 17	14	17
	8.5 x 14	16	20
	8K		19
Manual paper	A3	14	17
feed	8.5 x 13	17	20
	B4	16	19
	A4/B5/A5/8.5 x 11/ 5.5 x 8.5/16K	23	27
	A4R/8.5 x 11R	19	22
	16KR		23
	B5R	21	24
	11 x 17	14	16
	8.5 x 14	16	19

#### (9) Power source

Voltage/Current	220 - 240V 8A
Frequency	50/60Hz
Power source code	Inlet type
Power switch	1 power source

#### (10) Power consumption

Maximum rated power consumption	1.45kw
Shift time to sleep mode	Default (1 minute)

#### (11) Memory

Local Memory	Standard	32MB
	Expansion	512MB x 2
	Max.	1056MB

# B. Controller board

#### (1) Controller board

		SPLC board
Interface	Ethernet	No
	USB 2.0 Device	Full Speed 1slot
	Memory	No
	Memory expansion slot	

#### C. Operation panel

Туре	Dot matrix LCD, touch panel
Size	Monochrome H-VGA 8.1"
Display dot number	640 x 240 (H-VGA)
LCD drive display area	192 x 72mm
LCD backlight	Fluorescent lamp backlight system
LCD contrast adjustment	Yes

### **D. Scanner section**

### (1) Resolution/Gradation

Reading	Copy mode					
resolution	Platen	400 x 60	400 x 600dpi			
(api)	RSPF	400 x 60	400 x 600dpi			
Transmission	FA	FAX transmission mode				
resolusion	Select mode	Normal	Fine	Super	Ultra	
(dpi)		text	text	fine	fine	
				text	text	
	Input resolution:	203.2	203.2	203.2	406.4	
	OC	х	х	х	х	
		293.4	293.4	391.2	586.7	
	Input resolution:	203.2	203.2	203.2	406.4	
	RSPF	х	х	х	х	
		293.4	293.4	391.2	586.7	
	Transmission	203.2	203.2	203.2	406.4	
	resolution	х	х	х	х	
		97.8	195.6	391	391	
	Half tone	No	Yes	Yes	Yes	
Reading gradation	256 gradations					
Exposure lamp	Electrodeless xer	ion lamp				
Output gradation	Binary					

#### (2) Document table

Туре	Document table fixed type (Flat bed)		
Scanning area	297 x 431.8mm		
Original standard position	Left bottom reference		
Detection	Yes		
Detection size	Inch series	Automatic setting 11 x 17, 8.5 x 14, 8.5 x 11, 8.5 x 11R, 5.5 x 8.5 Manual setting 11 x 17, 8.5 x 14, 8.5 x 13 (216 x 330), 8.5 x 11, 8.5 x 11R, 5.5 x 8.5, A3, A4, A4R	
	AB series	Automatic setting A3, B4, A4, A4R, A5 Manual setting 11 x 17, 8.5 x 14, 8.5 x 13 (216 x 330), 8.5 x 11, 8.5 x 11R, A3, B4, A4, A4R, A5	

#### (3) Automatic document feeder

Туре	RSPF (Automatic duplex document feeder unit)		
Scan speed	When in s	ingle copy	When in duplex copy
Сору	31-sheet r 27 sheets, (400 x 600 26-sheet r 26 sheets, (400 x 600	nodel: /min Ddpi) nodel: /min Ddpi)	31-sheet model: 13.6 side/min (400 x 600dpi) 26-sheet model: 13.6 side/min (400 x 600dpi)
Fax	40 sheets/ (Normal te	/min ext, A4R)	17 sheets/min (Normal text, A4R)
Document set direction	Face-up re	eference	
Document standard position	Center ref	erence	
Document transport system	Sheet thro	ough system	
Document size	AB series: Inch series	: A3 - A5 s: 11 x 17 - 5	.5 x 8.5
Document weight	Single face: 35 - 128g/m <sup>2</sup> , 9 - 34 lbs, Duplex: 52 - 105g/m <sup>2</sup> , 13.9 - 28 lbs		
Max. loading capacity of documents	100 sheets (90g/m <sup>2</sup> ) Paper thickness of 13mm or less can be set.		
Transport disable document	OHP, perforated documents, photo, catalogue, second original sheet, tracing paper, carbon paper, heat-sensitive paper, wrinkled paper, folded or broken paper, pasted or cut-away paper, documents of many perforated holes (2-hole, 3-hole documents can be used), document printed by an ink ribbon		
Detection	Yes		
Detection size	Inch series	Automatic s 11 x 17, 8.5 8.5 x 11R, 5 Manual sett 11 x 17, 8.5 330), 8.5 x 5.5 x 8.5, A	etting 5 x 14, 8.5 x 11, 5.5 x 8.5, A3, A4 ing 5 x 14, 8.5 x 13 (216 x 11, 8.5 x 11R, 3, A4, A4R
	AB	Automatic s	etting 5 x 11, A3, B4, A4,
	30103	A4R, B5, B5 Manual sett 11 x 17, 8.5 330), 8.5 x A4, A4R, A4	5R, A5 ing 5 x 14, 8.5 x 13 (216 x 11, 8.5 x 11R, A3, B4, 5
Multi copy	S-S, S-D,	A4R, B5, B5 Manual sett 11 x 17, 8.5 330), 8.5 x A4, A4R, A5 D-D, D-S	5R, A5 ing 5 x 14, 8.5 x 13 (216 x 11, 8.5 x 11R, A3, B4, 5

# E. Paper feed section

Туре		Paper feed tray + Multi manual paper feed (Expanded up to 4 trays by installing options.)			
Paper feed method		Paper is fed from the above by the front loading system.			
Details of paper feed section		Tray1	Tray2	Manual paper feed tray	
Paper capacity	Standard paper (80g/m <sup>2</sup> )	500 :	sheets	100 sheets	
Paper size		A3, B4, A4, A4R, B5, B5R, A5, 11 x 17, 8.5 x 14, 8.5 x 13, 8.5 x 11, 8.5x11R, 5.5 x 8.5, 8K, 16K, 16KR	A3, B4, A4, A4R, B5R, 11 x 17, 8.5 x 14 (216 x 356), 8.5 x 13 (216 x 330), 8.5 x 11, 8.5 x 11R, 8K, 16KR	A3, B4, A4, A4R, B5, B5R, A5R, A5, B6R, 11 x 17, 8.5 x 14 (216 x 356), 8.5 x 13 (216 x 330), 8.5 x 11, 8.5 x 11R, 7.25 x 10.5R, 5.5 x 8.5, 8K, 16K, 16KR, A6R, Envelope <sup>*1</sup>	
Paper size detection		1	No	Yes	
Allowable paper type and weight for paper feed		56 - 105g/m <sup>2</sup> /15 - 28lbs Bond		Multi paper feed: Standard paper (56 - 128g/m <sup>2</sup> ) Special paper, heavy paper (max. 200g/m <sup>2</sup> ) Single paper feed: Standard paper, special paper, second original, heavy paper (max. 200g/m <sup>2</sup> ), 56- 200g/m <sup>2</sup> (14 - 54lbs)	
Paper type		Standard paper (56 - 80g/m <sup>2</sup> ) Normal paper (60 - 105g/m <sup>2</sup> ) Letterhead Color paper		<ul> <li>Standard paper: 100 sheets (56 - 80g/m<sup>2</sup>)</li> <li>Recycled paper/coarse paper: 100 sheets</li> <li>Heavy paper (max. 200g/m<sup>2</sup>): 30 sheets</li> <li>OHP/Label sheet/gift wrapping paper: 40 sheets</li> <li>Label sheet: 40 sheets</li> <li>Envelope (AB series: 10 sheets, Inch series: 5 sheets)</li> </ul>	
Paper size setting when	Inch series	8.5	x 11		
snipping	AB series	/	<b>\</b> 4		
Paper remaining detection		No (paper presence only)			

\* 1: Supported envelope kinds: Commercial10 (4 - 1/8" x 9 - 1/2"), International DL (110mm x 220mm), International C5 (162mm x 229mm)

# F. Paper exit section

#### (1) Center tray of main unit

• •	
Paper exit position/ system	Main unit top surface face-down paper exit
Paper exit capacity	500 sheets (A4, 8.5 x 11, 80g/m <sup>2</sup> paper)
Paper exit paper size/ kind	All kinds of paper which can be fed
Shifter function	Yes
Paper remaining detection for paper exit	Yes

# G. Copy functions

#### (1) Copy magnification ratio

Copy magnification	AB series	25%, 50%, 70%, 81%, 86%, 100%, 115%, 122%, 141%, 200%, 400%
ratio	Inch series	25%, 50%, 64%, 77%, 100%, 121%, 129%, 200%, 400%
Zoom	25 - 400% (Restriction	6 on by the document feeder unit: 50 - 200%)

### (2) Density/copy image quality process

Exposure mode	Binary: Automatic, Text, Text/Photo, Photo
Number of manual	5 steps
steps	

### (3) Duplex

., .	
System	Switchback system
Paper size	A3, B4, A4, A4R, B5, B5R, A5, 11 x 17, 8.5 x 14, 8.5 x 13, 8.5 x 11, 8.5 x 11R
Type and weight of paper which can be passed	56 - 105g/m <sup>2</sup> /15 - 21.3 lbs Bond Duplex print from manual paper feed can be made. (Except for heavy paper, OHP sheet, and other special paper)

\* When duplex printing is continued in a certain level of temperature, the printing speed may be reduced in order to prevent an abnormal temperature rise in the machine.

### (4) Copy functions

Automatic paper selection
Automatic magnification ratio selection
Vertical/horizontal independent magnification ratio
Paper type selection
Auto tray switching
Rotation copy
Electronic sort
Job reservation (only during warm-up)
Program call-out/registration (10 items)
Preheat function
Auto power shut off function
User management (100 items)
Mixed documents feed (MIX only)
Binding margin (Left/Right/Upper)
Edge erase/Center erase (Center/Edge/Center + Edge)
1 set 2 copy
Cover paper/Insert paper (Cover/Back cover only)
Multi shot (2 in 1/4 in 1) (Centering available)
Card shot (Centering available)
Pamphlet mode (Centering available)
Duplex copy direction switching
Large volume document mode
Black/white reverse (except for UK)
Stream feeding mode (ON/OFF switch by the system setting)

# H. Printer function

### (1) Platform

- IBM PC/AT
- Macintosh

### (2) Support OS

	OS		
Windows	2000		
	ХР	Yes	
	XP x64		
	Server 2003	No	
	Server 2003 x64	NO	
	Vista		
	Vista x64	165	
	Server 2008		
	Server 2008 x64		
Mac	9.0 - 9.2.2		
	X 10.2.8	No	
	X 10.3.9		
	X 10.4.11	1	
	X 10.5 - 10.5.6		

# I. Environmental conditions



Standard environmental	Temperature	20 - 25°C
conditions	Humidity	65 ± 5%RH
Usage environmental	Temperature	10 - 35°C
conditions	Humidity	20 - 85%RH
	Atmospheric	590 - 1013 hPa
	pressure	(height: 0 - 2000m)

# [3] CONSUMABLE PARTS

# 1. Supply system table

### A. East Europe/Russia

-					
No.	Item	Content	Life	Model name	Remarks
1	Toner cartridge	Toner cartridge (With IC chip) ×1	33K	MX-312GT	Life setting by A4 (8.5"×11") 6% document
	(black)	(Toner; Net 700g)			Default: Toner save mode
2	Developer (black)	Developer ×1	26cpm: 75K	MX-312GV	
		(Developer; Net 300g)	31cpm: 100K		
3	Drum	Drum ×1	26cpm: 75K	MX-312GR	
			31cpm: 100K		

# B. Asia Subsidiaries

-					
No.	Item	Content	Life	Model name	Remarks
1	Toner cartridge	Toner cartridge (With IC chip) ×1	33K	MX-312AT	Life setting by A4 (8.5"×11") 6% document
	(black)	(Toner; Net 700g)			Default: Toner save mode
2	Developer (black)	Developer ×1	26cpm: 75K	MX-312AV	
		(Developer; Net 300g)	31cpm: 100K		
3	Drum	Drum ×1	26cpm: 75K	MX-312AR	
			31cpm: 100K		

# C. SMEF/Agent

No.	Item	Content		Life	Model name	Remarks
1	Toner cartridge	Toner cartridge (With IC chip) ×	1	33K	MX-312FT	Life setting by A4 (8.5"×11") 6% document
	(black)	(Toner; Net 700g)				Default: Toner save mode
2	Developer (black)	Developer ×	1	26cpm: 75K	MX-312FV	
		(Developer; Net 300g)		31cpm: 100K		
3	Drum	Drum ×	1	26cpm: 75K	MX-312FR	
				31cpm: 100K		

# 2. Maintenance parts list

# A. East Europe/Russia/SMEF

No.	Item	Content		Life	Model name	Remarks
1	Upper heat roller kit	Upper heat roller	×1	150K	AR-310UH	
		Fuser gear	×1			
		Upper heat roller bearing	×2			
		Upper cleaning pad	×1			
		Fusing separation pawl (upper)	×4			
		Thermistor cleaning pad	×2			
2	Lower heat roller kit	Lower heat roller	×1	300K	MX-311LH	
		Fusing separation pawl (lower)	×4			
		Fuser bearing (lower)	×2			
3	150K PM kit	Drum separation pawl unit	×2	150K	MX-311KA	
		Transfer roller unit	×1			
		DV blade	×1			
		DV side sheet F	×1			
		DV side sheet R	×1			
		Toner filter unit	×1			
4	MC unit	MC unit	×10	26cpm: 75K (×10)	MX-311MC	
				31cpm: 100K (×10)		
5	Cleaner blade	Cleaner blade	×10	26cpm: 75K (×10)	MX-311CB	
				31cpm: 100K (×10)		
6	Drum frame unit	Drum frame unit	×1	26cpm: 225K	MX-311DU	* The life of the toner reception seat attached to
				31cpm: 300K		the drum frame is 300K, and it can be used up
						to 3 times. (Supplied as a drum frame unit.)
7	Transfer roller unit	Transfer roller unit	×1	150K	MX-311TX	
8	Staple cartridge	Staple cartridge	×3	5000 staples ×3	MX-SCX1	

\* The other maintenance parts than the above are supplied as service parts.

# B. Asia Subsidiaries/Agent

No.	Item	Content		Life	Model name	Remarks
1	Upper heat roller kit	Upper heat roller Fuser gear Upper heat roller bearing Upper cleaning pad	×1 ×1 ×2 ×1	150K	AR-310UH	
		Fusing separation pawl (upper) Thermistor cleaning pad	×4 ×2			
2	Lower heat roller kit	Lower heat roller Fusing separation pawl (lower) Fuser bearing (lower)	×1 ×4 ×2	300K	MX-311LH	
3	150K PM kit	Drum separation pawl unit Transfer roller unit DV blade DV side sheet F DV side sheet R Toner filter unit	×2 ×1 ×1 ×1 ×1 ×1	150K	MX-311KA	
4	MC unit	MC unit	×10	26cpm: 75K (×10) 31cpm: 100K (×10)	MX-311MC	
5	Cleaner blade	Cleaner blade	×10	26cpm: 75K (×10) 31cpm: 100K (×10)	MX-311CB	
6	Drum frame unit	Drum frame unit	×1	26cpm: 225K 31cpm: 300K	MX-311DU	* The life of the toner reception seat attached to the drum frame is 300K, and it can be used up to 3 times. (Supplied as a drum frame unit.)
7	Staple cartridge	Staple cartridge	×3	5000 staples ×3	MX-SCX1	

\* The other maintenance parts than the above are supplied as service parts.

# 3. Developer/Drum life end definition

When the developer/drum counter reaches the specified level.

When the developer/drum rpm reaches the specified level.

When either of the above reached the specified level, it is judged as life end.

In an actual case, when correction or warm-up operation is performed as well as output operation, the developer and the drum rotates.

Therefore, the developer/drum consuming level cannot be determined only by the copy/print quantity. When, therefore, the rpm reaches the specified level, it is judged as life end.

To check the drum and developer life, use SIM22-1.

	Developer/d	rum counter	Number of rotations (Rotations)
Developer/drum	26cpm model	550K	
	75K	100K	

# 4. Production number identification

#### <Toner cartridge>

The label on the toner cartridge shows the date of production.



#### <Developer>



The lot number is of 8 digits. Each digit indicates the content as follows. The number is printed on the right under side of the back surface of the developer bag.

- 1 Alphabet
- Indicates the production factory. 2 Number
- Indicates the production year. 3, 4 Number
- Indicates the production month.
- 5, 6 Number

Indicates the production day.

- 7 Hyphen
- 8 Number Indicates the production lot.

#### <Drum>

The laser print indicates the model conformity code and the date (year, month, day) of production.



1 Alphabet

- Indicates the model conformity code. L for this model.
- 2 Number

Indicates the end digit of the production year.

- Number or X, Y, Z
   Indicates the month of packing.
   X stands for October, Y November, and Z December.
- 4, 5 Number
  - Indicates the day of the month of packing.

# 5. Environment conditions



Standard environmental	Temperature	20 - 25°C		
conditions	Humidity	65 ± 5%RH		
Usage environmental	Temperature	10 - 35°C		
conditions	Humidity	20 - 85%RH		
	Atmospheric	590 - 1013 hPa		
	pressure	(height: 0 - 2000m)		
Storage period	Toner/Developer: 24 months from the			
	manufactured month (Production lot)			
	under unsealed state			
	Drum: 36 months	from the manufactured		
	month under unsealed state			

# [4] EXTERNAL VIEW AND INTERNAL STRUCTURE

# 1. External view



No.	Name	Function/Operation
1	Document feeder tray	Place the original(s) that you wish to scan face up here.
2	Original guides	Adjust to the size of the originals.
3	Document feeder cover	Open to remove misfed originals.
4	Reversing tray	Pull out to remove misfed originals.
5	Exit area	Originals exit the machine here after copying.
6	Document transport cover	Open to remove misfed originals.
7	Document transport cover knob	Pull to open the document transport cover.
8	Document glass	Place an original that you wish to scan face down here.
9	Power switch	Press to turn the machine power on and off.
10	Handles	Use to move the machine.
11	Operation panel	Contains operation keys and the touch panel.
12	Job separator tray (Upper tray) (optional)	Print jobs and received faxes are delivered to this tray.
13	Center tray	Finished copies are delivered to the center tray.
14	Front cover	Open to remove paper misfeeds and perform machine maintenance.
15	Paper trays	Each tray holds 500 sheets of copy paper.
16	Upper right side cover	Open to remove misfeeds when an optional job separator tray kit or a optional finisher is
		installed.
17	Side cover	Open to remove misfeeds.
18	Side cover handle	Pull to open the side cover.
19	Bypass tray paper guides	Adjust to the width of the paper.
20	Bypass tray	Regular paper and special paper (such as transparency film) can be fed from the bypass tray.
21	Bypass tray extension	Pull out the bypass tray extension before placing paper in the bypass tray.

# 2. Internal structure



No.	Name	Function/Operation	Note
1	Toner cartridge lock release lever	Use to unlock the toner cartridge.	
2	Toner cartridge	Contains toner.	
3	Roller rotating knob	Turn to remove misfed paper.	
4	Photoconductive drum	Copy images are formed on the photoconductive drum.	Do not touch the photoconductive drum (green portion). Doing so may damage the drum and cause smudges on copies.
5	Fusing unit release levers	To remove a paper misfeed in the fusing unit, push up on these levers and remove the paper.	The fusing unit is hot. Do not touch the fusing unit when removing misfed paper. Doing so may cause a burn or injury.
6	Fusing unit paper guide	Open to remove misfed paper.	

# 3. Operation panel



No.	Name	Function/Operation	Note
1	Touch panel	The machine status, messages and touch keys are displayed on the panel.	
		The display will show the status of printing, copying or network scanning	
		according to the mode that is selected. For details see the next page.	
2	Mode select keys and indicators	Use to change modes and the corresponding display on the touch panel.	
	[COPY] key	Press to select copy mode.	
	[PRINT] key/ONLINE indicator/	[PRINT] key: Press to select print mode.	
	DATA indicator	ONLINE indicator: Print jobs can be received when this indicator is lit.	
		DATA indicator: A print job is in memory. The indicator lights steadily while	
		the job is held in memory, and blinks while the job is printed.	
	[FAX] key/LINE indicator/	[FAX] key: Press to select fax mode when the fax option is installed.	When the fax option is
	DATA indicator	<ul> <li>LINE indicator : This lights up while faxes are being sent or received.</li> </ul>	installed.
		DATA indicator: Blinks when a fax has been received to memory and lights	
		steadily when a fax is waiting in memory for transmission.	
3	[JOB STATUS] key	Press to display the current job status.	
4	[SYSTEM SETTINGS] key	Use to adjust various settings of the machine including the contrast of the touch	
		panel and administrator settings.	
5	Numeric keys	Use to enter numeric values for various settings.	
6	[LOGOUT] key (⊛)	When auditing mode is enabled, press this key after finishing a job to return the	
		machine to account number entry standby.	
7	[#/P] key ( (#)?)	Use this key to execute a job program in copy mode.	
		The key is also used to dial in fax mode.	
8	[CLEAR] key (ⓒ)	Press to clear a copy number setting or cancel a job.	
9	[CLEAR ALL] key (🖓)	Resets the settings to the initial settings.	
10	[START] key (🕐)	Press in copy mode, scanner mode, or fax mode to begin copying, network	
		scanning, or faxing.	
		This key blinks when auto power shut mode has activated. Press the key to	
		return to normal operation.	
11	[INTERRUPT] key (🕗)	Use to perform an interrupt copy job.	

# 4. RSPF

# A. External view



No.	Name
1	Document set tray
2	Document guide
3	Document feed section cover
4	Document transport section cover
5	Document exit section

### **B.** Internal structure



No.	Code	Name	Туре	Function/Operation
1	EMPS	Document set sensor	Photo transmission	Detects presence of documents.
2	FGOD	Open/close sensor	Photo transmission	Detects open/close of the paper feed unit.
3	DFCL	Paper feed clutch	—	_
4	DFD	Paper entry sensor	Photo transmission	Detects presence of documents.
5	RSOL	Pressure release solenoid	—	_
6	CLH	Transport clutch	—	_
7	DTM	SPF motor	Stepping motor	Drives document feed on the tray, transport, and paper exit roller.
8	GSOL	Gate solenoid	—	_
9		Interface PWB	—	_
10	DLS1	Document length detection SW (Short)	Photo transmission	Detects the document length on the tray.
11	DLS2	Document length detection SW (Long)	Photo transmission	Detects the document length on the tray.
12	OPCLS	Book sensor	Photo transmission	Detects the SPF float.
13	RDD	Paper exit sensor	Photo transmission	Detects presence of documents.
14	SWD	Document width sensor	Volume	Detects the document width on the tray.

AR-5726/5731 EXTERNAL VIEW AND INTERNAL STRUCTURE 4-4



No.	Name	Code	Function and operation
1	Mirror home position sensor	MHPS	Mirror (scanner) home position detection
2	Document cover sensor	OCSW	Document cover open/close detection
3	Document size sensor	DSIN3	Document size detection (Inch series: PD3, 4) (AB series: PD4, 5)
4	2nd paper exit sensor (Option)	POD2	2nd paper exit detection
5	2nd paper exit full detection sensor (Option)	TOPF	2nd paper exit section full detection
6	1st paper exit sensor	POD1	1st paper exit detection
7	Shifter home position sensor (Except North America)	SFTHP	Shifter home position sensor detection
8	Paper exit sensor (DUP side)	PPD2	Paper exit detection
9	Thermistor		Fusing temperature detection
10	1st tray (paper tray) detection	CD1	1st tray (paper tray) empty detection
11	Manual feed paper entry sensor	PPD1L	Sensor of paper entry from the manual paper feed tray, the 2nd/multi-tray desk, or the DUP
12	Manual paper feed tray empty sensor 2	MPLS2	Manual feed tray position detection
13	Manual paper feed tray empty sensor 1	MPLS1	Manual feed tray position detection
14	Manual feed length detection sensor 1	MPLD1	Manual feed paper length detection
15	Manual feed length detection sensor 2	MPLD2	Manual feed paper length detection
16	Manual feed paper empty sensor	MPED	Manual feed paper empty detection
17	2nd tray paper pass sensor	PFD2	2nd tray paper pass

No.	Name	Code	Function and operation
18	2nd tray paper upper limit detection sensor	LUD2	2nd tray paper upper limit detection
19	2nd tray paper empty sensor	PED2	2nd tray paper empty detection
20	1st tray paper pass sensor	PPD1H	1st tray paper pass
21	1st tray paper upper limit detection sensor	LUD1	1st tray paper upper limit detection
22	1st tray paper empty sensor	PED1	1st tray paper empty detection
23	Toner sensor		Toner density detection
24	Center tray paper YES/NO sensor	LOEMP	Center tray paper YES/NO detection
25	Document size sensor	DSIN0	Document size detection (Inch series: PD1, 2) (AB series: PD1 – 3)
26	Reverse pass paper detection sensor	DUP2	Reverse pass detection

# 6. Switch



No.	Name	Code	Function and operation
1	Right cabinet door	DSWR0	Right cabinet door open/
	switch (Option)		close detection
2	Door switch	DSWR1	Front door and side door
			open/close detection
3	2nd right door switch	DSWR2	Side door open/close
			detection
4	Main switch	PSSW	Main power switch

# 7. Solenoid/Clutch

No.	Name	Code	Function and operation
1	Paper exit gate switching solenoid (Option)	OGS	Paper exit gate switcher
2	PS clutch	RRC	Main unit paper feed
3	Paper feed clutch	CPFS1	Paper feed roller drive
4	Manual paper feed solenoid	MPFS	Manual paper feed solenoid
5	Paper feed transfer clutch	TRC2	Paper feed transfer clutch
6	2nd tray paper feed clutch	CPFS2	
7	2nd tray paper feed solenoid	CPFC2	Solenoid for the paper feed from the tray
8	Paper feed solenoid	CPFC1	Solenoid for the paper feed from the tray
9	Separation pawl solenoid	PSPS	Separation pawl operation solenoid

8. Drive motor



No.	Name	Code	Function and operation
1	Mirror motor	MIRM	Optical mirror base drive
2	Shifter motor (Except North America)	SFTM	Shifter drive
4	Duplex motor	DPXM	Duplex paper switching and exit motor
5	DUP-2 motor		Reverse pass for paper transport
6	Main motor	MM	Main drive
7	Tray lift-up motor	LUM1	Tray paper lift-up
8	Tray lift-up motor	LUM2	Tray paper lift-up
9	Toner motor	ТМ	Toner supply



INO.	Name	Function and operation
1	Copy lamp	Image radiation lamp
2	Heater lamp	Fusing heat lamp

10. Fan/Filter



No.	Name	Code	Function and operation
1	Cooling fan	VFM	Cools the inside of the unit.
2	Exhaust fan motor	DCFM	Cools the inside of the unit.
3	Intake fan motor	DCFM2	Cools the inside of the unit.
4	Fusing paper exit fan	VFM2	Cools the inside of the unit.
			(31 sheet model)
5	Fusing paper exit fan	VFM2	Cools the inside of the unit.
6	Ozon filter		
7	Ozon filter		



No.	Name	Function and operation
1	Inverter PWB	Copy lamp control
2	CCD PWB	For image scanning (read)
3	Option connector PWB	
4	IMC PWB	Image process
5	MCU PWB	Main unit control
6	Mother board	Connection with FAX PWB
7	Tray interface PWB	2nd tray control
8	DC power supply PWB	DC voltage control
9	High voltage PWB	High voltage control
10	KEY PWB	
11	OPU PWB	Operation panel control
12	SPLC PWB	Output image signal

# 12. Roller



No.	Name	Function and operation
1	Paper exit roller	Paper exit roller
2	Transport roller	Paper transport roller
3	Upper heat roller	Fuses toner on paper.
		(with the Teflon roller)
4	Lower heat roller	Fuses toner on paper.
		(with the silicone rubber roller)
5	DUP transport follower	Duplex paper transport
	roller	
6	DUP transport roller	Duplex paper transport
7	Transport roller	Transfer images on the drum onto
		paper.
8	Resist roller	Synchronize the paper lead edge
		with the image lead edge.
9	Manual paper feed roller	Picks up papers in manual paper
		feed port.
10	Manual feed transport	Transports paper from the manual
	roller	paper feed port.
11	1st tray pick-up roller	Picks up paper from the tray.
12	1st tray paper feed roller	Transports the picked up paper to
		RESIST section.
13	2nd tray pick-up roller	Picks up paper from the tray.
14	2nd tray paper feed roller	Transports the picked up paper to
		RESIST section.

# [5] ADJUSTMENTS

# 1. Adjustment item list

	Section	Adjustment item			Adjustment procedure/SIM No.	
Α	Process section	(1)	Developing doctor gap adjustment		Developing doctor gap adjustment	
		(2)	MG roller main pole position adjustment		MG roller main pole position adjustment	
		(3)	Developing bias voltage adjustment		SIM8-1	
		(4)	Grid bias voltage adjustment		SIM8-2	
В	Mechanism section	(1)	Print start position adjustment		SIM50-5	
		(2)	RSPF image lead edge position adjustment		SIM50-6	
		(3)	Rear edge void adjustment		SIM50-1	
		(4)	Paper off center adjustment		SIM50-10	
		(5)	Left edge void area adjustment		SIM50-1-8	
		(6)	Main scanning direction (FR direction) distortion		No. 2/3 mirror base unit installing position	
			balance adjustment		adjustment	
					Copy lamp unit installing position adjustment	
		(7)	Sub scanning direction (scanning direction)		Winding pulley position adjustment	
			distortion adjustment			
		(8)	Main scanning direction (FR direction) distortion		Rail height adjustment	
			balance adjustment			
		(9)	Main scanning direction (FR direction)		SIM48-1-1	
			magnification ratio adjustment			
		(10)	Sub scanning direction (scanning direction)	а	OC mode in copying (SIM 48-1-2)	
			magnification ratio adjustment	b	RSPF sub scanning direction magnification ratio	
					(SIM48-1-3, 48-1-4)	
		(11)	Off center adjustment (RSPF mode)		SIM50-12	
		(12)	OC (RSPF) open/close detection position		SIM41-3	
			adjustment			
		(13)	Original sensor adjustment		SIM41-2, 41-4 (41-1)	
		(14)	RSPF white correction pixel position adjustment		SIM63-7	
			(required in an RSPF model when replacing the			
			lens unit)			
		(15)	RSPF scan position auto adjustment		SIM53-8	
С	Image density	(1)	Copy mode		SIM46-2	
	(exposure) adjustment					

# 2. Details of adjustment

#### A. Process section

- (1) Developing doctor gap adjustment
- 1) Remove the doctor cover.



- 2) Loosen the developing doctor fixing screw A.
- 3) Insert a thickness gauge of 1.5mm to the positions of three screws on the developing docter as shown.



- 4) Tighten the developing doctor fixing screw.
- 5) Check the clearance of the developing doctor. If it is within the specified range, then fix the doctor fixing screw with screw lock.
- \* When inserting a thickness gauge, be careful not to scratch the developing doctor and the MG roller.

#### <Adjustment specification>

Developing doctor gap F/C/R: 1.5 <sup>+0.1mm</sup><sub>-0.15mm</sub>

#### (2) MG roller main pole position adjustment

- 1) Put the developing unit on a flat surface.
- 2) Tie a needle or pin on a string.
- Hold the string and bring the needle close to the MG roller horizontally. (Do not use paper clip, which is too heavy to make a correct adjustment.) (Put the developing unit horizontally for this adjustment.)
- 4) Do not bring the needle into contact with the MG roller, but bring it to a position 2 or 3mm apart from the MG roller. Mark the point on the MG roller which is on the extension line from the needle tip.
- 5) Measure the distance from the marking position to the top of the doctor plate of the developing unit to insure that it is 9.1mm. If the distance is not within the specified range, loosen the fixing screw A of the main pole adjustment plate, and move the adjustment plate in the arrow direction to adjust.



- (3) Developing bias voltage adjustment (SIM 8-1)
- 1) Execute SIM 8-1.

SIMULATION 8- DV BIAS COPY	1 SETTING.	INPUT VALUE	200–650, ANI	D PRESS
START.	100		150	
1: AE(145)	400	2: TEXT(145)	450	400
3: TEXT/PHOTO	145) 450	4: PHOTO(145)	450	1/1
5: TONER SAVE(	145) 450	6: AE(122)	450	[↑]
7: TEXT (122)	450	8: TEXT/PHOTO	0(122) 450	
9: PHOTO(122)	450	10: TONER SAV	′E(122) 450	↓ ОК

- 2) Touch the exposure mode to be changed. The current set value is displayed.
- 3) Enter the set value with the 10-key.
- 4) Press the [START] key.

Output is made with the entered value, and the display returns to the original state.

#### <Adjustment specification>

ltem		Content	Setting range	Default
1	AE (145)	AE (145mm/s)		450
2	TEXT (145)	Character (145mm/s)		450
3	TEXT/PHOTO (145)	Character/Photo (145mm/s)		450
4	PHOTO (145)	Photo (145mm/s)		450
5	TONER SAVE (145)	Toner save (145mm/s)	200-	400
6	AE (122)	AE (122mm/s)	650	450
7	TEXT (122)	Character (122mm/s)		450
8	TEXT/PHOTO (122)	Character/Photo (122mm/s)		450
9	PHOTO (122)	Photo (122mm/s)		450
10	TONER SAVE (122)	Toner save (122mm/s)		400

#### (4) Grid bias voltage adjustment (SIM 8-2)

1) Execute SIM 8-2.



- 2) Touch the exposure mode to be changed. The current set value is displayed.
- 3) Enter the set value with the 10-key.
- 4) Press the [START] key.

Output is made with the entered value for 30sec, and the display returns to the original state.

#### <Adjustment specification>

	Item	Content	Setting range	Default
1	AE (145)	AE (145mm/s)		590
2	TEXT (145)	Character (145mm/s)	-	590
3	TEXT/PHOTO (145)	Character/Photo (145mm/s)		590
4	PHOTO (145)	Photo (145mm/s)		590
5	TONER SAVE (145)	Toner save (145mm/s)	350-	540
6	AE (122)	AE (122mm/s)	750	590
7	TEXT (122)	Character (122mm/s)		590
8	TEXT/PHOTO (122)	Character/Photo (122mm/s)		590
9	PHOTO (122)	Photo (122mm/s)		590
10	TONER SAVE (122)	Toner save (122mm/s)		540

Min. unit: -10V increment

#### **B.** Mechanism section

#### (1) Print start position adjustment

1) Execute SIM 50-5.

SIMULATION 50	<u>-5</u> USTMENT(PR	INT). INPUT VALUE	E 0-99, AND PRESS
START.			
1: TRAY1	53		53
2: OPTION	53		1/1
3: MANUAL	53		$\left[\uparrow\right]$
4: DUPLEX	53		
			↓ ОК

2) Touch the item to be adjusted.

The item and the currently set value are highlighted.

- Press the [P] key. The display is shifted to the copy menu.
- Select the paper feed tray, the print density, and the duplex mode. Enter the adjustment value with the 10-key.
- 5) Press the [START] key. Copying is started.

	Item	Content	Setting range	Default
1	TRAY1	1st tray	0-99	
2	OPTION	Option tray		50
3	MANUAL	Manual feed	1-99	55
4	DUPLEX	Back print		

- Measure the distance H between the paper lead edge and the image print start position. Set the image print start position set value again.
  - 1 step of the set value corresponds to about 0.127mm shift.
  - · Calculate the set value from the formula below.
    - 99 H/0.127 (mm) = Image print start position set value <H: Print start position measurement value (mm)>



\* Fit the print edge with the paper edge, and perform the lead edge adjustment.

Example:99 - 5/0.127 = 99 - 39.4 = about 59

Note: FIf the set value is not obtained from the above formula, perform the fine adjustment.

- 7) Execute SIM 50-1-2 to adjust the main tray lead edge void.
  - 1 step of the set value corresponds to about 0.127mm shift.Calculate the set value from the formula below.
    - B/0.127 (mm) = Lead edge void adjustment value <B: Lead edge void (mm)>



Example: When setting the lead edge void to 2.5mm: 2.5 / 0.127 = about 20

#### <Adjustment specification>

Adjustment mode	SIM	Set value	Spec value	Setting range
Main tray lead edge void	50-1 -2	B/0.127	Lead edge void: 1 – 4mm	1 00
Print start position	50-5	99 – H/0.127	Image loss: 3mm or less	1 – 99

[H: Print start position measurement value (mm),

B: Lead edge void (mm)]

#### (2) RSPF image lead edge position adjustment

1) Set a scale on the OC table as shown below.



- Note: Since the printed copy is used as a test chart, put the scale in paralleled with the edge lines.
- Make a copy, then use the copy output as an original to make an RSPF copy again.
- Check the copy output. If necessary, perform the following adjustment procedures.
- 4) Execute SIM 50-6.
- Set the RSPF lead edge position set value so that the same image is obtained as that obtained in the previous OC image lead edge position adjustment.

#### <Adjustment specification>

Adjustment mode	SIM	Set value	Spec value	Setting range
RSPF image lead edge position	50-6	1 step: 0.127mm shift	Lead edge void: 1 – 4mm Image loss: 3mm or less	1 – 99

#### (3) Rear edge void adjustment

1) Set a scale as shown in the figure below.



- Set the document size to A4 (8.5" x 11"), and make a copy at 100%.
- 3) If an adjustment is required, follow the procedures below.



- Execute SIM 50-1 and set the density mode to DEN-B. The currently set adjustment value is displayed.
- Enter the set value and press the start key. The correction value is stored and a copy is made.

<Adjustment specification>

Adjustment mode	SIM	Set value	Spec value	Setting range
Rear edge void	50-1-6	1 step: 0.127mm shift	4mm or less	1 – 99

#### (4) Paper off center adjustment

- 1) Set a test chart (UKOG-0089CSZZ) on the document table.
- 2) Select a paper feed port and make a copy.
- 3) Execute SIM 50-10.

SIMULATION 50	-10	
PRINT OFF-CEN	ITER ADJUS	STMENT. INPUT VALUE 1-99, AND
PRESS START.		
1: BYPASS	50	50
2: TRAY1	50	1/1
3: TRAY2	50	(↑)
4: TRAY3	50	
5: TRAY4	50	
6: DUPLEX	50	

- 4) Touch the item to be adjusted.
- The item and the currently set value are highlighted. 5) Press the [START] key.

 Press the [START] key. The display is shifted to the copy menu.

- 6) Select the paper feed tray and the print density. Enter the adjustment value with the 10-key.
- 7) Press the [START] key.

|--|

	Item Content		Setting range	Default
1	BYPASS	Manual paper feed		
2	TRAY1	1st tray		
3	TRAY2	2nd tray	1.00	50
4	TRAY3	3rd tray	1-99	50
5	TRAY4	4th tray		
6	DUPLEX	Back print		

#### <Adjustment specification>

Adjustment mode	SIM	Set value	Spec value	Setting range
Paper off center	50-10 -2	Add 1: 0.127mm shift to R side.	Single: Center	
Second print surface off-center	50-10 -6	Reduce 1: 0.127mm shift to L side.	±2.0mm Duplex: Center ±2.5mm	1 – 99

#### (5) Left edge void area adjustment

- Note: Before performing this adjustment, be sure to check that the paper off center adjustment (SIM 50-10) is completed.
- 1) Execute SIM 50-1.

SIMULATION 50-1				
LEAD EDGE ADJUST	MENT.	INPUT VALUE 1-99, AND	PRES	SS START.
1: RRC-A	43	2: DEN-A	18	43
3: DEN-A -MANUAL	18	4: DEN-A -OPTION	18	
5: DEN-A -DUPLEX	18	6: DEN-B	3	1/1
7: DEN-B-DUP	50	8: SIDE VOID	18	$\uparrow$
9: SIDE VOID-DUP	18	10: LOSS(OC)	3	$\square$
				↓ ОК

- 2) Note down the adjustment value of SIM 50-5 (Items 1, 2, 3, 4), and change the value to 99.
- 3) Set SIM 50-1 (Items 2, 3, 4, 5) to 1. (By setting to 1, there is no void.)
- Place a chart with a clear lead edge (or a ruler) on the OC document table.
- Use SIM 50-1 (Item 1) to execute test print. Check the print out and adjust so that the lead edge image is printed. (1 – 99: About 0.127mm/Step)
- 6) Reset the adjustment values of SIM 50-5 (Items 1, 2, 3, 4) to the original values, and execute test print. Check the print out and adjust so that the lead edge image is printed on the lead edge of paper. (1 99: About 0.127mm/Step).
- Adjust SIM 50-1 (Items 2, 3, 4, 5) so that the lead edge void on the print out is the specified value. (1 – 99: About 0.127mm/Step)
- Similar to procedure 7, adjust SIM 50-1 (Item 6, 7) so that the rear edge void is the specified value. (1 – 99: About 0.127mm/Step)
- Similar to procedure 7, adjust SIM 50-1 (Item 8, 9) so that the left edge void is the specified value. (1 – 99: About 0.127mm/Step)
- 10) Make an enlargement copy (400%), and check that there is no shade of the cabinet printed at the lead edge.
- 11) If there is a shade printed at the lead edge in procedure 9, adjust SIM 50-1 (Item 10). (1 5: About 0.677mm)
  \* If there is no problem, set to 3.

Item		Content	Setting range	Default
1	RRC-A	Original scan start position	1-99	43
		adjustment		
		Lead edge position		
		adjustment value (OC)		
2	DEN-A	Lead edge cancel	1-99	18
		adjustment (Main tray)		
3	DEN-A-MANUAL	Lead edge cancel	1-99	18
		adjustment		
		(Manual feed tray)		
4	DEN-A-OPTION	Lead edge cancel	1-99	18
		adjustment (Option tray)		
5	DEN-A-DUPLEX	Lead edge cancel	1-99	18
		adjustment		
		(back of the machine)		
6	DEN-B	Rear edge void adjustment	1-99	30
7	DEN-B-DUP	Rear edge void adjustment	1-99	50
		(Duplex)		
8	SIDE VOID	Left edge void adjustment	1-99	18
		(First print surface)		
9	SIDE VOID-DUP	Left edge void adjustment	1-99	18
		(Duplex)		
10	LOSS(OC)	Image loss amount	1-5	3
		adjustment (Lead edge		
		image loss set value) (OC)		

#### <Adjustment specification>

Adjustment	SIM	Set value	Spec	Setting
mode	SIIVI	Set value	value	range
Left edge void	50-1	1 step: 0.127mm	0.5 – 4mm	1 – 99
	-8	shift		

- (6) Main scanning direction (FR direction) distortion balance adjustment
- 1) Remove the OC glass, the right cabinet and the upper right side cover.



2) Loosen the copy lamp unit wire fixing screw.



 Manually turn the mirror base drive pulley and bring No. 2/3 mirror base unit into contact with the positioning plate.

At that time, if the front frame side and the rear frame side of No. 2/ 3 mirror base unit are brought into contact with the positioning plate at the same time, the mirror base unit parallelism is proper. If one of them is in contact with the positioning plate, perform the adjustment of 4).



 Loosen the set screw of the scanner drive pulley which is not in contact with No. 2/3 mirror base unit positioning plate. 5) Without moving the scanner drive pulley shaft, manually turn the scanner drive pulley until the positioning plate is brought into contact with No. 2/3 mirror base unit, then fix the scanner drive pulley.



6) Put No. 2/3 mirror base unit on the positioning plate again, push the projections on the front frame side and the rear frame side of the copy lamp unit to the corner frame, and tighten the wire fixing screw.



(7) Sub scanning direction (scanning direction) distortion adjustment (Winding pulley position adjustment)

This adjustment must be performed in the following cases:

- When the mirror base drive wire is replaced.
- When the lamp unit, or No. 2/3 mirror holder is replaced.
- When a copy as shown is made.



1) Set A3 (11" x 17") white paper on the original table as shown below.



- 2) Open the original cover and make a normal (100%) copy.
- Measure the width of the black background at the lead edge and at the rear edge.



If the width (La) of the black background at the lead edge is equal that (Lb) at the rear edge, there is no need to execute the following procedures of 4) - 7).

- Loosen the mirror base drive pulley fixing screw on the front frame side or on the rear frame side.
- When La < Lb</li>

Turn the mirror base drive pulley on the front frame side in the arrow direction A. (Do not move the mirror base drive pulley shaft.) When La > Lb



5) Tighten the fixing screw of the mirror base drive pulley.

#### <Adjustment specification>

La = Lb

6) Execute the main scanning direction (FR) distortion balance adjustment previously described in 2) again.

# (8) Main scanning direction (FR direction) distortion balance adjustment (Rail height adjustment)

When there is no skew copy in the mirror base scanning direction and there is no horizontal error (right angle to the scanning direction), the adjustment can be made by adjusting the No. 2/3 mirror base unit rail height.

Before performing this adjustment, be sure to perform the horizontal image distortion adjustment in the laser scanner section.

This adjustment must be performed in the following cases:

- When the mirror base wire is replaced.
- When the copy lamp unit and no. 2/3 mirror unit are replaced.
- When the mirror unit rail is replaced and moved.
- When a following copy is made.



1) Make an original for the adjustment.

Make test sheet by drawing parallel lines at 10mm from the both ends of A3 (11" x 17") white paper as shown below. (These lines must be correctly parallel to each other.)



- Make a normal (100%) copy of the test sheet on A3 (11" x 17") paper. (Fit the paper edge and the glass holding plate edge.)
- 3) Measure the distances (La, Lb, Lc, Ld) at the four corners as shown below.



When La = Lb and Lc = Ld, no need to perform the procedures 4) and 5).

 Move the mirror base B rail position up and down (in the arrow direction) to adjust.



• When La > Lb

Shift the mirror base B rail upward by the half of the difference of La–Lb.

When La < Lb</li>

Shift the mirror base B rail downward by the half of the difference of Lb–La.

Example: When La = 12mm and Lb = 9mm, shift the mirror base B rail upward by 1.5mm.

- When Lc >Ld Shift the mirror base B rail downward by the half of the difference of Lc-Ld.
- When Lc < Ld

When Lc < Ld, move the mirror base B on the paper feed side upward.

\* When moving the mirror base rail, hold the mirror base rail with your hand.

#### <Adjustment specification>

- La = Lb, Lc = Ld
- 5) After completion of adjustment, manually turn the mirror base drive pulley, scan the mirror base A and mirror base B fully, and check that the mirror bases are not in contact with each other.
- \* If the mirror base rail is moved extremely, the mirror base may be in contact with the frame or the original glass. Be careful to avoid this.
- (9) Main scanning direction (FR direction) magnification ratio adjustment (SIM 48-1)
- Note: Before performing this adjustment, be sure to check that the CCD unit is properly installed.
- 1) Put a scale on the original table as shown below.



- 2) Execute SIM 48-1.
- After warm-up, shading is performed and the current set value of the main scanning direction magnification ratio is displayed on the display section in 2 digits.
- 4) Manual correction mode (SIM48-1-1) Enter the set value and press the start key. The correction value is stored and a copy is made.

#### <Adjustment specification>

Note: A judgment must be made with 200mm width, and must not be made with 100mm width.

Adjustment mode	Spec value	SIM	Set value	Setting range
Main scanning direction	At normal: ±1.0%	48- 1-1	Add 1: 0.1% increase Reduce 1: 0.1%	1 – 99
ratio			decrease	

#### (10) Sub scanning direction (scanning direction) magnification ratio adjustment (SIM 48-1-2, SIM 48-1-3)

#### a. OC mode in copying

Note: Execute the procedure after completion of SIM 48-1-1.

 Put a scale on the original table as shown below, and make a normal (100%) copy.



- Compare the scale image and the actual scale. If necessary, perform the following adjustment procedures.
- 3) Execute SIM 48-1-2.
- 4) Enter the set value and press the start key. The set value is stored and a copy is made.

#### <Adjustment specification>

Adjustment mode	Spec value	SIM	Set value	Setting range
Sub scanning	At normal:	48-1-	Add 1:	1 – 99
direction	±1.0%	2	0.05% increase	
magnification			Reduce 1:	
ratio (OC mode)			0.05% decrease	

#### b. RSPF mode in copying

- Note: Before performing this adjustment, be sure to check that the CCD unit is properly installed and that OC mode adjustment in copying has been completed.
- 1) Put a scale on the original table as shown below, and make a normal (100%) copy to make a test chart.



- Note: Since the printed copy is used as a test chart, put the scale in parallel with the front side edge of the glass.
- 2) Set the test chart on the RSPF and make a normal (100%) copy.
- 3) Compare the scale image and the actual image.
- If necessary, perform the following adjustment procedures.
- 4) Execute SIM 48-1-3.
- After warm-up, shading is performed. The current front surface sub scanning direction magnification ratio correction value is displayed in two digits on the display section.

- 6) Enter the set value and press the start key. The set value is stored and a copy is made.
- Execute SIM 48-1-4. The current back surface sub scanning direction magnification ratio is displayed in two digits on the display section.
- Enter the set value and press the start key. The set value is stored and a copy is made.

#### <Adjustment specification>

Adjustment mode	Spec value	SIM	Set value	Setting range
Sub scanning direction	At normal: ±1.0%	48-1-3 48-1-4	Add 1: 0.05% increase	1 – 99
magnification ratio (RSPF mode)			Reduce 1: 0.05% decrease	

#### (11) Off center adjustment (RSPF mode)

- Note: Before performing this adjustment, be sure to check that the paper off center is properly adjusted.
- 1) Place the center position adjustment test chart (sheet with a straight line in the scan direction at the center) on the RSPF.
- 2) Make a normal copy from the manual paper feed tray, and check the printed copy with the test chart.

If any adjustment is required, perform the following procedure.

- 3) Execute SIM 50-12.
- After warm-up, shading is performed and the current set value of the off center adjustment is displayed on the display section in 2 digits.
- 5) Enter the set value and press the start key. The set value is stored and a copy is made.

#### <Adjustment specification>

Adjustment mode	Spec value	SIM	Set value	Setting range
Original off center mode	Single: Center ± 3.0mm	50-12	Add 1: 0.1mm shift to R side	1 – 99
(RSPF mode)	Duplex: Center		Reduce 1: 0.1mm	

#### (12) OC (RSPF) open/close detection position adjustment

1) Execute SIM 41-3.

 Gradually close the OC (RSPF) from the full open position, and measure distance A when the display on the operation panel changes. (See the figure below.)



Distance A = Table glass top - OC (RSPF) handle rib



#### <Adjustment specification>

OC (SPF) open/close position A: 125 - 225mm

- 3) If the distance is outside the specified range, adjust the open/close sensor attachment plate position as shown below.
- Distance < 125mm: Shift toward A.
- · Distance > 225mm: Shift toward B.



#### (13) Original sensor adjustment (SIM 41-2, 41-4)

- 1) Set A3 (11" x 17") paper on the OC table. (Keep the SPF (OC cover) open.)
- 2) Execute SIM 41-2.
- 3) Keep A=125mm, and execute SIM 41-4. (Do not put paper on the table.)
- 4) Check the reaction with SIM 41-1.
- (14) RSPF white correction pixel position adjustment (required in an RSPF model when replacing the lens unit) (SIM63-7)
- 1) Fully open the RSPF.
- 2) Execute SIM 63-7.
- When the operation panel displays "COMPLETE," the adjustment is completed.
- If the operation panel displays "ERROR," perform the following measures.
- When the display is 0: Check that the SPF is open.
   Check that the lamp is ON. (If the lamp is OFF, check the MCU connector.)

Check that the CCD harness is properly inserted into the MCU connector.

- When the display is 281 or above:
  - 1) Remove the table glass.
  - 2) Remove the dark box.
  - Slide the lens unit toward the front side and attach it, then execute SIM.
- When the display is 143 or below:
  - 1) Remove the table glass.
  - 2) Remove the dark box.
  - Slide the lens unit toward the rear side and attach it, then execute SIM.



- \* When the lens unit is moved, execute the OC main scanning magnification ratio auto adjustment, SIM 48-1-1.
- \* This adjustment is basically O.K. with SIM 63-7.

#### (15) RSPF scan position auto adjustment

#### [Function]

Used to adjust the RSPF scan position automatically.

#### [Operation]

- With the RSPF or the OC cover open, place a white paper background on the OC glass. (In the RSPF standard model, the RSPF glass surface is included.)
- Enter SIM53-08, and press [START] button. Outline of SIM: The optical unit is shifted to recognize the boundary between the OC glass and the RSPF glass cover. With the same position as the reference, the RSPF scan position is automatically adjusted.

<Note>

- After completion of the RSPF scan position auto adjustment, the RSPF lead edge adjustment must be executed. (Both surfaces)
- There must be no other sheet than the black chart on the glass surface.
- Especially when in RSPF scan, the center area is scanned in the main scan direction. Be careful to prevent external light from entering the scan area.
- Check that the lead edge is not shifted. (Both surfaces) (If the original lead edge adjustment has been made properly, even when the scan position is shifted, it is followed automatically.)



### C. Image density (exposure) adjustment

#### (1) Copy mode (SIM46-2)

1) Set a test chart (UKOG-0162FCZZ) on the OC table as shown below.



- 2) Place three or more sheets of A3 (11" x 17") paper on the test chart.
- 3) Execute SIM 46-2.
- After warm-up, shading is performed and the current set value of the density (exposure) level is displayed on the display section in 2 digits.

For mode selection, use the [10-key].

- 5) Change the set value with the [10-key] to adjust the copy image density.
- 6) Make a copy and check that the specification below is satisfied.
- Note: Place originals in the rear reference, and the test chart in the front reference when adjusting the exposure.

#### <Adjustment specification>

Density mode	Exposure level	Sharp Gray Chart output	Set value	Setting range
AUTO	-	"3" is copied.	If too bright,	
TEXT	3.0	"3" is copied.	increase the	
TEXT/PHOTO	3.0	"3" is copied.	on the copy	
PHOTO	3.0	"2" is copied.	quantity display.	
AE (TONER SAVE)	-	"3" is copied.	If too dark, decrease the	1 – 99
TEXT (TONER SAVE)	3.0	"3" is copied.	on the copy	
TEXT PHOTO (TONER SAVE)	3.0	"3" is copied.	quantity display.	

# [6] SIMULATION

### 1. General

#### A. Outline and purpose

The simulation has the following functions to grasp the machine operating status, identify the trouble position and causes in an earlier stage, and make various setups and adjustments speedily for improving the serviceability of the machine.

- 1) Various adjustments
- 2) Setup of specifications and functions
- 3) Canceling troubles
- 4) Operation check
- 5) Various counters check, setup, and clear
- 6) Machine operating status (operation history) data check, clear
- 7) Transfer of various data (adjustments, setup, operations, counters) The operating procedures and the displays differ depending on the form of the operation panel of the machine.

#### B. Code-type simulation

#### (1) Operating procedures and operations

- \* Entering the simulation mode
- 1) #/P key (program) ON  $\rightarrow$  Asterisk (\*) key ON  $\rightarrow$  CLEAR key ON  $\rightarrow$  Asterisk (\*) key ON  $\rightarrow$  Ready for input of a main code of simulation
- 2) Entering a main code with the 10-key  $\rightarrow$  START key ON
- 3) Entering a sub code with the 10-key  $\rightarrow$  START key ON
- 4) Select an item with the scroll key and the item key.
- The machine enters the mode corresponding to the selected item. Press START key to start the simulation operation.
   To cancel the current simulation mode or to change the main code and the sub code, press the SYSTEM SETTINGS key.
- \* Canceling the simulation mode to return to the normal mode
- 1) Press CLEAR ALL key.
- (2) How to change the simulation adjustment value set by the touch panel in the adjustment value entry process

#### a. Target SIM list

3-7, 8-1, 8-2, 8-3, 8-10, 8-11, 8-12, 9-5, 43-1, 44-34, 46-2, 46-9, 46-10, 46-11, 46-18, 46-20, 46-30, 46-31, 48-1, 48-2, 50-1, 50-5, 50-6, 50-10, 50-12, 51-1, 51-2, 51-9, 53-7

#### b. Touch panel operating procedure

- In the adjustment value setup menu, the selected item is highlighted. Change is made to the highlighted simulation adjustment value.
- If all the list of the adjustment items is not shown on one page, touch
  [<sup>↑</sup>] and [<sup>↓</sup>] button to shift the page.
- To change an adjustment value, touch the select the item to change the adjustment value. (The selected item is highlighted.) Enter the adjustment value and perform one of the following procedures, and the display of the adjustment value of the selected item is renewed as well as the adjustment value.
- 1) Touch [OK] button.
- 2) Touch another selected item to change the selection state.
- If all the list of the adjustment items cover two or more pages, touch [↑] and [↓] button to shift the page.
- 4) Press [START] key.
- \* For simulations which allow confirmation print, copying is started after changing the adjustment value.
  (46-2, 46-9, 46-10, 46-11, 46-18, 48-1, 48-2, 50-1, 50-5, 50-6, 50-10, 50-12, 51-2, the bold-faced items in the above list.)
- \* If the entry value is outside the adjustable range, an error buzzer sounds and the adjustment value is not renewed. Page shift is not made, either.



# 2. Simulation code list

Co	de	Function
Main	Sub	Function
	4	Used to check the operation of the scanner unit
	1	and its control circuit.
	0	Used to check the operation of sensor and detector
	2	in the scanning (read) section and the related circuit.
	1	Used to check the operation of the RSPF unit and
	1	the related circuit.
2	2	Used to check the operation of sensors and detectors
-	2	in the RSPF unit and the related circuit.
	3	Used to check the operation of the loads in the
	-	RSPF unit and the control circuits.
	2	Used to check the operation of sensor and detector
		In the finisher and the related circuit.
	3	Used to check the operation of the load in the
	10	Lead to make each adjustment of the finisher
3	10	Used to shack the object or operation
		Beciproceting operations are continuously
	11	performed or the home position is checked.
		(The shifter is shifted to the home position or
		moved in one way by the specified steps.)
	<u>^</u>	Used to check the operation of sensor and detector
4	2	in the option tray and the related circuit.
4	2	Used to check the operation of the load in the
	3	option tray and the control circuit.
	1	Used to check the operation of the display (LED),
		LCD in the operation panel, and control circuit.
5	2	Used to check the operation of the heater lamp and
Ū	-	the control circuit.
	3	Used to check the operation of the copy lamp and
	-	the control circuit.
		Used to check the operation of the loads (clutches
	1	and solenoids) in the paper transport system and
6		the control circuit.
	2	Used to check the operation of each fan motor and
	1	Lead to get the aging operation conditions
7	6	Used to set the cycle of intermittent aging
'	8	Lised to set the display of the warm-up time
	0	Used to check and adjust the operation of the
	1	developing bias voltage in each copy mode and the
		control circuit.
		Used to check and adjust the operation of the main
	2	charger grid voltage in each copy mode and the
		control circuit.
		Used to check and adjust the operation of the
	10	developing bias voltage in each printer mode and
8		the control circuit.
Ĭ		Used to check and adjust the operation of the main
	11	charger grid voltage in each printer mode and the
		CONTROL CIRCUIT.
	10	Used to check and adjust the operation of the
	13	control circuit
		Used to check and adjust the operation of the main
	14	charger grid voltage in FAX mode and the control
		circuit.
		Used to check and adjust the operation of the load
	1	(motor) in the duplex section and the control circuit.
_	4	Duplex motor RPM setting
9		Used to adjust the timing of switching from normal
	5	rotation to reverse rotation or from reverse rotation
		to normal rotation of the duplex motor.
10	0	Used to check the operation of the toner motor and
10	0	its control circuit.

Co	de	Function
Main	Sub	Function
14	0	Used to cancel excluding the self-diag U2/PF
	•	troubles.
16	0	Used to cancel the self-diag U2 trouble.
17	0	Used to cancel the self diag "PF" trouble.
21	1	Used to set the maintenance cycle.
	1	Used to check the counter value of each section.
		Used to check the total numbers of misfeed and
	2	considerably great it is judged as necessary for
	2	repair. The misfeed rate is obtained by dividing this
		count value with the total counter value.)
		Used to check the misfeed positions and the
	3	number of misfeed at each position.
	0	(When the number of misfeed is considerably
		great, it can be judged as necessary for repair.)
	4	Used to check the total trouble (self diag) history.
	5	Used to check the ROM version of each unit
		(Section).
22	6	information, and the machine adjustment values
22	7	Used to display of the administrator password
	8	Used to display the original, staple counter.
	0	Used to check the number of use of each paper
	9	feed section. (the number of prints)
	10	Used to check the system configuration.
	11	Used to display the FAX send/receive counter
	••	(FAX reception and print counter).
		Used to check the misfeed positions and the
	12	Number of misfeed at each position.
		great, it can be judged as necessary for repair.)
	13	Used to display the CRUM type.
	10	Used to display the scanner counter in the network
	19	scanner mode.
		Used to clear the misfeed counter, the misfeed
	1	history, the trouble counter, and the trouble history.
		(The counters are cleared after completion of maintenance)
		Used to clear the number of use (the number of
	2	prints) of each paper feed section.
	0	Used to clear the number usage data of the stapler,
	3	RSPF, and scanning.
	4	Used to reset the maintenance counter.
	-	Used to reset the developer counter.
24	5	(Ine developer counter of the DV unit which is
	6	Used to clear the convicunter
	0	Used to clear the OPC drum (membrane decrease)
	7	correction counter. (This simulation is executed
		when the OPC drum is replaced.)
	0	Used to clear the printer counter and other
	9	counters.
	10	FAX counter data clear
	15	Used to clear the scanner counter in the network
		scanner mode.
		Used to check the operation of the main drive
	1	operation of the toner concentration sensor.
25	-	(The toner concentration sensor output can be
		monitored.)
	2	Used to make the initial setting of toner
	-	concentration when replacing developer.
06	4	Used to set whether the job separator is installed
26	I	detection it is set in this simulation )

Co	de	<b>–</b>
Main	Sub	Function
	2	Used to set whether the automatic detection of
		paper size is made or not.
	-	Used to set the specifications of the auditor.
	3	Setting must be made depending on the use
		condition of the auditor.
	5	Used to set the count mode of the total counter and
	6	Used to set the specifications depending on the
	10	Lised to input the Software Key for E MAIL PIC
	12	Used to input the Software Key for the PS
	14	extension kit
	18	Used to set enable/disable of toner save operation
		Used to set the specification (language display) for
	22	the destination.
		Used to set ON/OFF of the heater lamp slow-up
	30	control conforming to the CE mark control.
		Used to set whether the same continuous troubles
	25	are displayed as one trouble or the series of
	35	troubles with SIM 22-4 when the same troubles
		occur continuously.
	36	Used to set whether the machine is stopped or not
26		when the maintenance counter life is expired.
	37	Used to set whether the machine is stopped or not
		when the developer counter life is expired.
	38	Used to set whether the machine is stopped or not
		Used to set ON/OFF of the block and white
	50	reversion function
	56	Gamma life correction setting
	57	Lised to set the model code
	- 07	Lised to set enable/disable of the FAX mode key
	60	when FAX is not installed. (When FAX is installed.
		the FAX mode is enabled regardless of this setup.)
		5 17
		In the power save time setting, the pre-heat (pre-
		heat mode setting) and the auto power shut off
	71	time can be set to the short time setup (pre-heat: 1
		min, auto power shut off: 1 min) and the long time
		setup (pre-heat: 15min, auto power shut off:
		60min).
		I he letterhead support is set.
	72	sot value of SIM 26.46 (Image output direction
		setting) is set to "Setting Enable" accordingly
		Used to display the sensor status attached to the
	1	machine.
		Used to display the status of the sensors attached
30	~	to the standard tray and the manual feed tray. (Use
	2	SIM 4-2 for the option trays.)
		The sensor of an uninstalled tray is not displayed.
	1	Used to check the sensor of the machine manual
		feed tray.
40	2	Used to adjust the manual paper feed tray paper
-		width detector detection level.
	3	I ne AD conversion value of manual feed width
		Used to check the document size detection shate
	1	sensor
		Used to adjust the detection level of the document
	2	size photo sensor.
41		Used to check the light reception level and the
	3	detection level of the original size detection photo
		sensor.
	А	Used to adjust the detection level of OC 20
	4	degrees.

Code		Function
Main	Sub	T unction
	1	Used to set the fusing temperature.
43	10	Used to set the paper feed cycle timing when
		printing postcards.
	1	Used to make various setups in each mode of
	0	process control.
	2	Drum life correction setting
	3	Used to set the DV count correction.
	9	information
		Lised to display the environment (temperature
	14	humidity) correction information.
44		Used to set the toner density control correction
	16	value.
	17	Used to display the toner density control reference
	17	value.
	34	Used to set the transfer current value in each
	04	mode.
		Used to set the time from the start of the main
	40	motor rotation (Ready) to the start of toner supply
		In previous rotation after turning on the power.
	2	mode
		Used to adjust the shift amount and the inclination
	9	value for each level (1 to 5) of the exposure mode
	Ū	(Text).
		Used to adjust the shift amount and the inclination
	10	value for each level (1 to 5) of the exposure mode
		(Text/Photo).
		Used to adjust the shift amount and the inclination
	11	value for each level (1 to 5) of the exposure mode
		(Photo).
	12	FAX exposure level adjustment
		(1 mode automatic adjustment)
	13	(Normal mode individual adjustment)
46		FAX exposure level adjustment
.0	14	(Fine text mode individual adjustment)
	15	FAX exposure level adjustment
	15	(Super Fine mode individual adjustment)
	16	FAX exposure level adjustment
	10	(Ultra Fine mode individual adjustment)
	18	Used to adjust inclination for each exposure mode.
	19	Used to set the control method of the exposure
	20	mode.
		BSPE for OC exposure
		Used to set the AE and the limit value in AE
	30	(Toner save).
		Used to set the AE and the limit value in AE
	31	(Toner save).
	39	Used to switch the FAX send image quality.
	1	Used to adjust the copy mode magnification ratio
		(main scanning direction, sub scanning direction).
48	2	Used to adjust the scanner mode magnification
		ratio (main/sub scanning direction).
	3	Used to adjust the print mode magnification ratio
	0	COTECTION.
	0	FAX magnification adjustment (read)
	1	Used to adjust the convilead edge position
50	I	Used to adjust the print image position (top margin)
	5	on the print paper in the print mode.
	<u> </u>	Used to adjust the print image position (top margin)
	6	on print paper in the copy mode. (RSPF)
	8	FAX lead edge adjustment (read)
	9	FAX lead edge adjustment (print)

Co	de	Function
Main	Sub	Function
50	10	Used to adjust the print image center position. (Adjustment can be made for each paper feed section.)
	12	Used to adjust the print image center position. (Adjustment can be made for each document mode.)
	1	Used to adjust the OPC drum separation pawl ON time.
51	2	Used to adjust the contact pressure of paper onto the resist roller in each section (copier paper feed section, duplex paper feed section, RSPF paper feed section). (When the print image position varies greatly for the paper or when a lot of paper jam troubles occur, the adjustment is required.)
	8	Used to set the OPC drum separation pawl operation inhibit. (ON/OFF)
	9	Used to adjust the OPC drum separation voltage ON/OFF timing.
	6	Used to adjust the detection level of the RSPF width. The adjustment method is the 4-point system. Set the guide to Max. (A3/WLetter) position, A4R/Letter R position, A5R/Invoice R position, and Min. position for adjustment.
	7	Used to enter the RSPF width detection adjustment value.
53	8	Used to adjust the RSPF scan position of the mirror unit automatically. For the RSPF scan position automatic adjustment, the mirror unit is shifted to 11mm before the RSPF glass cover edge, and is operated automatically to scan images by the unit of 1 step, detecting the position up to the glass cover automatically.
	9	BSPE read position adjustment
	10	PSPE over adjustment
55	10	Lised to set the seft switch
61	1	Used to set the Soft switch. Used to check the LSU (polygon motor) operation. Check speed can select 145mm/s or 122mm/s individually.
	1	Used to check the result of shading correction. (The shading correction data are displayed.)
63	7	Used to adjust the RSPF white correction start pixel position automatically. This adjustment is performed after the lens unit is replaced.
64	1	Used to check the operation of the printer function (auto print operation).
	1	Used to adjust the touch panel (LCD display section) detection position.
65	2	Used to check the touch panel (LCD display section) detection position adjustment result.
	5	Used to check the key inputs of the operation panel.
	1	Used to change and check the FAX-related soft SW.
	2	Used to clear the FAX-related soft SW. (Except for the FAX adjustment values)
66	3	FAX PWB memory check
	4	Signal send mode (Signal send level: Max.)
	5	Signal send mode (Signal send level soft SW setting)
	6	Printing the confidential password
	7	Print the screen memory contents
	10	Image data memory clear
	11	Used to send 300bps signals. (Signal send level: Max.)
	12	Used to send 300bps signals. (Signal send level: Set by soft SW)
	13	Used to register the dial numbers.
	14	Used to perform the dial test. (10 PPS send test)
	15	Used to perform the dial test. (20 PPS send test)
	16	Used to perform the dial test. (DTFM signal send test)

Code		Function
Main	Sub	Function
	17	Used to check the DTFM signal send operation.
		(Signal send level: Max.)
	18	Used to check the DTFM signal send operation.
	10	(Signal send level: Set by soft SW.)
	19	Used to write the SRAM data to the Flash ROM.
	20	Used to write the Flash ROM data to the SRAM.
	21	FAX information print
	22	Handset sound volume adjustment (Japan only)
66	24	Used to clear the FAST storage data. (SEC only)
	30	Used to set the TEL/LIU.
	31	Used to set the TEL/LIU.
	32	Receive data check
	33	Signal detection check
	34	Communication time measurement display
	37	Speaker sound volume adjustment
	41	CI signal check
	52	Pseudo-ringer check

# 3. Details of simulation

# 1

1-1		
Purpose	Operation test/check	
Function	Used to check the operation of the scanner unit and its	
(Purpose)	control circuit.	
Section	Optical (Image scanning)	
Item	Operation	

#### **Operation/procedure**

Enter the number of operations, and set the magnification ratio and the original size.

- 1. Select the desired item, and press the [START] key.
- 2. Enter the set value with the 10-key, and press the [START] key.

The scanner unit operates at the speed corresponding to the set value. The scan counter is displayed during execution.

Set magnification ratio	25% to 400% (1% increment) (Default 100%)
Document size	Varies depending on the destination.
Set number of times	1 to 999 (0: Continuous operation)

#### 1-2

Purpose	Operation test/check
Function	Used to check the operation of sensor and detector in
(Purpose)	the scanning (read) section and the related circuit.
Section	Optical (Image scanning)
Item	Operation

#### **Operation/procedure**

The status of sensors and detectors in the scanner section is displayed. The active sensors and detectors are highlighted.

MHPS Mirror home position sensor

# 2

2-1	
Purpose	Operation test/check
Function	Used to check the operation of the RSPF unit and the
(Purpose)	related circuit.
Section	RSPF
Item	Operation

#### **Operation/procedure**

Enter the number of operations, and set the magnification ratio and the original size.

- 1. Select the desired item, and press the [START] key.
- 2. Enter the set value with the 10-key, and press the [START] key.
- The RSPF unit operates at the speed corresponding to the set value.

The scan counter is displayed during execution.

Set magnification ratio	50% to 200% (1% increment) (Default 100%)	
Document size	Varies depending on the destination.	
Duplex	Selectable only when RSPF is installed.	
Set number of times	1 to 999 (0: Continuous operation)	

Note: Executable only when the RSPF is installed.

#### 2-2

Purpose	Operation test/check
Function	Used to check the operation of sensors and detectors
(Purpose)	in the RSPF unit and the related circuit.
Section	RSPF
Item	Operation

#### **Operation/procedure**

The operations of sensors and detectors in the RSPF section are displayed.

The active sensors and detectors are highlighted.

(For the original size, the detection result of the original size displayed on the copy menu is highlighted.)

EMPS	Original empty sensor
DLS1	Original length sensor (Small)
DLS2	Original length sensor (Large)
FGOD	RSPF paper feed cover open/close sensor
DFD	RSPF paper entry sensor
RDD	RSPF original exit sensor
OPCLS	Book sensor
	Original detection width sensor
SWD_LEN	(Unit of 0.1mm. "Width x 10" is displayed. Example: For
	300mm, 3000 is displayed.)
SWD_A/D	Original detection width sensor A/D value

RSPF width detection size (One of the following is displayed.)

A4/A3, LT/WLT, B5/B4, INV/LTR, A5/A4R, B5R, EXTRA, 8K/16K, 16KR

Note: Executable only when the RSPF is installed.

2-3	
Purpose	Operation test/check
Function	Used to check the operation of the loads in the RSPF
(Purpose)	unit and the control circuits.
Section	RSPF
Item	Operation

#### **Operation/procedure**

Select the load to be checked with the 10-key, and press the [START] key.

The motor for 10sec, the solenoid ON for 500msec, OFF for 500msec. (20 times)

Item		Content
1	DTM-F	RSPF motor forward rotation
2	DTM-R	RSPF motor reverse rotation
С	DFCL	RSPF paper feed clutch
4	CLH	RSPF PS clutch
5	GSOL	Document exit gate solenoid
6	RSOL	Document exit pressure solenoid

Note: Executable only when the RSPF is installed.

# 3

3-2	
Purpose	Operation test/check
Function	Used to check the operation of sensor and detector in
(Purpose)	the finisher and the related circuit.
Section	Finisher
Item	Operation

#### **Operation/procedure**

Used to display the operations of sensors and detectors in the finisher section.

The	active	sensors	and	detectors	are	highlighted	t
						~ ~	

FDTPD	Paper delivery tray paper detector
FSTPD	Staple tray paper detector
FAPHPS-R	Paper alignment plate HP sensor R
FAPHPS-F	Paper alignment plate HP sensor F
FDRPS	Delivery roller position sensor
FPPD1	Paper pass detector
FDTLLS	Delivery tray lower limit sensor
FTPS	Tray position sensor
FPLD	Paper level detector
FSSW	Safety switch
FSLD	Staple lead edge detector
FSED	Staple empty detector
FSHPS	Staple HP sensor
FPRD	Process tray paper rear edge detection
FPLS	Paper level sensor

Note: Executable only when the finisher is installed.

3-3		
Purpose	Operation test/check	
Function	Used to check the operation of the load in the finisher and the control circuit	
Section	Finisher	
Item	Operation	

#### **Operation/procedure**

Select the load to be checked with the 10-key, and press the  $\left[\text{START}\right]$  key.

The finisher main motor operates for 10sec, the staple motor 5 times, the tray lift-up motor one reciprocating operation, other motors max. 20 reciprocating operations from the home position, the solenoid repeats 500msec ON and 500msec OFF 20 times.

The staple operation motor operates only when there is no cartridge installed.

	Item	Content
1	FTLM	Tray lift motor
2	FSM	Staple motor
3	FPAM-R	Paper alignment motor R
4	FPAM-F	Paper alignment motor F
5	FPDM	Paper delivery motor
6	FPS	Paddle solenoid
7	FPTM	Paper transport motor
8	FDRLM	Delivery roller lift motor
9	FPGS	Paper gate solenoid
10	FARLS	Alignment roller lift solenoid
11	FSL	Staple light

#### 3-10

Purpose	Adjustment		
Function (Purpose)	Used to make each adjustment of the finisher.		
Item	Operation		

#### **Operation/procedure**

- 1. Select an item to be adjusted with 10-key, and press [START] key.
- 2. Enter an adjustment value with 10-key, and press [START] key.

Item		Content	Installation range	Default
1	FPAM ADJUST	Paper alignment width adjustment	40-60	50
2	FDRLM ADJUST	Paper delivery roller descending position adjustment	40-60	50

3-11	
Purpose	Operation test/check
Function (Purpose)	Used to check the shifter operation. Reciprocating operations are continuously performed or the home position is checked. (The shifter is shifted to the home position or moved in one way by the specified steps.)
Item	Operation

#### Operation/procedure

Select item "1," and press the [START] key.

The shifter is reciprocated continuously at the specified interval.

Item		Content
1	F-R	Reciprocating operation
2	HP CHECK	Home position check

#### [Selection 2]

- 1. Select item "2," and press the [START] key.
- 2. Move the shifter to the home position or in one way by the specified steps with the following keys.

[*] key	Shifts the position toward R side by the specified steps.
[0 key	Shifts the position toward HP side by the specified steps.
[#] key	Shifts to F.
SFTHP	Shifter home position (At detection, highlighted)

# 4

4-2	
Purpose	Operation test/check
Function	Used to check the operation of sensor and detector in
(Purpose)	the option tray and the related circuit.
Section	Paper feed
Item	Operation

#### **Operation/procedure**

The operating states of the sensor and the detector are displayed. (Only the installed option trays are displayed. For the standard tray, use SIM 30-2.)

The active sensors and detectors are highlighted.

PED2	2nd tray paper empty sensor
LUD2	2nd tray paper upper limit detection sensor
PFD2	2nd tray paper pass sensor
CD2	2nd tray empty sensor
PED3	3rd tray paper empty sensor
LUD3	3rd tray paper upper limit detection sensor
PFD3	3rd tray paper pass sensor
CD3	3rd tray empty sensor
PED4	4th tray paper empty sensor
LUD4	4th tray paper upper limit detection sensor
PFD4	4th tray paper pass sensor
CD4	4th tray empty sensor
DSWR2	2nd tray right door detection sensor
DSWR3	3rd tray right door detection sensor
DSWR4	4th tray right door detection sensor

Note: Execution is possible only when the option tray is installed.

4-3	
Purpose	Operation test/check
Function	Used to check the operation of the load in the option
(Purpose)	tray and the control circuit.
Section	Paper feed
Item	Operation

#### **Operation/procedure**

Select the load to be checked with the 10-key, and press the  $\left[\text{START}\right]$  key.

The motor for 10sec, the solenoid ON for 500msec, OFF for 500msec. The lift-up motor operates only when the tray is opened. (20 times)

Item		Content
1	LUM2	2nd tray lift-up motor
2	CPFC2	2nd tray pick-up solenoid
3	CPFS2	2nd tray paper feed clutch
4	TRC2	2nd tray transport roller clutch
F	DM	2nd tray paper transport motor
5		(3rd tray paper transport motor)
6	LUM3	3rd tray lift-up motor
7	CPFC3	3rd tray pick-up solenoid
8	CPFS3	3rd tray paper feed clutch
9	TRC3	3rd tray transport roller clutch
10	LUM4	4th tray lift-up motor
11	CPFC4	4th tray pick-up solenoid
12	CPFS4	4th trav paper feed clutch

Note: Execution is possible only when the option tray is installed.

5	

5-1	
Purpose	Operation test/check
Function	Used to check the operation of the display (LED), LCD
(Purpose)	in the operation panel, and control circuit.
Section	Operation (screen/operation)
Item	Operation

#### **Operation/procedure**

The LCD is displayed as follows. (All LED's are ON.)

With the upper half highlighted and the lower half normally displayed, contrast changes "Standard  $\rightarrow$  MAX  $\rightarrow$  MIN." in every 2sec.

SIMULATION 5-1		
LCD/LED CHECK.		

#### (6 sec later)

With the upper half normally displayed and the lower half highlighted, contrast changes "Standard  $\rightarrow$  MAX  $\rightarrow$  MIN." in every 2sec.



\* When returning to the sub menu selection menu, the display of the standard contrast is displayed for an instant.

5-2	
Purpose	Operation test/check
Function	Used to check the operation of the heater lamp and the
(Purpose)	control circuit.
Section	Fusing
Item	Operation

#### Operation/procedure

1. Select the lamp to be checked with the 10-key, and press the [START] key.

ON/OFF operation of the heater lamp is repeated 5 times in an interval of 100ms/900ms.

When completing the operation, the cooling fan is rotated at a low speed. Item Content

Item		Content	
1	HL1	Heater lamp 1 (Main) operation	
2	HL2	Heater lamp 2 (Sub) operation	

5-3	
Purpose	Operation test/check
Function	Used to check the operation of the copy lamp and the
(Purpose)	control circuit.
Section	Optical (Image scanning)
Item	Operation

#### **Operation/procedure**

When the [START] key is pressed, the copy lamp is lighted for 10sec.
6-1	
Purpose Operation test/check	
Function (Purpose)	Used to check the operation of the loads (clutches and solenoids) in the paper transport system and the control circuit.
Section Paper transport (Discharge/Switchback/Transport)	
Item	Operation

1. Select the load to be checked with the 10-key, and press the [START] key.

The motor for 10sec, the solenoid ON for 500msec, OFF for 500msec. (20 times)

When the [SYSTEM SETTINGS] is pressed, the operation is interrupted. The lift-up motor operates only when the tray is opened.

	Item	Content
1	LUM1	1st tray lift-up motor
2	CPFC1	1st tray pick-up solenoid
3	CPFS1	1st tray paper feed clutch
4	MPFS	Manual feed pick-up solenoid
5	RRC	Resist roller clutch
6	PSPS	Separation pawl solenoid
7	OGS	Paper exit gate switching solenoid
8	LUM2	2nd tray lift-up motor
9	CPFC2	2nd tray pick-up solenoid
10	CPFS2	2nd tray paper feed clutch
11	TRC2	2nd tray transport roller clutch
12	LUM3	3rd tray lift-up motor
13	CPFC3	3rd tray pick-up solenoid
14	CPFS3	3rd tray paper feed clutch
15	TRC3	3rd tray transport roller clutch
16	LUM4	4th tray lift-up motor
17	CPFC4	4th tray pick-up solenoid
18	CPFS4	4th tray paper feed clutch
19	ROGS	Right paper exit gate solenoid

The lift-up motor operates only when the tray is opened.

6-2		
Purpose	Operation test/check	
Function	Used to check the operation of each fan motor and its	
(Purpose)	control circuit.	
Section	Others	
Item	Operation	

#### Operation/procedure

Select the load to be checked with the 10-key, and press the [START] key.

The selected load is operated for 10sec.

Item		Content
1	VFM	Fusing fan operates
2	DCFM&DCFM2	Power cooling fan, power cooling fan 2 operations
3	VFM2	Fusing exit paper fan operates
3	VFM&DCFM&DCFM2 &VFM2	Fusing fan, power cooling fan, and power cooling fan 2 are operated at the same time.

7	

7-1	
Purpose	Setting/Operation test/check
Function (Purpose)	Used to set the aging operation conditions.
Item	Operation

#### **Operation/procedure**

- 1. Select the load to be set with the 10-key.
- 2. Press the [START] key.

When selected without setup, the selected value is registered and highlighted. When selected with previous setup, the previous setup is canceled and it is displayed normally.

Press [CA] key, and the simulation will be terminated and the machine goes into the aging standby mode with the set content.

I his setting is canceled by power OF
---------------------------------------

	Item	Content
1	AGING	Aging enable/disable setting
2	MISFEED	Jam detection enable/disable setting
3	FUSING*1	Fusing operation enable/disable setting The fusing temperature is not controlled. The heater is not turned ON.
4	INTERVL	Intermittent setting (Valid only when set to AGING.)
5	WARMUP	Warm-up save setting The machine goes into the ready state only by shading, disregarding fusing and process control. After going into the ready state, normal control is performed.
6	DV CHK.	Developing unit detection enable/disable setting

\*1: When the machine exits from the fusing ignoring state, the roller may be cooled down. Therefore, reset the machine to warm up again.

When, therefore, the simulation is canceled by pressing the [CA] key or when the copy mode display is shifted to the initial menu display in the simulation mode of one page copy, the machine is reset.

Note: In SIM 7-1, pressing [CA] key terminates the simulation and the machine enters the aging mode without resetting. Therefore, to perform "4. Intermittent setup," the intermittent cycle must be set with SIM 7-6 in advance.

Reset is not performed when the machine enters the aging mode.

7-6	
Purpose	Setting/Operation test/check
Function (Purpose)	Used to set the cycle of intermittent aging.
Item	Operation

#### **Operation/procedure**

- 1. Enter the interval aging cycle time (sec) with the 10-key pad. Refer to SIM 7-1.
- 2. Press the [START] key.

When the [START] key is pressed in aging, copying is performed continuously. This simulation is used to set the time interval between copy operations in the unit of second.

This setting is valid when SIM 7-1 (Intermittent setting) is enabled.

Setting range	1-255
Default	3

7-8	
Purpose	Setting/Operation test/check
Function (Purpose)	Used to set the display of the warm-up time.
Item	Operation
• ·· ·	

1. Warm-up starts by the cover open/close.

(Can be performed repeatedly by open/close of the cover.)

- 2. The warm-up time is counted up and displayed in the unit of sec. If the [CA] key is pressed at this time, count-up is interrupted to terminate the simulation. (However, warm-up is continued.)
- 3. After completion of warming up, "WARM UP COMPLETED" is displayed and the control returns to the initial screen.

## 8

8-1	
Purpose	Adjustment/Operation test/check
Function (Purpose)	Used to check and adjust the operation of the developing bias voltage in each copy mode and the control circuit.
Section	Image process (Photoconductor/Developing/Transfer/Cleaning) Developer/Toner hopper

#### **Operation/procedure**

1. Touch the exposure mode to be changed. The current set value is displayed.

- 2. Enter the set value with the 10-key.
- 3. Press the [START] key.

Output is made with the entered value, and the display returns to the original state.

Item		Content	Setting	Default
			range	
1	AE (145)	AE (145mm/s)		450
2	TEXT (145)	Character (145mm/s)		450
3	TEXT/PHOTO (145)	Character/Photo (145mm/s)		450
4	PHOTO (145)	Photo (145mm/s)		450
5	TONER SAVE (145)	Toner save (145mm/s)	200-	400
6	AE (122)	AE (122mm/s)	650	450
7	TEXT (122)	Character (122mm/s)		450
8	TEXT/PHOTO (122)	Character/Photo (122mm/s)		450
9	PHOTO (122)	Photo (122mm/s)	1	450
10	TONER SAVE (122)	Toner save (122mm/s)		400

(\*) Linked with the destinations of SIM 26-6.

Linked with the auto exposure mode of SIM 46-19-1.

The minimum increment is 10V.

The result of (Set value) -200/ 10 is stored in the EEPROM.

When reading a value from the EEPROM, the value of (EEP value \*10+200) is used as the set value.

8-2	
Purpose	Adjustment/Operation test/check
Function (Purpose)	Used to check and adjust the operation of the main charger grid voltage in each copy mode and the control circuit.
Section	Image process (Photoconductor/Developing/Transfer/Cleaning) Photo conductor

#### **Operation/procedure**

- 1. Touch the exposure mode to be changed. The current set value is displayed.
- 2. Enter the set value with the 10-key.
- 3. Press the [START] key.

Output is made with the entered value for 30sec, and the display returns to the original state.

Item		Content	Setting range	Default
1	AE (145)	AE (145mm/s)		590
2	TEXT (145)	Character (145mm/s)		590
3	TEXT/PHOTO (145)	Character/Photo (145mm/s)	-	590
4	PHOTO (145)	Photo (145mm/s)		590
5	TONER SAVE (145)	Toner save (145mm/s)	350-	540
6	AE (122)	AE (122mm/s)	750	590
7	TEXT (122)	Character (122mm/s)		590
8	TEXT/PHOTO (122)	Character/Photo (122mm/s)		590
9	PHOTO (122)	Photo (122mm/s)	1	590
10	TONER SAVE (122)	Toner save (122mm/s)	1	540

Min. unit: 10V increment

(\*) Linked with the destinations of SIM 26-6. Linked with the auto exposure mode of SIM 46-19-1.

8-10		
Purpose Adjustment/Operation test/check		
Function (Purpose)	Used to check and adjust the operation of the developing bias voltage in each printer mode and the control circuit.	
Section	Image process (Photoconductor/Developing/Transfer/Cleaning) Developer/Toner hopper	

#### Operation/procedure

- 1. Touch the exposure mode to be changed. The current set value is displayed.
- 2. Enter the set value with the 10-key.
- 3. Press the [START] key.

Output is made with the entered value for 30sec, and the display	/
returns to the original state.	

			Installa	
	Item	Content	tion	Default
			range	
1	DENS1 (145)	Density1 (145mm/s)		300
2	DENS2 (145)	Density2 (145mm/s)		370
3	DENS3 (145)	Density3 (145mm/s)		420
4	DENS4 (145)	Density4 (145mm/s)		530
5	DENS5 (145)	Density5 (145mm/s)		600
6	TS (145)	Toner save (145mm/s)	200-	250
7	DENS1 (122)	Density1 (122mm/s)	650	300
8	DENS2 (122)	Density2 (122mm/s)		370
9	DENS3 (122)	Density3 (122mm/s)		420
10	DENS4 (122)	Density4 (122mm/s)		530
11	DENS5 (122)	Density5 (122mm/s)		600
12	TS (122)	Toner save (122mm/s)		250

The minimum increment is 10V.

The result of (Set value) -200/ 10 is stored in the EEPROM.

When reading a value from the EEPROM, the value of (EEP value \*10+200) is used as the set value.

8-11	
Purpose	Adjustment/Operation test/check
Function (Purpose)	Used to check and adjust the operation of the main charger grid voltage in each printer mode and the control circuit.
Section	Image process (Photoconductor/Developing/Transfer/Cleaning) Photo conductor

#### **Operation/procedure**

- 1. Touch the exposure mode to be changed. The current set value is highlighted.
- 2. Enter the set value with the 10-key.
- 3. Press the [START] key.

## Output is made with the entered value for 30sec, and the display returns to the original state.

			Installa	
Item		Content	tion	Default
			range	
1	DENS1 (145)	Density 1 (145mm/s)		440
2	DENS2 (145)	Density 2 (145mm/s)		510
3	DENS3 (145)	Density 3 (145mm/s)		560
4	DENS4 (145)	Density 4 (145mm/s)		670
5	DENS5 (145)	Density 5 (145mm/s)		740
6	TS (145)	Toner save (145mm/s)	350-	390
7	DENS1 (122)	Density 1 (122mm/s)	750	440
8	DENS2 (122)	Density 2 (122mm/s)		510
9	DENS3 (122)	Density 3 (122mm/s)		560
10	DENS4 (122)	Density 4 (122mm/s)		670
11	DENS5 (122)	Density 5 (122mm/s)	1	740
12	TS (122)	Toner save (122mm/s)	1	390

Min. unit: 10V increment

## 8-13 Purpose Adjustment/Operation test/check Function (Purpose) Used to check and adjust the operation of the developing bias voltage in FAX mode and the control circuit. Section Image process (Photoconductor/Developing/Transfer/Cleaning) Developer/Toner hopper

#### **Operation/procedure**

1. Enter the set value with the 10-key.

2. Press the [START] key.

Output is made with the entered value for 30sec. and the display returns to the original state.

Setting range	200-650
Default	450

The minimum increment is 10V.

The result of (Set value-200) / 10 is stored in the EEPROM.

When reading a value from the EEPROM, the value of (EEP value \* 10 +200) is used as the set value.

Therefore, an even number must be entered. If not, the entered odd number +1 is displayed after pressing [START] key.

8-14		
Purpose	Adjustment/Operation test/check	
Function (Purpose)	Used to check and adjust the operation of the main charger grid voltage in FAX mode and the control circuit.	
Section	Image process (Photoconductor/Developing/Transfer/Cleaning) Photo conductor	

#### **Operation/procedure**

- 1. Enter the set value with the 10-key.
- 2. Press the [START] key.

Output is made with the entered value for 30sec. and the display returns to the original state.

Setting range	350-750
Default	590

9

9-1	
Purpose	Operation test/check
Function	Used to check and adjust the operation of the load
(Purpose)	(motor) in the duplex section and the control circuit.
Section	Duplex
Item	Operation

#### **Operation/procedure**

1. Select the operation mode with the 10-key.

2. Press the [START] key.

The operation is performed for 30sec, and the display returns to the original state.

Item Content		Content
1	DMF145	Duplex motor/Duplex 2 motor forward rotation (145mm/s)
2	DMF122	Duplex motor/Duplex 2 motor forward rotation (122mm/s)
3	DMR145	Duplex motor/Duplex 2 motor reverse rotation (145mm/s)
4	DMR122	Duplex motor/Duplex 2 motor reverse rotation (122mm/s)

Operation test/check
Duplex motor RPM setting
Duplex
Operation

Enter the set value with the 10-key.

When the duplex motor setting is made, the duplex 2motor is also set accordingly.

Setting range	1-13
Default	5

#### 9-5

Purpose	Adjustment
Function (Purpose)	Used to adjust the timing of switching from normal rotation to reverse rotation or from reverse rotation to normal rotation of the duplex motor.

#### **Operation/procedure**

- 1. Touch the item to set.
- 2. Enter the set value with the 10-key, and press the [START] key.

Item		Installation range	Default
1	145mm/s		18
2	122mm/s	10 76	18
3	RIGHT 145mm/s	10-70	50
4	RIGHT 122mm/s		50

## 10

10-0		
Purpose	Operation test/check	
Function	Used to check the operation of the toner motor and its	
(Purpose)	control circuit.	
	Image process	
Section	(Photoconductor/Developing/Transfer/Cleaning)	
	Developer/Toner hopper	
Item	Operation	

#### **Operation/procedure**

Press the [START] key and operate the toner motor for 30 sec.



14-0			
Purpose	Clear/Cancel (Trouble etc.)		
Function (Purpose)	Used to cancel excluding the self-diag U2/PF troubles.		
Item	Trouble	Error	

#### **Operation/procedure**

- 1. Press the [START] key.
- 2. When "1: YES" is selected, troubles other than U2 and PF are canceled. (When "2: NO" is selected, the simulation is canceled.)

Í	6

16-0		
Purpose Clear/Cancel (Trouble etc.)		
Function (Purpose)	Used to cancel the self-diag U2 trouble.	
Item	Trouble	Error

#### **Operation/procedure**

- 1. Press the [START] key.
- When "1: YES" is selected, U2 trouble is canceled. (When "2: NO" is selected, the simulation is canceled.)

|--|

### 17-0

Purpose	Cancel (Trouble, etc)		
Function (Purpose)	Used to cancel the self diag "PF" trouble.		
Item	Trouble	Error	

#### Operation/Procedure

- 1. Press the [START] key.
- When "1: YES" is selected, PF trouble is canceled. (When "2: NO" is selected, the simulation is canceled.)

2	

21-1		
Purpose	Setting	
Function (Purpose)	Used to set the maintenance cycle.	
Item	Specifications	Counter

#### **Operation/procedure**

- 1. Enter the set value with the 10-key.
- 2. Press the [START] key.

Item	Content	
	26cpm	31cpm
0	5K	5K
1	10K	10K
2	20K	50K
3	25K	75K
4	50K	100K
5	75K (Default)	150K (Default) *
6	FREE	FREE

- \* When selecting 150K, maintenance message is displayed by implementing the following conditions.
- Maintenance count = 150K.
- DV count = 100K
- DR count = 100K
- \* When maintenance message is displayed, replace consumption part reaching the number of sheets of maintenance, then clear the replaced part's counter only.

## 22

22-1	
Purpose	Adjustment/setting/operation data output/check (display/print)
Function (Purpose)	Used to check the counter value of each section.
Item	Counter

#### **Operation/procedure**

Each counter is displayed.

TOTAL	Total counter
MAINTENANCE	Maintenance counter
DEVE	Developer counter
DRUM	Drum counter
COPY	Copy counter
PRINTER	Printer counter
IMC	IMC counter
DUPLEX	Duplex counter
OTHERS	The other counters
FAX SEND	FAX Send counter
FAX RCV	FAX receive counter
FAX OUTPUT	FAX print counter
DEVE RANGE	Developer traveling distance counter
DRUM RANGE	Drum traveling distance counter
DEVE ROLL	Developer rotation counter (K)
DRUM ROLL	Drum rotation counter (K)
DEVE LIFE	Developer life meter (%)
DRUM LIFE	Drum life meter (%)

22-2	
Purpose	Adjustment/setting/operation data output/check (display/print)
Function (Purpose)	Used to check the total numbers of misfeed and troubles. (When the number of misfeed is considerably great, it is judged as necessary for repair. The misfeed rate is obtained by dividing this count value with the total counter value.)
Item	Trouble

#### **Operation/procedure**

Each counter data are displayed.

PAPER JAM	JAM counter
SPF JAM	RSPF JAM counter
TROUBLE	Trouble counter

The counter display is in 7 digits.

22-3		
Purpose	Adjustment/setting/operation data output/check (display/print)	
Function (Purpose)	Used to check the misfeed positions and the number of misfeed at each position. (When the number of misfeed is considerably great, it can be judged as necessary for repair.)	
Item	Trouble	Mis-feed

#### **Operation/procedure**

The misfeed history is displayed in the sequence of recentness by the name of sensors and detectors. Max. 40 items of information can be stored in memory. (The old ones are deleted sequentially.) The trouble section may be determined by the data.

(Jam cause code)

Item	Jam contents
TRAY1	1st tray pick-up miss
TRAY2	2nd tray pick-up miss
TRAY3	3rd tray pick-up miss
TRAY4	4th tray pick-up miss
BPT	Multi manual feed pick-up miss
PPD1_ND	Paper-in sensor lead edge jam
PPD1_ST	Paper-in sensor rear edge jam
PPD1_DUP	Paper-in sensor reverse jam
PPD2_ND	Duplex sensor lead edge jam
PPD2_ST	Duplex sensor rear edge jam
PPD_PRI	PS time out jam
POD3_ND	Right paper exit lead edge jam
POD3_ST	Right paper exit rear edge jam
POD2_ND	Upper tray paper exit lead edge jam
POD2_ST	Upper tray paper exit rear edge jam
POD1_ND	Lower tray paper exit lead edge jam
POD1_ST	Lower tray paper exit rear edge jam
PINT_SHORT	Abnormality between PS papers.
PFD2_ND	2nd paper pass lead edge jam
PFD2_ST	2nd paper pass rear edge jam
PFD3_ND	3rd paper pass lead edge jam
PFD3_ST	3rd paper pass rear edge jam
PFD4_ND	4th paper pass lead edge jam
PFD4_ST	4th paper pass rear edge jam
SIZE_SHORT	Duplex short scale error
FPPD1_N	Finisher entry port sensor not-reached jam
FPPD1_S	Finisher entry port sensor remaining jam
FSTPD_S	Finisher paper exit remaining jam
FSTPLJ	Finisher staple jam

22-4	
Purpose	Adjustment/setting/operation data output/check (display/print)
Function (Purpose)	Used to check the total trouble (self diag) history.
Item	Trouble

#### **Operation/procedure**

The trouble error codes are displayed in the sequence of the latest one first. Max. 40 items of information are stored. (Older ones are deleted in sequence.) The machine condition can be estimated by this data.

22-5	
Purpose	Adjustment/Setting/Check
Function (Purpose)	Used to check the ROM version of each unit (section).
Item	Software

#### **Operation/procedure**

Used to display the ROM version of each section.

[Display example]

ROM version  $1.250 \rightarrow [1.25]$  (up to 2 decimal places)

The display of the protocol monitor and the soft SW follows this display.

S/N	Machine serial number
MCU	Main Control Unit
IMC	IMC
OPE	Panel + Panel label code
PRINTER	PRINTER
NIC	NIC
FINISHER	FINISHER
FAX	FAX
IMC OPE PRINTER NIC FINISHER FAX	IMC Panel + Panel label code PRINTER NIC FINISHER FAX

If it is not installed, "-----" is displayed.

Panel display	Destination	Panel software support language			
JPN	Japan	Japanese, American English, English			
	SEC				
	SECL				
FES	SUK	American English, English, French, Spanish, Brazilian Portuguese			
	SCA/SCNZ				
	Distributor area				
EEU	SEEG/ SEA/East Europe, etc.	English, German, Polish, Czech, Hungarian, Greek, Turkish, Russian, French, Italian, Slovak			
NEU	SEF/ SEES/ SEIS/SEN, etc.	English, German, French, Spanish, Dutch, Italian, Portuguese, Swedish, Norwegian, Finnish, Danish			
CHN	SOCC	Simplified Chinese, American English, English, Japanese			
TWN	Taiwan	Traditional Chinese (Local support), American English, English			
ABB	Saudi	American English, English, French, Spanish,			
	Arabia	Hebrew (Local support), Arabic			
FAS	Iran	English, Arabic, Persian, American English, French, Spanish			

Purpose	Adjustment/setting/operation data output/check (display/print)		
Function	Used to print each system setting, the account		
(i uipose)	mormation, and the machine adjustment values.		
Item	Data Setting/adjustment data		

(Initial screen)

The currently set value is highlighted beside the adjustment item.

- 1. Select the adjustment item with the 10-key.
- 2. Press the [START] key.

The display is shifted to the copy menu and the set value is stored.

- 3. Select the paper feed tray and the print density.
- 4. Press the [START] key. Copying is started.

After canceling a jam (After picking up, the [C] key is invalid.)

When the other information is repeatedly printed, the display may show the message, "Remove original from original table." However, the operation is performed normally.

Item		Content		
1	ALL	All lists group print (Default)		
2	SYSTEM SETTING	System setting information list		
3	ACCOUNTING COUNTERS	List of total number of prints		
4	AUDITOR NO.	Department number list		
5	MACHINE SIM SETTING	Machine simulation setting list		
6	FAX SIM SETTING*1	FAX simulation setting list (Only when the FAX board is installed. The display does not go to the print data transfer display, but to the FAX SIM menu.)		

\* When the IMC board is not installed, key input is disabled.

\* Duplex print cannot be made.

- \* For the FAX SIM setting list, the display and the operating procedures differ.
- Note: When the simulation is canceled, the display returns to the original state but the machine is not reset.

22-7				
Purpose	User data output/Check (Display/Print)			
Function (Purpose)	Used to display of the administrator password.			
Item	Data User data			

#### **Operation/procedure**

Used to display the administrator password.

#### 22-8

Purpose	Adjustment/setting/operation data output/check (display/print)
Function (Purpose)	Used to display the original, staple counter.
Item	Counter

#### **Operation/procedure**

Each counter is displayed.

SPF	RSPF counter
SCAN	Scan counter
STAPLE	Stapler counter

The counter display is in 7 digits.

22-9	
Purpose	Adjustment/setting/operation data output/check (display/print)
FunctionUsed to check the number of use of each paper fe(Purpose)section. (the number of prints)	
Section	Paper feed
Item	Counter

#### **Operation/procedure**

Used to display each paper feed counter.

BYPASS	Manual feed counter
TRAY1	Tray 1 counter
TRAY2	Tray 2 counter
TRAY3	Tray 3 counter
TRAY4	Tray 4 counter

The counter display is in 7 digits.

#### 22-10

Purpose	Adjustment/setting/operation data output/check (display/print)	
Function (Purpose)	Used to check the system configulation.	
Item	Specifications Option	

#### **Operation/procedure**

The detected machine composition is displayed.

(The job	separator	cannot be	detected.	Based or	SIM 26-1	setting.)
----------	-----------	-----------	-----------	----------	----------	-----------

Item	Display items	
SPEED	26CPM/31CPM	
DF	NONE/[1: RSPF]	
OUTPUT	NONE/[2: Finisher]/[3: Job separator]	
CASETTE1	NONE/[4: One-step paper feed unit]	
CASETTE2	NONE/[5: Two-step paper feed unit]	
IMC MEM	NONE/Expansion memory capacity (MB)	
PRINTER	NONE/[6: PRINTER]	
PS3	NONE/[7: PS3]	
NIC	NONE/[8: NIC]	
SCANNER	NONE/[9: SCANNER]	
FAX	NONE/[10: FAX]	
FAX MEM	NONE/Memory capacity (MB)	
HAND SET	NONE/[11: Handset]	
USB HOST	NONE/USB HOST	

Item	Display items	
ICCARDR/W	NONE/MX-ECX2	

NONE: When it is not installed, "-----" is displayed.

[]: Shows the product code in the list below.

No.	Item	Model code
1	RSPF	MX-RP10
2	Finisher	MX-FN13
3	Job separator	MX-TR11
4	1 tray paper feed unit	MX-DE10 (*1)
5	2 tray paper feed unit	MX-DE11 (*1)
6	PRINTER	MX-PB12
7	PS3	MX-PK10
8	NIC	STANDARD (Only SoftNic)
9	SCANNER	MX-NSX1
10	FAX	AR-FX7
11	Handset	AR-HN4

\*1: The number of installed units is displayed beside the model code. For the tray, only the option tray is displayed.

22-11	
Purpose	Adjustment/setting/operation data output/check (display/print)
Function	Used to display the FAX send/receive counter
(Purpose)	(FAX reception and print counter).
Section	FAX
Item	Counter

#### Operation/procedure

Used to display the FAX send/receive counter.

FAX SEND PAGE/TIME	FAX send page and time
FAX RECEIVE PAGE/TIME	FAX receive page and time
FAX OUTPUT	FAX output (number of print)

The counter display is in 8 digits.

Note: Executable only when the FAX is installed.

22-12		
Purpose	Adjustment/setting/operation data output/check (display/print)	
Function (Purpose)	Used to check the misfeed positions and the number of misfeed at each position. (When the number of misfeed is considerably great, it can be judged as necessary for repair.)	
Section	RSPF	
Item	Trouble	Misfeed

#### **Operation/procedure**

Used to display the RSPF jam history data sequentially from the latest one.

Forty RSPF jam histories are displayed sequentially from the la	test
---	------

		_	Paper Reached/
Error code	Name	Sensor name	Not Reached to
			the sensor
	RSPF paper in lead	SPF P-IN	Not Reached
DED_ND	edge jam	sensor	NUL NEACHEU
DED ST	RSPF paper in rear	SPF P-IN	Beached
000_31	edge jam	sensor	neacheu
	DSDE papar out		Reached,
RDD_ND		SFF F-IIN	P_OUT Not
_	lead edge jam	sensor	Reached
PDD ST	RSPF paper out	SPF P-OUT	Reached, P_IN
ופ_טטח	rear edge jam	sensor	passed (OFF)
			Not Reached
JAM_REV		SFF F-IIN	(Paper after
	reverse jam	sensor	reversing)
	RSPF short size	SPF P-IN	Passed (OFF at
URG_SHORT	error	sensor	JAM)

			Paper Reached/	
Error code	Name	Sensor name	Not Reached to	
			the sensor	
		SPF P-OUT	Booohod	
	RSPF long size	sensor	neacheu	
ORG_LONG	error	SPF P-IN	Decelerat	
		sensor	Reached	

#### 22-13

Purpose	Adjustment/setting/operation data output/check (display/print)
Function (Purpose)	Used to display the CRUM type.
Item	Specifications

#### **Operation/Procedure**

Used to	display	the	CRUM	type.
---------	---------	-----	------	-------

Item	Content
00	Not fixed.
01	AR-A
02	AR-B
03	AR-C
04	China
05	Japan
99	Conversion completed.

#### 22-19

Purpose	Adjustment/setting/operation data output/check (display/print)
Function	Used to display the scanner counter in the network
(Purpose)	scanner mode.
Section	Network scanner
Item	Counter

#### Operation/procedure

Used to display the scanner counter.

SCANMODE Scanner mode counter

The counter display is in 7 digits.

ļ	2	4	

24-1	
Purpose	Data clear
Function (Purpose)	Used to clear the misfeed counter, the misfeed history, the trouble counter, and the trouble history. (The counters are cleared after completion of maintenance.)
Section	Memory
Item	Counter

#### **Operation/procedure**

Jam/trouble counter is cleared individually. (The history of each counter is deleted when clearing)

- 1. Select the counter to be cleared with the 10-key.
- 2. Press the [START] key.
  - The confirmation menu is shown.
- 3. Select "1: YES."
  - 1: YES (Cleared)

2: NO (Not cleared) (Default)

Item Content		Content	
1	JAM	JAM counter/JAM history	
2	SPF JAM	RSPF JAM counter/RSPF JAM history	
3	TROUBLE	Trouble counter/Trouble history	

Purpose	Data clear
Function	Used to clear the number of use (the number of prints)
(Purpose)	of each paper feed section.
Section	Paper feed
Item	Counter

#### **Operation/procedure**

Used to clear each paper feed counter individually.

- 1. Select the counter to be cleared with the 10-key.
- 2. Press the [START] key. The confirmation menu is shown.
- 3. Select "1: YES."

1: YES (Cleared)

2: NO (Not cleared) (Default)

	Item	Content
1	BYPASS	Manual feed counter
2	TRAY1	Tray 1 counter
3	TRAY2	Tray 2 counter
4	TRAY3	Tray 3 counter
5	TRAY4	Tray 4 counter

#### 24-3

Purpose	Data clear
Function	Used to clear the number usage data of the stapler,
(Purpose)	RSPF, and scanning.
Section	Transport/Finisher
Item	Counter

#### **Operation/procedure**

Used to clear the original and staple counters individually.

- 1. Select the counter to be cleared with the 10-key.
- 2. Press the [START] key.
- The confirmation menu is shown.
- 3. Select "1: YES."
  - 1: YES (Cleared)
  - 2: NO (Not cleared) (Default)

	Item	Content
1	SPF	RSPF counter
2	SCAN	Scan counter
3	STAPLE	Stapler counter

#### 24-4

Purpose	Data clear
Function (Purpose)	Used to reset the maintenance counter.
Item	Counter

#### **Operation/procedure**

- 1. Press the [START] key. The confirmation menu is shown.
- 2. Select "1: YES."
  - 1: YES (Cleared)
    - 2: NO (Not cleared) (Default)

24-5				
Purpose	Data clear			
Function (Purpose)	Used to reset the developer counter. (The developer counter of the DV unit which is installed is reset.)			
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)			
	Developer/Toner hopper			
Item	Counter	Developer		

#### Operation/procedure

After execution of SIM25-2, this counter is cleared.

- 1. Press the [START] key.
- The confirmation menu is shown.
- 2. Select "1: YES."
- 1: YES (Cleared)
- 2: NO (Not cleared) (Default)

#### 24-6

Purpose	Data clear	
Function (Purpose)	Used to clear the copy counter.	
Item	Counter Copier	

#### **Operation/procedure**

- 1. Press the [START] key. The confirmation menu is shown.
- 2. Select "1: YES."
- 1: YES (Cleared)
  - 2: NO (Not cleared) (Default)

#### 24-7

Purpose	Data clear
Function (Purpose)	Used to clear the OPC drum (membrane decrease) correction counter. (This simulation is executed when the OPC drum is replaced.)
Section	Image process (Photoconductor/Developing/Transfer/Cleaning) Photo conductor
Item	Counter

#### **Operation/procedure**

- 1. Press the [START] key.
  - The confirmation menu is shown.
- 2. Select "1: YES."
- 1: YES (Cleared)
  - 2: NO (Not cleared) (Default)

#### 24-9

Purpose	Data clear	
Function (Purpose)	Used to clear the printer counter and other counters.	
Section	Printer	
Item	Counter	Printer

#### **Operation/procedure**

- 1. Select the counter to be cleared with the 10-key.
- 2. Press the [START] key. The confirmation menu is shown.
- 3. Select "1: YES."
- 1: YES (Cleared)

2: NO (Not cleared) (Default)

Item		Content
1	PRINTER	Printer counter
2	IMC	IMC counter
3	DUPLEX	DUPLEX counter
4	OTHERS	The other counters

Purpose	Data clear	
Function (Purpose)	FAX counter data clear	
Section	FAX	
Item	Counter	

#### Operation/procedure

- 1. Select a counter to be cleared with the 10 key.
- 2. Select "1: YES."
  - 1: YES (Cleared)

2: NO (Not cleared) (Default)

Item		Content	
, F	FAX SEND	FAX send page and time	
' (	PAGE & TIME)		
ہ F	AX RECEIVE	FAX receive page and time	
2 (	PAGE & TIME)		
3 F	AX OUTPUT	FAX output (number of prints)	

Note: Executable only when the FAX is installed.

24-15	
Purpose	Data clear
Function	Used to clear the scanner counter in the network
(Purpose)	scanner mode.
Section	Scanner section
Item	Counter

#### Operation/procedure

- 1. Press the [START] key.
- The confirmation menu is shown.
- 2. Select "1: YES."
  - 1: YES (Cleared)
  - 2: NO (Not cleared) (Default)

The scanner mode counter and the number of send of the scanner are cleared.

- \* The simulation to perform communication with the PCL is inhibited until Notice Page storing is completed. (Only when the serviceman call error occurs.)
- \* When in other than the serviceman call error, entering the simulation is not allowed from the system check display.

## 25

25-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the operation of the main drive (excluding the scanner section) and to check the operation of the toner concentration sensor. (The toner concentration sensor output can be monitored.)
Section	DRIVE
Item	Operation

#### **Operation/procedure**

1. Press the [START] key.

The main motor rotates to start monitoring the toner density control sensor. (3min operation)

\* Even in toner end error, if there is no other error (including cover open) after turning on the power, this simulation can be performed.

25-2	
Purpose	Setting
Function (Purpose)	Used to make the initial setting of toner concentration when replacing developer.
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)
	Developer/Toner hopper

#### **Operation/procedure**

After execution, the developer counter is cleared.

- 1) Open the cover with the power OFF.
- 2) Turn on the power. (Since the cover is open, the machine does not perform initializing.)
- 3) Execute the simulation.
- 4) Enter SIM 25-2. ([25]  $\rightarrow$  [START] key  $\rightarrow$  [2]  $\rightarrow$  [START] key)
- 5) Close the cover just before starting the simulation.
- 6) Press the [START] key.

The main motor rotates. After stirring for 3 min, the toner density control sensor value is sampled 16 times, and the average value is stored.

When "EE-EU" or "EE-EL" after completion, an error display is shown.

Note: After completion of execution, be sure to press the [CA] key to cancel the simulation.

2	

26-1		
Purpose	Setting	
Function (Purpose) Used to set whether the job not. (Since this cannot be o detection, it is set in this sin		e separator is installed or letected by hardware nulation.)
ltem	Specifications	Option

#### **Operation/procedure**

1. Select the set value with the 10-key.

2. Press the [START] key.

Set value Connection option		
0	None (default)	
1	Job separator provided.	

#### 26-2

Purpose	Setting
Function	Used to set whether the automatic detection of paper
(Purpose)	size is made or not.
Section	Paper feed
Item	Specifications

#### **Operation/procedure**

- 1. Select the item with the 10-key and press the [START] key. Used to set the automatic size detection.
- 2. Set whether automatic detection of paper size is made or not with the 10-key.

	Setting to detect B4/Legal as FC
1:B4/LG,FC	0: B4 legal is detected as B4 legal. (Default)
	1: B4 legal is detected as FC.
	This setup detects Letter as A4 in the inch series and
0.44	A4 as Letter in the AB series.
2:A4<->L1	0: Detection disable (Default)
	1: Detection valid

#### 8.5" x 13" detection valid/invalid setup

Set value	Setup	Remarks
0	Detection invalid	Default
1	Detection valid	

#### Detection size when 8.5" x 13" document/paper is used.

	<b>E</b> rectories of	England Dealing		Set value	
	Employed	Destina	Document	0	1
	unit	uon	size	(Invalid)	(Valid)
			FC	B4	FC
			(8.5" x 13")	04	(8.5" x 13")
		AB	LG	B4	FC
		series	(8.5" x 14")	54	(8.5" x 13")
	Document		B4	B4	FC
Docu	table/		5.		(8.5" x 13")
ment	RSPE		FC	LG	FC
	11011		(8.5" x 13")	(8.5" x 14")	(8.5" x 13")
		Inch	LG	LG	FC
		series	(8.5" x 14")	(8.5" x 14")	(8.5" x 13")
			B4	WLT	WLT
				(11" x 17")	(11" x 17")
	Machine	All		Set with system setting.	
	paper feed	destina	-		
	tray	tions			
		AB	FC	LG	FC
			(8.5" x 13")	(8.5" x 14")	(8.5" x 13")
		series	LG	LG	FC
Paper	Manual	001100	(8.5" x 14")	(8.5" x 14")	(8.5" x 13")
	naner feed		B4	B4	B4
	trav		FC	LG	FC
	licy	Inch	(8.5" x 13")	(8.5" x 14")	(8.5" x 13")
		series	LG	LG	FC
		001100	(8.5" x 14")	(8.5" x 14")	(8.5" x 13")
			B4	B4	B4

A4/LT (8.5" x 11") detection enable/disable setup

In the inch series, Letter is detected as A4; in the AB series, A4 is detected as Letter.

Set value	Setup	Remarks
0	Detection invalid	Default
1	Detection valid	

Detection size when A4/LT (8.5" x 11") document/paper is used.

	Employed	Dectino	Destina Document	Setv	/alue
	Employed	Destina		0	1
	unit	uon	size	(Invalid)	(Valid)
				A4	LT
		AB	A4	A4	(8.5" x 11")
	Document	series	LT	A.4	LT
Docu	table/		(8.5" x 11")	A4	(8.5" x 11")
ment	RSPF	Inch series	A4	LT	۵4
				(8.5" x 11")	74
			LT	LT	۵4
			(8.5" x 11")	(8.5" x 11")	74
	Machine	All			
	paper feed	paper feed destina		Set with system setting.	
Paper	tray	tions			
	Manual	All		Begardle	use of the
	paper feed	destina	-	simulatio	
	tray tions			Simulation Setup.	

26-3	
Purpose	Setting
Function (Purpose)	Used to set the specifications of the auditor. Setting must be made depending on the use condition of the auditor.
Section	Auditor
Item	Specifications

#### **Operation/procedure**

Select the mode corresponding to the auditor specification mode with the 10-key.

	Item	Content	Setting range	Default
0	P10	Built-in auditor mode		
1	VENDOR	Coin vendor mode	0-2	0
2	OTHER	Others		

When "1: VENDOR (Coin vendor mode)" is set, the following three items of system setting are changed.

- 1) Set the LCD backlight change inhibit to "1: OFF (Enable)."
- When SIM 26-6 destination setting is set to "0: Japan," duplex copy inhibit setting must be set to "0: ON (Inhibit)."
- 3) Set the sort automatic selection to "0: OFF (Disable)."

26-5		
Purpose	Setting	
Function	Used to set the count mode	of the total counter and the
(Purpose)	maintenance counter.	
Item	Specifications	Counter

#### **Operation/procedure**

Used to set the count up number (1 or 2) when an A3/WLT paper passes through.

For the drum counter and the developer counter, double count is employed unconditionally.

(Target counter selection)

Item		Content
1	TOTAL COUNTER	Total counter
2	MAINTENANCE COUNTER	Maintenance counter

Used to set the count up number of the selected counter.

Item		Content	Setting range	Default
1	SINGLE COUNT	Single count	1.0	0
2	DOUBLE COUNT	Double count	1-2	2

#### 26-6

Purpose	Setting	
Function	Used to set the specifications depending on the	
(Purpose)	destination.	
Item	Specifications	Destination

#### Operation/procedure

Select the destination with the 10-key.

By changing the destination, some other setting items may be changed.

	Item	Content	Setting range	Default
0	JAPAN	Japan		
1	SEC	SEC		
2	SECL	SECL		
3	SEEG	SEEG		
4	SUK	SUK		
5	SCA	SCA		
6	SEF	SEF		
7	INEG	EX inch series	0-14	0
8	ABEG	EX AB series		
9	INEF	EX inch series (FC)		
10	ABEF	EX AB series (FC)		
11	CHINESE	China		
12	TAIWAN	Taiwan AB		
13	SEEG2	SEEG2		
14	TAIWAN2	Taiwan China		

20-12		
Purpose	Setting	
Function (Purpose)	Used to input the Software Key for E-MAIL RIC.	
Section	E-MAIL RIC	
Item	Specifications	

#### **Operation/procedure**

The current setup is displayed with ON or OFF.

Enter an input (20 digits) of the E-MAIL RIC soft key with the 10-key and press the [START] key, and the collating result is displayed with OK or NG.

After canceling the simulation, if OK, the E-MAIL RIC function is enable; if NG, the E-MAIL RIC function is disabled.

This setting must be reset after the simulation cancel.

#### 26-14

Purpose	Setting
Function (Purpose)	Used to input the Software Key for the PS extention kit.
Section	Printer
Item	Specifications

#### **Operation/procedure**

The current setup is displayed with ON or OFF.

Enter an input (20 digits) of the PS expansion kit soft key with the 10key and press the [START] key, and the collating result is displayed with OK or NG.

After canceling the simulation, if OK, the PS expansion kit function is enable; if NG, the PS expansion kit function is disabled.

This setting must be reset after the simulation cancel.

Note: Executable only when the PCL/PS3 is installed.

#### 26-18

Purpose	Setting	
Function (Purpose)	Used to set enable/disable of toner save operation.	
Item	Specifications Operation mode (Common)	

#### **Operation/procedure**

Input the set value with the 10-key and press the [START] key.

	Item	Content	Setting range	Default
0	OFF	Disable	0.1	- 1
1	ON	Enable	0-1	I

26-22	
Purpose	Setting
Function	Used to set the specification (language display) for the
(Purpose)	destination.
Item	Specifications

#### **Operation/procedure**

Select the display language with the 10-key, and press the  $\left[\text{START}\right]$  key.

This setup varies in connection with SIM 26-6 (Destination setup).

	Item	Remarks
0	JAPANESE	
1	ENG.US	
2	ENG.UK	
3	FRENCH	
4	GERMAN	
5	ITALY	
6	DUTCH	
7	SWEDISH	
8	SPANISH	

Item		Remarks
9	PORTUGUESE	
10	TURKISH	
11	GREEK	
12	POLISH	
13	HUNGARIAN	
14	CZECH	
15	RUSSIAN	
16	FINNISH	
17	NORWEGIAN	
18	DANISH	
19	CHINESE	
20	TAIWANESE	Traditional Chinese supported locally
21	SLOVAK	
22	HEBREW	Supported locally
22	BRAZILIAN	
23	PORTUGUESE	
24	ARABIC	
25	FARSI	

#### 26-30

Purpose	Setting	
Function	Used to set ON/OFF of the heater lamp slow-up control	
(Purpose)	conforming to the CE mark control.	
Item	Specifications Operation mode (Common)	

#### **Operation/procedure**

Input the set value with the 10-key and press the [START] key. This setup varies in connection with SIM 26-6 (Destination setup).

Item		Default	
		U.S.A, Canada, Australia, France, Taiwan	Others
0	OFF	0	4
1	ON	U	I

26-35	
Purpose	Setup
Function (Purpose)	Used to set whether the same continuous troubles are displayed as one trouble or the series of troubles with SIM 22-4 when the same troubles occur continuously.
Item	Specifications

#### **Operation/procedure**

Enter the set value with 10-key, and press [START] key.

	Item Content		Default
0	ONCE	When two or more troubles occur, only one is registered.	0
1	ANY	All the troubles occurred are registered.	

26-36		
Purpose	Setting	
<b>Function</b> Used to set whether the machine is stopped or not		
(Purpose) when the maintenance counter life is expired.		
Item	Operation	

#### **Operation/procedure**

Input the set value with the 10-key and press the [START] key.

Item		Content	Default
0	STOP	Stop	1
1	NON STOP	Non stop	I

Purpose	Setting
Function (Purpose)	Used to set whether the machine is stopped or not when the developer counter life is expired.
Item	Operation

#### Operation/procedure

Input the set value with the 10-key and press the [START] key.

Item		Item Content	
0	STOP	Stop	4
1	NON STOP	Non stop	I

#### 26-38

Purpose	Setting
Function (Purpose)	Used to set whether the machine is stopped or not when the drum counter life is expired.
Item	Operation

#### **Operation/procedure**

Input the set value with the 10-key and press the [START] key.

Item		Item Content		1
0 STOP Stop		4	1	
1	NON STOP	Non stop	I	1

#### 26-50

Purpose	Setting
Function	Used to set ON/OFF of the black and white reversion
(Purpose)	function.
Item	Operation

#### **Operation/procedure**

Enter the set value with the 10-key, and press the [START] key.

Item		Content	Default
0	ON	Enable	1 (U.K.)
1	OFF	Disable	0 (Others)

#### 26-56

Purpose	Setting
Function (Purpose)	Gamma life correction setting
Item	Operation

#### **Operation/procedure**

Sets enable/disable of the gamma life correction function.

	Item	Set value	Default
1	AE (Japan)		0
2 AE (Ex Japan) 0		0	
3 Text		1	
4 Text/Photo			1
5	5 Photo (Error diffusion)		1
6 Photo (Dither)		1: Enable	1
7 T/S AE (Japan)		0	
8 T/S AE (Ex Japan)		0	
9	9 T/S Text		1
10	T/S Text/Photo		1

#### 26-57

Purpose	Setting
Function (Purpose)	Used to set the model code.
Item	Operation

#### **Operation/procedure**

Input the set value with the 10-key and press the [START] key.

	Item
1	AR-5726
2	AR-5731

26-60		
Purpose	Setting	
Function (Purpose)	Used to set enable/disable of the FAX mode key when FAX is not installed. (When FAX is installed, the FAX mode is enabled regardless of this setup.)	
Item	Operation	

#### **Operation/procedure**

Input the set value with the 10-key and press the [START] key.

Item			Default	
		Content	U.S.A, Canada,	Othors
			U.K., Australia	Others
~		Effective (The message with		
0	ON	FAX uninstalled is displayed.)	0	1
1	OFF	Disable (Error Beep)		

This setup varies in connection with SIM 26-6 (Destination setup).

Purpose	Setting
Function (Purpose)	In the power save time setting, the pre-heat (pre-heat mode setting) and the auto power shut off time can be set to the short time setup (pre-heat: 1 min, auto power shut off: 1 min) and the long time setup (pre-heat: 5min, auto power shut off: 30min).

Select the short time setup or the long time setup of the pre-heat time and the auto power shut off time with the 10-key, and press the [START] key.

Item	Content	Default
1	Preheat: 1min, auto power shut off: 1min	-
2	Preheat: 5min, auto power shut off: 30min	1

Note: When the sub code 71 is entered to display the setting menu,the default values are always displayed. (However,the default time is not always set.)

26-72		
Purpose	Setting	
	The letterhead support is set.	
Function	When "Letterhead paper setting" is selected, the set	
(Purpose)	value of SIM 26-46 (Image output direction setting) is	
	set to "Setting Enable" accordingly.	

#### **Operation/procedure**

Input the set value with the 10-key and press the [START] key.

	Item	Content	Setting range	Default
0	OFF	Letterhead paper is not set.	0.1	0
1	ON	Letterhead paper is set.	0-1	0

## 30

30-1	
Purpose	Operation test/check
Function	Used to display the sensor status attached to the
(Purpose)	machine.
Section	Others
Item	Operation

#### **Operation/procedure**

The active sensors and detectors are highlighted.

PPD1H	PS paper detection 1 sensor
PPD1L	PS paper detection 2 sensor
PPD2	Fusing paper sensor
POD1	1st paper exit paper out sensor
DVCH	Developing cartridge detection sensor
DRST	Drum intial detection sensor
DSWR1	Interlock switch (side door)
SFTHP	Shifter home position sensor
POD2	2nd paper exit paper out sensor
TOPF	2nd paper exit full detection sensor
DSWR0	2nd paper exit cover open/close detection sensor
LOEMP	1st paper exit empty detection sensor
DUP2	Reverse path paper sensor
POD3	Right paper exit sensor
PTOPF	Right paper exit full sensor

30-2		
Purpose	Operation test/check	
	Used to display the status of the sensors attached to	
Function	the standard tray and the manual feed tray. (Use SIM	
(Purpose)	4-2 for the option trays.)	
	The sensor of an uninstalled tray is not displayed.	
Section	Paper feed	
Item	Operation	

#### **Operation/procedure**

The active sensors and detectors are highlighted.

PED11st tray paper empty sensorLUD11st tray paper upper limit detection sensorCD11st tray empty sensorPED22nd tray paper empty sensorLUD22nd tray paper upper limit detection sensorCD22nd tray paper upper limit detection sensorCD22nd tray paper upper limit detection sensorDSWR22nd tray paper pass sensorDSWR22nd tray right door detection sensorMPEDManual tray paper empty detectionMPLS1Manual tray length detection 1MPLS2Manual tray length detection 2MPLD1Manual feed paper length detection 1MPLD2Manual feed paper length detection 1		
LUD11st tray paper upper limit detection sensorCD11st tray empty sensorPED22nd tray paper empty sensorLUD22nd tray paper upper limit detection sensorCD22nd tray paper upper limit detection sensorCD22nd tray paper pass sensorDSWR22nd tray right door detection sensorMPEDManual tray paper empty detectionMPLS1Manual tray length detection 1MPLS2Manual tray length detection 2MPLD1Manual feed paper length detection 1MPLD2Manual feed paper length detection 2	PED1	1st tray paper empty sensor
CD11st tray empty sensorPED22nd tray paper empty sensorLUD22nd tray paper upper limit detection sensorCD22nd tray empty sensorPFD22nd tray paper pass sensorDSWR22nd tray right door detection sensorMPEDManual tray paper empty detectionMPLS1Manual tray length detection 1MPLS2Manual tray length detection 2MPLD1Manual feed paper length detection 1MPLD2Manual feed paper length detection 2	LUD1	1st tray paper upper limit detection sensor
PED2       2nd tray paper empty sensor         LUD2       2nd tray paper upper limit detection sensor         CD2       2nd tray empty sensor         PFD2       2nd tray paper pass sensor         DSWR2       2nd tray right door detection sensor         MPED       Manual tray paper empty detection         MPLS1       Manual tray length detection 1         MPLS2       Manual tray length detection 2         MPLD1       Manual feed paper length detection 1         MPLD2       Manual feed paper length detection 2	CD1	1st tray empty sensor
LUD2       2nd tray paper upper limit detection sensor         CD2       2nd tray empty sensor         PFD2       2nd tray paper pass sensor         DSWR2       2nd tray right door detection sensor         MPED       Manual tray paper empty detection         MPLS1       Manual tray length detection 1         MPLS2       Manual tray length detection 2         MPLD1       Manual feed paper length detection 1         MPLD2       Manual feed paper length detection 2	PED2	2nd tray paper empty sensor
CD2       2nd tray empty sensor         PFD2       2nd tray paper pass sensor         DSWR2       2nd tray right door detection sensor         MPED       Manual tray paper empty detection         MPLS1       Manual tray length detection 1         MPLS2       Manual tray length detection 2         MPLD1       Manual feed paper length detection 1         MPLD2       Manual feed paper length detection 2	LUD2	2nd tray paper upper limit detection sensor
PFD2       2nd tray paper pass sensor         DSWR2       2nd tray right door detection sensor         MPED       Manual tray paper empty detection         MPLS1       Manual tray length detection 1         MPLS2       Manual tray length detection 2         MPLD1       Manual feed paper length detection 1         MPLD2       Manual feed paper length detection 2	CD2	2nd tray empty sensor
DSWR2       2nd tray right door detection sensor         MPED       Manual tray paper empty detection         MPLS1       Manual tray length detection 1         MPLS2       Manual tray length detection 2         MPLD1       Manual feed paper length detection 1         MPLD2       Manual feed paper length detection 2	PFD2	2nd tray paper pass sensor
MPED       Manual tray paper empty detection         MPLS1       Manual tray length detection 1         MPLS2       Manual tray length detection 2         MPLD1       Manual feed paper length detection 1         MPLD2       Manual feed paper length detection 2	DSWR2	2nd tray right door detection sensor
MPLS1       Manual tray length detection 1         MPLS2       Manual tray length detection 2         MPLD1       Manual feed paper length detection 1         MPL D2       Manual feed paper length detection 2	MPED	Manual tray paper empty detection
MPLS2     Manual tray length detection 2       MPLD1     Manual feed paper length detection 1       MPLD2     Manual feed paper length detection 2	MPLS1	Manual tray length detection 1
MPLD1 Manual feed paper length detection 1 MPLD2 Manual feed paper length detection 2	MPLS2	Manual tray length detection 2
MPLD2 Manual feed paper length detection 2	MPLD1	Manual feed paper length detection 1
in 222 manda lood paper lengar detection 2	MPLD2	Manual feed paper length detection 2

Width detection size of the manual feed tray (one of them is displayed.) A4/A3, LT/WLT, B5/B4, INV/LTR, A5/A4R, B5R, POSTCARD, EXTRA, 8K/16K

(At detection, highlighted)

40-1	
Purpose	Operation test/check
Function	Used to check the sensor of the machine manual feed
(Purpose)	tray.
Section	Paper feed
Item	Operation

#### **Operation/procedure**

The active sensors and detectors are highlighted.

MPLS1	Manual tray length detection 1
MPLS2	Manual tray length detection 2
MPLD1	Manual feed paper length detection 1
MPLD2	Manual feed paper length detection 2

Width detection size of the manual feed tray (one of them is displayed.) A4/A3, LT/WLT, B5/B4, INV/LTR, A5/A4R, B5R, POSTCARD, EXTRA, 8K/16K

40-2	
Purpose	Adjustment
Function	Used to adjust the manual paper feed tray paper width
(Purpose)	detector detection level.
Section	Paper feed
Item	Operation

#### **Operation/procedure**

The adjustment method is of the 4-point system. Set the guide to Max. (A3/WLetter) position, A4R/Letter R position, A5R/Invoice R position, and Min. position for adjustment.

- 1) Set A3/W Letter and fit the guide, then press the [START] key.
- 2) Set A4R/LetterR and fit the guide, then press the [START] key.
- 3) Set to A5R/INVOICE R and fit the guide, then press the [START] key.
- 4) Narrow the guide at minimum, press the [START] key.
- 5) Set the paper detection width (+), and press the [START] key.

6) Set the paper detection width (-), and press the [START] key. If "FAILED" is displayed in procedure 1), 2), 3), or 4), it is NG of adjustment. Repeat the adjustment.

Middle position adjustment I	Yes	MID-L ADJ.ON
Middle position adjustment E	No	MID-L ADJ.OFF
Middle position adjustment S	Yes	NID-S ADJ.ON
windle position adjustment S	No	MID-S ADJ.OFF

|--|

40.0	
Purpose	Adjustment
Function	The AD conversion value of manual feed width
Section	Paper feed
Item	Operation

#### **Operation/procedure**

The AD conversion value of manual feed width detection is displayed.



41-1	
Purpose	Operation test/check
Function	Used to check the document size detection photo
(Purpose)	sensor.
Section	Others
Item	Operation

#### **Operation/procedure**

The operation status of the sensors and detectors in the original size detection section are displayed. The active sensors and detectors are highlighted.

ocsw	Original cover state Open: Highlighted display Close: Normal display
PD1 to 5	Original sensor status Without original: Normal display With original: Highlighted display

For AB series, PD1 to 5 is displayed, for inch series, PD1 to 4.

#### 41-2

Purpose	Adjustment
Function	Used to adjust the detection level of the document size
(Purpose)	photo sensor.
Section	Others
Item	Operation

#### **Operation/procedure**

Place an A3 (or WLT) document on the document table, and press [START] key with the OC cover open.

The adjustment is performed and the result is displayed.

OCSW	Original cover state Open: Highlighted display
	Close. Normal display
1 to 5	PD sensor detection level (Hexadecimal display)

The value in [] shows the threshold value. (Hexadecimal display) For AB series, 1 to 5 is displayed, for inch series, 1 to 4.

During execution of the simulation, "EXECUTING" is displayed.

41-3	
Purpose	Operation test/check
Function (Purpose)	Used to check the light reception level and the detection level of the original size detection photo sensor.
Section	Others
Item	Operation

#### Operation/procedure

The detection output level of each sensor is displayed in real time.

ocsw	Original cover state
	Close: Normal display
1 to 5	PD sensor detection level (Hexadecimal display)

The value in [] shows the threshold value of 20 degree detection adjustment. (Hexadecimal display)

For AB series, 1 to 5 is displayed, for inch series, 1 to 4.

41-4	
Purpose	Adjustment
Function (Purpose)	Used to adjust the detection level of OC 20 degrees.
Section	Others
Item	Operation

#### **Operation/procedure**

Set the OC cover at 20 degrees detection and press the [START] key. The detection output level of each sensor is displayed in real time.

	Original cover state
OCSW	Open: Highlighted display
	Close: Normal display
1 to 5	PD sensor detection level (Hexadecimal display)

The value in [] shows the threshold value of 20 degree detection adjustment. (Hexadecimal display)

For AB series, 1 to 5 is displayed, for inch series, 1 to 4.

During execution, [EXECUTING] is highlighted.

|--|

43-1	
Purpose	Setting
Function (Purpose)	Used to set the fusing temperature.
Section	Fixing (Fusing)
Item	Operation

#### **Operation/procedure**

1. Touch the item to be set.

2. Enter the set value with the 10-key.

ltom		Contont	Setting	Default	
	nem	Content	range	(Others)	(Europe)
1	Ready Temp Main (145)	Ready temperature Main (145mm/s)	150 - 220	185	190
2	Ready Temp Sub (145)	Ready temperature Sub (145mm/s)	150 - 220	180	185
3	Ready Temp Main (122)	Ready temperature Main (122mm/s)	150 - 220	175	180
4	Ready Temp Sub (122)	Ready temperature Sub (122mm/s)	150 - 220	170	175

ltem		Contont	Setting	Default	
		Content	range	(Others)	(Europe)
	WarmUp	Warmup target	150		
5	Target Main	temperature Main 220 180		190	
	(145)	(145mm/s)	220		
	WarmUp	Warmup target	150 -		
6	Target Sub	temperature Sub	220	180	190
	(145)	(145mm/s)			
_	WarmUp	Warmup target	150 -		
7	Target Main	temperature Main	220	175	
	(122)	(122mm/s)			
•	WarmUp	Warmup target	150 -	170	
0	(122)	(122mm/s)	220		
	(122) Warml In	(122mm/s) Warmun			
	Temp Main	complete			
9	(145)	temperature Main	0 - 40	1	0
	(110)	(145 mm/s)			
	WarmUp	Warmup			
10	Temp Sub	complete	0 40		-
10	(145)	temperature Sub	0 - 40	1	5
	. ,	(145mm/s)			
	WarmUp	Warmup			
11	Temp Main	complete	0 - 40	10	
	(122)	temperature Main	0 - 40		
		(122mm/s)			
	WarmUp	Warmup			
12	Temp Sub	complete	0 - 40	15	
	(122)	(122mm/o)			
	COOdai	(12211111/S)	150		
13	6000pi Main (145)	(145  mm/s)	150 -	190	195
-	600dpi Sub	600dpi Sub	150 -		
14	(145)	(145mm/s)	220	190	195
	POST	Postcard Main	. = -		
15	CARD	(145mm/s)	150 -	200	
	Main (145)	,	220		
	POST	Postcard Sub	150		
16	CARD Sub	(145mm/s)	220	200	
	(145)		220		
	CARDBOA	Thick paper Main	150 -		
17	RD Main	(145mm/s)	220	20	00
	(145)	<b>T</b> I : 1 0 1			
10		Thick paper Sub	150 -	0	20
10	(145)	(145mm/s)	220	200	
	(140) 600dpi	600dni Main	150 -		
19	Main (122)	(122 mm/s)	220	175	185
	600dpi Sub	600dpi Sub	150 -		
20	(122)	(122 mm/s)	220	175	185
	CARDBOA	Postcard Main			
21	RD Main	(122mm/s)	150 -	19	90
	(122)	· · · ·	220		
	POST	Postcard Sub	150		
22	CARD Sub	(122mm/s)	150 -	190	
L	(122)		220		
	POST	Thick paper Main	150 -		
23	CARD	(122mm/s)	220	19	90
	(122mm/s)				
	CARDBOA	Thick paper Sub	150 -		
24	RD Sub	(122mm/s)	220	19	90
	(122)				

43-10		
Purpose	Setting	
Function	Used to set the paper feed cycle timing when printing	
(Purpose)	postcards.	
Section	Paper feed	
Item	Operation	
On evention (averageduve		

Input the set value with the 10-key and press the [START] key.

Setting range	1-99
Default	50

## 44

44-1		
Purpose	Setting	
Function	Used to make various setups in each mode of process	
(Purpose)	control.	
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)	
Item	Operation	
Operation/procedure		
Enter the set value with the 10-key and press the [START] key		

Enter the set value with the 10-key, and press the [START] key.

Item		Content	Default
4	ENVIRONMENT	Environmental correction Allow/	1
1	ADJ.	Inhibit (0: Inhibit, 1: Allow)	1
2		Duplex print correction Allow/	0
2	DUPLEX PRINT ADJ.	Inhibit (0: Inhibit, 1: Allow)	0
		Transfer current enviroment	
3		correction Allow/Innibit	0
	(10)	(0: Inhibit, 1: Allow)	

44-2		
Purpose	Setting	
Function (Purpose)	Drum life correction setting	
Section	Image process (Photoconductor)	
Item	Operation	

#### **Operation/procedure**

- 1. Select an item with 10-key, and press [START] key.
- 2. Enter the setting value, and press [START] key.

Item		Content	Default
1	GRIDBIAS ADJUST	Drum life correction Disable/ Enable (0: Disable, 1: Enable)	1

44-3	
Purpose	Setting
Function (Purpose)	Used to set the DV count correction.
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)
Item	Operation

- 1. Select an item with 10-key, and press [START] key.
- 2. Enter the setting value, and press [START] key.

Item		Content	Default	
1	PR_LIFE_ADJUST	DV count correction Disable/ Enable (0: Disable, 1: Enable)	1	
2	TN_LIFE_ADJUST	Life of toner control DV correction Disable/Enable (0: Disable, 1: Enable)	1	
3	RATE_ADJUST	Printing rate correction Disable/Enable (0: Disable, 1: Enable)	1	
4	TONER_ADJUST	Toner unconditionally supply correction Disable/Enable (0: Disable, 1: Enable)	1	

#### 44-9

Purpose	Adjustment/Setup/Operation data output/Check (Display/Print)
Function (Purpose)	Used to display the process control correction information.
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)
Item	Operation

#### **Operation/procedure**

Used to display the process control correction information.

44-14		
Purpose	Adjustment/Setup/Operation data output/Check (Display/Print)	
Function (Purpose)	Used to display the environment (temperature, humidity) correction information.	
Item	Operation	

#### **Operation/procedure**

The following data are displayed.

TH AREA	Current environment area
TMP DATA	Detection temperature of sensor (C°)
HUD DATA	Detection humidity of sensor (%)

\* The value before entry of SIM is displayed. (It is not revised in real time.)

If sim entry is just after power turned on, the display value is all 0.

44-16				
Purpose	Setting			
Function (Purpose)	Used to set the toner density control correction value.			
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)			
Item	Operation			

#### **Operation/procedure**

Sets the toner density control correction value of the traveling distance count.

	Item			Default
1	0 - 93000	(31-sheet model)	1-99	45
2	93001 - 186000	(31-sheet model)	1-99	45
3	186001 - 279000	(31-sheet model)	1-99	45
4	279001 - 372000	(31-sheet model)	1-99	45
5	372001 - 465000	(31-sheet model)	1-99	45

	Item		Setting	Default
			range	
6	465001 - 857313	(31-sheet model)	1-99	45
7	857314 - 1714625	(31-sheet model)	1-99	45
8	1714626 - 2571938	(31-sheet model)	1-99	45
9	2571939 - 3429250	(31-sheet model)	1-99	45
10	3429251 - 4286563	(31-sheet model)	1-99	45
11	4286564 - 5143875	(31-sheet model)	1-99	45
12	5143876 - 6001188	(31-sheet model)	1-99	45
13	6001189 - 6858500	(31-sheet model)	1-99	45
14	6858501 - 7715813	(31-sheet model)	1-99	45
15	7715814 - 8573125	(31-sheet model)	1-99	45
16	8573126 - 9430438	(31-sheet model)	1-99	45
17	9430439 - 10287750	(31-sheet model)	1-99	45
18	10287751 - 11145063	(31-sheet model)	1-99	45
19	11145064 - 12002375	(31-sheet model)	1-99	45
20	12002376 -	(31-sheet model)	1-99	45
21	0 - 93000	(26-sheet model)	1-99	45
22	93001 - 186000	(26-sheet model)	1-99	45
23	186001 - 279000	(26-sheet model)	1-99	45
24	279001 - 372000	(26-sheet model)	1-99	45
25	372001 - 465000	(26-sheet model)	1-99	45
26	465001 - 857313	(26-sheet model)	1-99	45
27	857314 - 1714625	(26-sheet model)	1-99	45
28	1714626 - 2571938	(26-sheet model)	1-99	45
29	2571939 - 3429250	(26-sheet model)	1-99	45
30	3429251 - 4286563	(26-sheet model)	1-99	45
31	4286564 - 5143875	(26-sheet model)	1-99	45
32	5143876 - 6001188	(26-sheet model)	1-99	45
33	6001189 - 6858500	(26-sheet model)	1-99	45
34	6858501 - 7715813	(26-sheet model)	1-99	45
35	7715814 - 8573125	(26-sheet model)	1-99	45
36	8573126 - 9430438	(26-sheet model)	1-99	45
37	9430439 - 10287750	(26-sheet model)	1-99	45
38	10287751 - 11145063	(26-sheet model)	1-99	45
39	11145064 - 12002375	(26-sheet model)	1-99	45
40	12002376 -	(26-sheet model)	1-99	45

#### 44-17

Purpose Adjustment/Setup/Operation data output/Check (Display/Print)	
Function	Used to display the toner density control reference
(Purpose) value.	
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)
Item	Operation

#### **Operation/procedure**

The following data are displayed. (The displayed value is the previous print correction value.)

TARGET	Toner concentration control reference value
DEV REF	Developer adjustment value
LIFE	Toner container life correction value (SIM 44-16)
TH	Toner container environment correction value

TARGET = DEV REF+(LIFE-50)+(TH-50)

Developer adjustment value 128, life correction 60 (developer adjustment value plus 10), environment correction 45 (5 subtraction correction), rapid toner supply correction = 128+(60-50)+(45-50) = 133.)

## Purpose Setting Function

(Purpose) Used to set the transfer current value in each mode.

#### **Operation/procedure**

1. Touch the item to be set.

2. Enter the set value with the 10-key.

To support an individual necessity in paper and the environment, it is variable in the range of 5 to 30uA in the increment of 1uA in each mode. When changing +V2, check with +V1 unchanged. If there is any trouble in the half tone image of graphics, keep the relationship between +V1 and +V2 at the default and change it.

When the image quality is deteriorated because the user selects the OHP mode and use other than the recommended OHP, decrease the transfer current to adjust deterioration of black background picture quality. If some of characters are not printed, increase the transfer current.

This setting is changed in linkage with SIM 26-6 destination setting.

\*1: SECL/SCA/SEF/EX inch series/EX AB series/EX inch series (FC)/ EX AB series (FC)/China/Taiwan/SEEG2

\*2: SEC/SEEG/SUK

Item		Content	Setting	Def	ault
item		Content	range	*1	*2
1	+V1F (145)	145mm/s normal paper W +V1 single surface. Duplex (Front)	5-30 5		5
2	+V1R (145)	145mm/s normal paper W +V1 Duplex (Back)	5-30	5-30 5	
3	+V2F (145)	145mm/s normal paper W +V2 single surface. Duplex (Front)	nn/s normal paper W single surface. Duplex 5-30 18 nt)		20
4	+V2R (145)	145mm/s normal paper W +V2 Duplex (Back)	5-30	14	18
5	+V1S-F (145)	145mm/s normal paper N1 +V1 single surface. Duplex (Front)	5-30	Ę	5
6	+V1S-R (145)	145mm/s normal paper N1 +V1 Duplex (Back)	5-30	5	5
7	+V2S-F (145)	145mm/s normal paper N1 +V2 single surface. Duplex (Front)	5-30	-30 18	
8	+V2S-R (145)	145mm/s normal paper N1 +V2 Duplex (Back)	5-30	0 18	
9	+V1SS-F (145)	145mm/s normal paper N2 +V1 single surface. Duplex (Front)	5-30	5	
10	+V1SS-R (145)	145mm/s normal paper N2 +V1 Duplex (Back)	5-30	5	
11	+V1SS-F (145)	145mm/s normal paper N2 +V2 single surface. Duplex (Front)	5-30	) 18	
12	+V1SS-R (145)	145mm/s normal paper N2 +V2 Duplex (Back)	5-30	1	8
13	+V1 THICK (145)	145mm/s thick paper > LTR +V1	5-30	5	5
14	+V2 THICK (145)	145mm/s thick paper > LTR +V2	5-30	1	4
15	+V1 THICK S (145)	145mm/s thick paper ≦ LTR +V1	5-30	5	
16	+V2 THICK S (145)	145mm/s thick paper ≦ LTR +V2	5-30	0 14	
17	+V1 THIN (145)	145mm/s thin paper > LTR +V1	5-30	·30 5	
18	+V2 THIN (145)	145mm/s thin paper > LTR +V2	5-30 18		8
19	+V1 THIN S (145)	145mm/s thin paper ≦ LTR +V1	5-30 5		5
20	+V2 THIN S (145)	$\frac{145 \text{mm/s thin paper} \leq \text{LTR}}{+\text{V2}}$ 5-30		1	8

	Item	Content	Setting	Der *1	ault *2
21	+V1 LABEL (145)	145mm/s label paper > LTR	5-30 5		2
22	+V2 LABEL (145)	145mm/s label paper > LTR	5-30	1	8
23	+V1 LABEL S	145mm/s label paper $\leq$ LTR	5-30	5	5
24	+V2 LABEL S (145)	145mm/s label paper $\leq$ LTR	5-30	1	4
25	145) ±V1 OHP (145)	$145$ mm/s OHP $> 1$ TB $\pm 1/1$	5-30	F	
26	+V1 OHP (145)	145 mm/s OHP > 1TB + V2	5-30	1	ς Δ
27	±V1 OHP S (145)	$145$ mm/s OHP $\leq$ 1TB $\pm$ V1	5-30	F	-
20		$145 \text{mm/s} \text{OHP} \le 1\text{TP} \pm 1/2$	5 20	1	0
20 29	+V1 POSTCARD	145mm/s postcard/envelope	5-30	5	0
30	(145) +V2 POSTCARD	> 100mm +V1 145mm/s postcard/envelope	5-30	2	6
21	(145) +V1 POSTCARD	> 100mm +V2 145mm/s postcard/envelope	5 20	-	-
31	S (145)	≦ 100mm +V1	5-30	Ę	)
32	+V2 POSTCARD S (145)	145mm/s postcard/envelope ≦ 100mm +V2	5-30	2	6
33	+V1F (122)	122mm/s normal paper W +V1 single surface. Duplex (Front)	5-30	Ę	5
34	+V1R (122)	122mm/s normal paper W +V1 Duplex (Back)	5-30	5	5
35	+V2F (122)	122mm/s normal paper W +V2 single surface. Duplex (Front)	5-30	12	14
36	+V2R (122)	122mm/s normal paper W +V2 Duplex (Back)	5-30	5-30 12	
37	+V1S-F (122)	122mm/s normal paper N1 +V1 single surface. Duplex	5-30	5-30 5	
38	+V1S-R (122)	122mm/s normal paper N1 +V1 Duplex (Back)	5-30	30 5	
39	+V2S-F (122)	122mm/s normal paper N1 +V2 single surface. Duplex (Front)	5-30	30 14	
40	+V2S-R (122)	122mm/s normal paper N1 +V2 Duplex (Back)	5-30	30 14	
41	+V1SS-F (122)	122mm/s normal paper N2 +V2 Duplex (Back)	5-30	5	5
42	+V1SS-R (122)	122mm/s normal paper N2 +V1 single surface. Duplex (Front)	5-30	Ę	5
43	+V2SS-F (122)	122mm/s normal paper N2 +V1 Duplex (Back)	5-30	1	4
44	+V2SS-R (122)	122mm/s normal paper N2 +V2 single surface. Duplex (Front)	5-30	1	4
45	+V1 THICK (122)	122mm/s thick paper > LTR +V1	5-30	Ę	5
46	+V2 THICK (122)	122mm/s thick paper > LTR +V2	5-30	1	0
47	+V1 THICK S (122)	122mm/s thick paper $\leq$ LTR +V1	5-30	5	
48	+V2 THICK S (122)	122mm/s thick paper $\leq$ LTR +V2	5-30	12	
49	+V1 THIN (122)	122mm/s thin paper > LTR +V1	5-30	5	
50	+V2 THIN (122)	122mm/s thin paper > LTR +V2	5-30	1	2
51	+V1 THIN S (122)	122mm/s thin paper $\leq$ LTR +V1	5-30	Ę	5
52	+V2 THIN S (122)	122mm/s thin paper ≦ LTR +V2	5-30	0 12	
53	+V1 LABEL (122)	122mm/s label paper > LTR +V1	5-30	5	5
54	+V2 LABEL (122)	122mm/s label paper > LTR +V2	5-30	1	2

ltom		Contont	Setting	Default	
	nem	Content	range	*1 *2	
55	+V1 LABEL S	122mm/s label paper ≦ LTR	5 20	5	
55	(122)	+V1	5-30	5	
56	+V2 LABEL S	122mm/s label paper ≦ LTR	5 20	10	
50	(122)	+V2	5-30	12	
57	+V1 OHP (122)	122mm/s OHP > LTR +V1	5-30	5	
58	+V2 OHP (122)	122mm/s OHP > LTR +V2	5-30	8	
59	+V1 OHP S (122)	122mm/s OHP ≦ LTR +V1	5-30	) 5	
60	+V2 OHP S (122)	2) 122mm/s OHP ≦ LTR +V2		12	
61	+V1 POSTCARD	122mm/s postcard/envelope	5-30	5	
01	(122)	> 100mm +V1	5-30	5	
62	+V2 POSTCARD	122mm/s postcard/envelope	5-30	16	
02	(122)	> 100mm +V2	5-50	10	
62	+V1 POSTCARD	122mm/s postcard/envelope	5 20	5	
03	S (122)	≦ 100mm +V1	5-30	5	
64	+V2 POSTCARD	122mm/spostcard/envelope	5-30	16	
04	S (122)	≦ 100mm +V2	5-30	10	

Purpose	Setting
Function (Purpose)	Used to set the time from the start of the main motor rotation (Ready) to the start of toner supply in previous rotation after turning on the power.

#### **Operation/procedure**

Enter the set value with the 10-key, and press the [START] key.

Set the toner supply previous rotation time.

Setting range	1-99 (sec)
Default	4 (sec)

### 46

46-2				
Purpose	Adjustment			
Function (Purpose)	Used to set the exposure level in each exposure mode.			
Item	Picture quality	Density		

**Operation/procedure** 

- 1. Touch the item to be adjusted. (Automatic adjustment) The currently set value is highlighted beside the adjustment item.
- 2. Press the [START] key.
- The display is shifted to the copy menu.
- 3. Select the paper feed tray and the print density. Use the 10-key to set the exposure level.
- 4. Press the [START] key. Copying is started.

#### (Exposure mode)

Item		Content		Setting range	Default
1	AE	AE			
2	TEXT	Character	Level 3.0		
3	TEXT/PHOTO	Character/Photo	Level 3.0		
4	PHOTO	Photo	Level 3.0	1-99	50
5	AE(TS)	AE (TS)			
6	TEXT(TS)	Character (TS)	Level 3.0		
7	TEXT/PHOTO(TS)	Character/Photo (TS)	Level 3.0		

\* Except for AE and AE (TS), only Level 3 can be set.

Note: When this simulation is canceled, the display returns to the initial menu but the machine is not reset.

46-9			
Purpose	Adjustment		
Function (Purpose)	Used to adjust the shift amovalue for each level (1 to 5) (Text).	ount and the inclination of the exposure mode	
Item Picture quality Density		Density	

#### **Operation/procedure**

- 1. Touch the item to be adjusted.
- The adjustment item and the currently set value are highlighted. 2. Press the [START] key.
- The display is shifted to the copy menu.
- 3. Select the paper feed tray and the print density. Use the 10-key to set the exposure level.
- 4. Press the [START] key.

Copying is started.

Exposure m	oue (Text)

Item		Content	Setting range	Default
1	1.0 (SHIFT)	Character level 1.0 (shift q'ty)	1-99	22
2	1.0 (GAMMA)	Character level 1.0 (slant)	1-99	44
3	2.0 (SHIFT)	Character level 2.0 (shift q'ty)	1-99	36
4	2.0 (GAMMA)	Character level 2.0 (slant)	1-99	47
5	3.0 (SHIFT)	Character level 3.0 (shift q'ty)	1-99	50
6	3.0 (GAMMA)	Character level 3.0 (slant)	1-99	50
7	4.0 (SHIFT)	Character level 4.0 (shift q'ty)	1-99	61
8	4.0 (GAMMA)	Character level 4.0 (slant)	1-99	55
9	5.0 (SHIFT)	Character level 5.0 (shift q'ty)	1-99	72
10	5.0 (GAMMA)	Character level 5.0 (slant)	1-99	60
11	TS 1.0	Character (TS) level 1.0	1-99	22
	(SHIFT)	(shift q'ty)		
12	1TS 1.0	Character (TS) level 1.0	1-99	44
	(GAMMA)	(slant)	1.00	
13	TS 2.0	Character (TS) level 2.0	1-99	36
	(SHIFT)	(shift q'ty)		
14	TS 2.0	Character (TS) level 2.0	1-99	47
	(GAMMA)	(slant)		
15	TS 3.0	Character (TS) level 3.0	1-99	50
	(SHIFT)	(shift q'ty)	1.00	00
16	TS 3.0	Character (TS) level 3.0	1-99	50
	(GAMMA)	(slant)	1.00	00
17	TS 4.0	Character (TS) level 4.0	1-99	61
	(SHIFT)	(shift q'ty)	1.00	01
18	TS 4.0	Character (TS) level 4.0	1-99	55
10	(GAMMA)	(slant)	1.00	00
19	TS 5.0	Character (TS) level 5.0	1-99	72
	(SHIFT)	(shift q'ty)		. 2
20	TS 5.0	Character (TS) level 5.0	1-99	60
20	(GAMMA)	(slant)	1-00	00

Note: When this simulation is canceled, the display returns to the initial menu but the machine is not reset.

46-10		
Purpose	Adjustment	
Function (Purpose)	Used to adjust the shift amount and the inclination value for each level (1 to 5) of the exposure mode (Text/Photo).	
Item	Picture quality	

#### **Operation/procedure**

- 1. Touch the item to be adjusted.
- The adjustment item and the currently set value are highlighted. 2. Press the [START] key.
- The display is shifted to the copy menu.
- 3. Select the paper feed tray and the print density. Use the 10-key to set the exposure level.
- 4. Press the [START] key. Copying is started.

#### (Exposure mode (Text/Photo))

Item		Content	Setting range	Default
1	1.0 (SHIFT)	Character/Photo level 1.0 (shift q'ty)	1-99	30
2	1.0 (GAMMA)	Character/Photo level 1.0 (slant)	1-99	37
3	2.0 (SHIFT)	Character/Photo level 2.0 (shift q'ty)	1-99	40
4	2.0 (GAMMA)	Character/Photo level 2.0 (slant)	1-99	43
5	3.0 (SHIFT)	Character/Photo level 3.0 (shift q'ty)	1-99	50
6	3.0 (GAMMA)	Character/Photo level 3.0 (slant)	1-99	50
7	4.0 (SHIFT)	Character/Photo level 4.0 (shift q'ty)	1-99	57
8	4.0 (GAMMA)	Character/Photo level 4.0 (slant)	1-99	61
9	5.0 (SHIFT)	Character/Photo level 5.0 (shift q'ty)	1-99	64
10	5.0 (GAMMA)	Character/Photo level 5.0 (slant)	1-99	66
11	TS 1.0 (SHIFT)	Character/Photo (TS) level 1.0 (shift q'ty)	1-99	30
12	TS 1.0 (GAMMA)	Character/Photo (TS) level 1.0 (slant)	1-99	37
13	TS 2.0 (SHIFT)	Character/Photo (TS) level 2.0 (shift q'ty)	1-99	40
14	TS 2.0 (GAMMA)	Character/Photo (TS) level 2.0 (slant)	1-99	43
15	TS 3.0 (SHIFT)	Character/Photo (TS) level 3.0 (shift q'ty)	1-99	50
16	TS 3.0 (GAMMA)	Character/Photo (TS) level 3.0 (slant)	1-99	50
17	TS 4.0 (SHIFT)	Character/Photo (TS) level 4.0 (shift q'ty)	1-99	57
18	TS 4.0 (GAMMA)	Character/Photo (TS) level 4.0 (slant)	1-99	61
19	TS 5.0 (SHIFT)	Character/Photo (TS) level 5.0 (shift q'ty)	1-99	64
20	TS 5.0 (GAMMA)	Character/Photo (TS) level 5.0 (slant)	1-99	66

Note: When this simulation is canceled, the display returns to the initial menu but the machine is not reset.

46-11			
Purpose	Adjustment		
Function (Purpose)	Used to adjust the shift amovalue for each level (1 to 5) (Photo).	ount and the inclination of the exposure mode	
Item	Picture quality	Density	

#### **Operation/procedure**

1. Touch the item to be adjusted.

The adjustment item and the currently set value are highlighted. 2. Press the [START] key.

The display is shifted to the copy menu.

- 3. Select the paper feed tray and the print density. Use the 10-key to set the exposure level.
- 4. Press the [START] key. Copying is started.

#### (Exposure mode (Photo))

Item		Content	Setting range	Default
1	1.0(SHIFT)	Photo level 1.0 (shift q'ty)		16
2	1.0(GAMMA)	Photo level 1.0 (slant)		50
3	2.0(SHIFT)	Photo level 2.0 (shift q'ty)		33
4	2.0(GAMMA)	Photo level 2.0 (slant)		50
5	3.0(SHIFT)	Photo level 3.0 (shift q'ty)	1 00	50
6	3.0(GAMMA)	Photo level 3.0 (slant)	1-99	50
7	4.0(SHIFT)	Photo level 4.0 (shift q'ty)		56
8	4.0(GAMMA)	Photo level 4.0 (slant)		61
9	5.0(SHIFT)	Photo level 5.0 (shift q'ty)		62
10	5.0(GAMMA)	Photo level 5.0 (slant)		66

Note: When this simulation is canceled, the display returns to the initial menu but the machine is not reset.

46-12	
Purpose	Adjustment
Function	FAX exposure level adjustment
(Purpose)	(1 mode automatic adjustment)
Section	FAX
Item	Image quality

#### **Operation/procedure**

1. Select "1: COPY START." The currently set value is displayed beside the item.

- 2. Enter the set value of the exposure level with the 10-key, and press the [#/P] key.
- 3. Press the [START] key.

Copying is started and the set value is stored.

Normal display	NOW PRINTING
	DOOR OPEN
Error display	JAM
	PAPER EMPTY

There is no tray selection operation.

The optimum paper tray for the scanned size is selected.

	Item	Setting range	Default
1	COPY START	-	-
2	FAX EXP.LEVEL	0-99	50

Note: Executable only when the FAX is installed.

#### 46-13

Purpose	Adjustment
Function	FAX exposure level adjustment
(Purpose)	(Normal mode individual adjustment)
Section	FAX
Item	Image quality

#### **Operation/procedure**

The currently set value is highlighted beside the item.

- 1. Select an item to be adjusted.
- 2. Enter the set value of the exposure level with the 10-key.
- 3. Press the [START] key.

Copying is started and the set value is stored.

Normal display	NOW PRINTING
Error display	DOOR OPEN
	JAM
	PAPER EMPTY

There is no tray selection operation.

The optimum paper tray for the scanned size is selected.

	Item	Content	Setting range	Default
1	COPY START	Copy start	-	-
2	EXP.LEVEL	Exposure level selection		
3	AE	Normal text AE	0-99	50
4	MANUAL	Normal text MANUAL		

Purpose	Purpose Adjustment	
Function FAX exposure level adjustment		
(Purpose) (Fine text mode individual adjustment)		
Section FAX		
Item	Image quality	

#### **Operation/procedure**

1. Select "1: COPY START."

The currently set value is displayed beside the item.

- 2. Enter the set value of the exposure level with the 10-key, and press the [#/P] key.
- 3. Press the [START] key.

Copying is started and the set value is stored.

Normal display	NOW PRINTING
	DOOR OPEN
Error display	JAM
	PAPER EMPTY

There is no tray selection operation.

The optimum paper tray for the scanned size is selected.

	Item	Content	Setting range	Default
1	COPY START	Copy start	-	-
2	EXP.LEVEL	Exposure level selection		
3	AE (PHOTO ON)	Fine text AE (Half tone)		
4	AE (PHOTO OFF)	Fine text AE		
Б	MANUAL	Fine text MANUAL	0-99	50
5	(PHOTO ON)	(Half tone)		
6	MANUAL (PHOTO OFF)	Fine text MANUAL		

Note: Executable only when the FAX is installed.

#### 46-15

Purpose	Adjustment
Function FAX exposure level adjustment	
(Purpose) (Super Fine mode individual adjustment)	
Section FAX	
Item	Image quality

#### Operation/procedure

The currently set value is highlighted beside the item.

- 1. Select an item to be adjusted.
- 2. Enter the set value of the exposure level with the 10-key.
- 3. Press the [START] key.

Copying is started and the set value is stored.

Normal display	NOW PRINTING
	DOOR OPEN
Error display	JAM
	PAPER EMPTY

#### There is no tray selection operation.

The optimum paper tray for the scanned size is selected.

	Item	Content	Setting range	Default
1	COPY START	Copy start	-	-
2	EXP.LEVEL	Exposure level selection		
3	AE (PHOTO ON)	Super Fine AE (Half tone)		
4	AE (PHOTO OFF)	Super Fine AE	0-00	50
5	MANUAL (PHOTO ON)	Super Fine MANUAL (Half tone)	0-99	50
6	MANUAL (PHOTO OFF)	Super Fine MANUAL		

Note: Executable only when the FAX is installed.

#### 46-16

40-10	
Purpose	Adjustment
Function	FAX exposure level adjustment
(Purpose)	(Ultra Fine mode individual adjustment)
Section	FAX
ltem	Image quality

#### **Operation/procedure**

The currently set value is highlighted beside the item.

- 1. Select an item to be adjusted.
- 2. Enter the set value of the exposure level with the 10-key.
- 3. Press the [START] key.
  - Copying is started and the set value is stored.

Normal display	NOW PRINTING
Error display	DOOR OPEN
	JAM
	PAPER EMPTY

There is no tray selection operation.

The optimum paper tray for the scanned size is selected.

	Item	Content	Setting range	Default
1	COPY START	Copy start	-	-
2	EXP.LEVEL	Exposure level selection		
3	AE (PHOTO ON)	Ultra Fine AE (Half tone)		
4	AE (PHOTO OFF)	Ultra Fine AE		
Б	MANUAL	Ultra Fine MANUAL	0-99	50
5	(PHOTO ON)	(Half tone)		
6	MANUAL (PHOTO OFF)	Ultra Fine MANUAL		

Note: Executable only when the FAX is installed.

46-18	
Purpose	Adjustment
Function (Purpose)	Used to adjust inclination for each exposure mode.
Item	Picture quality

#### **Operation/procedure**

1. Touch the item to be adjusted.

The adjustment item and the current set value are highlighted.

- Press the [START] key. The display is shifted to the copy menu.
- 3. Select the paper feed tray and the print density. Set the exposure level with the 10-key.
- 4. Press the [START] key. Copying is started.

(Auto adjustment)

	Item Content		Setting range	Default	
1	AE	AE			
2	TEXT	Character	Level 3.0		
3	TEXT/PHOTO	Character/Photo	Level 3.0		
4	PHOTO	Photo	Level 3.0	1 00	50
5	AE(TS)	AE(TS)		1-99	50
6	TEXT(TS)	Character (TS)	Level 3.0		
7	TEXT/PHOTO(TS)	Character/Photo (TS)	Level 3.0		

Note: When this simulation is canceled, the display returns to the initial menu but the machine is not reset.

Purpose	Adjustment			
Function (Purpose)	Used to set the control method of the exposure mode.			
Item Picture quality				
Operation/procedure				

1. Touch the item to be adjusted.

The currently set value is highlighted beside the adjustment item.

- 2. Press the [START] key.
- The display is shifted to the adjustment value entry menu.

3. Enter the adjustment value with the 10-key, and press the [START] key. When the [SYSTEM SETTINGS] key is pressed, the display returns to the original state (adjustment item selection menu).

Item		Content	Default
	AE MODE	Auto exposure mode*	
1	(1:EXPOSURE	(1: Priority on Image quality,	2
	2:TONER)	2: Priority on toner consumption)	
	AE STOP(COPY)	Auto exposure STOP mode	
2	(0:FIXED	(COPY)	0
	1:REAL TIME)	(0: Fixed, 1: Real-time)	
3	AE MODE(FAX) (0:FIXED 1:REAL TIME)	Auto exposure STOP mode (FAX) (0: Fixed, 1: Real-time)	0
4	AE STOP(SCAN) (0:FIXED 1:REAL TIME)	Auto exposure STOP mode (SCANNER) (0: Fixed, 1: Real-time)	0
5	PHOTO MODE	Photo mode (1: ED (Error diffusion) , 2: DT (Dither))	2

\* Auto exposure mode

- When SIM 26-6 (Destination setup) is changed from EX Japan to Japan, the setup value becomes 1 (Default: Japan). If, on the contrary, it is changed from Japan to EX Japan, the set value becomes 2 (Default: EX Japan)
- If the auto exposure mode setup value is changed, the setup value of SIM 46-30 (AE limit setup) is reset to the default value.

46-20			
Purpose	Adjustment		
Function	Used to set the exposure correction value of SPF/		
(Purpose)	RSPF for OC exposure.		
Item	Picture quality		

#### **Operation/procedure**

1. Touch the item to be adjusted.

The adjustment item and the currently set value are highlighted.

2. Enter the set value with the 10-key.

Item		Content	Setting range	Default
1	SPF EXPOSURE	SPF	1.00	52
2	RSPF EXPOSURE	RSPF	1-99	55

46-30	
-------	--

Purpose	Setting
Function	Used to set the AE and the limit value in AE
(Purpose)	(Toner save).

#### **Operation/procedure**

- 1. Touch the item to be adjusted.
  - The adjustment item and the currently set value are highlighted.
- 2. Enter the set value with the 10-key.

If SIM 26-6 (Destination setup) and SIM46-19 (Auto exposure mode) are changed, this setup is also changed to the default value accordingly.

Item		Setting range	Default	
1	AE	0.21	0	
2	AE(TS)	0-31	0	

#### 46-31

Purpose	Setting
Function	Used to set the AE and the limit value in AE
(Purpose)	(Toner save).

#### **Operation/procedure**

- Touch the item to be adjusted. The adjustment item and the currently set value are highlighted.
- 2. Enter the set value with the 10-key.

Item		Setting range	Default
1	AE		
2	TEXT	0.0	4
3	TEXT/PHOTO	0-2	I
4	PHOTO		

46-39			
Purpose	Setting		
Function (Purpose)	Used to switch the FAX send image quality.		
Enter the set value with the 10-key.			

Item		Content Setting range		Default
0	HAIRLINE	Original with pencil lines and thin lines	0-1	0
1	PRINTER	Printed original	Ţ	

## 48

48-1	
Purpose	Adjustment
Function (Purpose)	Used to adjust the copy mode magnification ratio (main scanning direction, sub scanning direction).
Section	Image processing
Item	Picture quality

#### **Operation/procedure**

1. Touch the item to be set.

The item and the currently set value are highlighted.

- 2. Press the [START] key.
- The display is shifted to the copy menu.
- 3. Select the paper feed tray and the print density, and enter the adjustment value with the 10-key.
- 4. Press the [START] key. Copying is started.

Item		Content	Setting range	Default
1	F-R	Main scanning magnification ratio adjustment		50
2	SCAN	Sub scanning magnification ratio adjustment		60
3	SPF (SIDE1)	RSPF surface sub scan magnification ratio	1-99	
4	SPF (SIDE2)	RSPF back surface sub scan magnification ratio		50
5	DUPLEX	DUPLEX sub scanning magnification ratio adjustment		
6	MirSpeed	Mirror speed adjustment		

Note: When this simulation is canceled, the display is shifted to the initial menu, but the machine is not reset.

Purpose	Adjustment
Function         Used to adjust the scanner mode magnification	
(Purpose) (main/sub scanning direction).	
Section	Image processing
Item	Picture quality

#### **Operation/procedure**

- 1. Touch the item to be set.
- The item and the currently set value are highlighted.
- 2. Press the [START] key.
  - The display is shifted to the copy menu.
- 3. Select the paper feed tray and the print density, and enter the adjustment value with the 10-key.

### 4. Press the [START] key.

#### Copying is started.

	Item	Content	Setting range	Default
1	F-R	Main scanning magnification ratio adjustment		
2	SCAN	Sub scanning magnification ratio adjustment	1 00	50
3	SPF (SIDE1)	RSPF surface sub scan magnification ratio	1-99	50
4	SPF (SIDE2)	RSPF back surface sub scan magnification ratio		

48-3			
Purpose	Adjustment		
Function	Function Used to adjust the print mode magnification ratio		
(Purpose) correction.			
Section	Image processing		
Item	Picture quality		

#### **Operation/procedure**

- 1. The adjustment item and the currently set value are highlighted.
- 2. Enter the adjustment value with the 10-key.

Changes magnification ratio by changing speed of main motor.

The change of the paper transfer speed is 0.1% when changing value is 1.

ltem		Content	Setting range	Default
1	145mm/s	Main motor speed (145mm/s)		50
2	122mm/s	Main motor speed (122mm/s)	45-55	50

#### 48-8

10 0	
Purpose	Adjustment
Function (Purpose)	FAX magnification adjustment (read)
Section	FAX

#### **Operation/procedure**

The currently set value is highlighted beside the item.

- 1. Select an item to be adjusted.
- 2. Enter the set value of the magnification ratio adjustment with the 10 key.
- 3. Press the [START] key.
  - Copying is started and the set value is stored.

Normal display	NOW PRINTING
	DOOR OPEN
Error display	JAM
	PAPER EMPTY

There is no operation of tray selection.

The optimum paper tray for the scanned size is selected.

Even when the SPF/RSPF is selected, if there is no original on the SPF/RSPF, the OC is scanned.

Even when the OC is selected, if there is any original on the SPF/ RSPF, the SPF/RSPF is scanned. (Setting 2)

Item		Content	Setting range	Default
1	COPY START	Copy start	-	-
2	SCAN SELECT	Scan selection	1-255*	128
2	(OC/SPF/RSPF)	(OC/ SPF/RSPF)	1-200	120
		SCAN Main scanning		
3	OC(MAIN)	magnification ratio	1-255*	128
		adjustment (OC)		
		SCAN Sub scanning		
4	OC(SUB)	magnification ratio	1-255*	128
		adjustment (OC)		
		SCAN Main scanning		
5	SPF(MAIN)	magnification ratio	1-255*	128
		adjustment (SPF)		
		SCAN Sub scanning		
6	SPF(SUB)	magnification ratio	1-255*	128
		adjustment (SPF)		
		SCAN Main scanning		
7	RSPF(MAIN)	magnification ratio	1-255*	128
	. ,	adjustment (RSPF)		
		SCAN Sub scanning		
8	RSPF(SUB)	magnification ratio	1-255*	128
		adjustment (RSPF)		

 $^{\ast}$  The adjustment can be made in the range of –12.7% - +12.7% by the increment of 0.1%.

Note: Executable only when the FAX is installed.

48-9	
Purpose	Adjustment
Function (Purpose)	FAX magnification adjustment (print)
Section	FAX

#### **Operation/procedure**

The currently set value is highlighted beside the item.

- 1. Select an item to be adjusted.
- 2. Enter the set value of the magnification ratio correction with the 10 key.
- 3. Press the [START] key.

Normal display	NOW PRINTING
	DOOR OPEN
Error display	JAM
	PAPER EMPTY

There is no operation of tray selection.

The optimum paper tray for the scanned size is selected.

When two pages are scanned, duplex printing is made.

Item		Content	Setting range	Default
1	COPY START	Copy start	1-255	128
2	Horizontal	Print magnification ratio adjustment (Horizontal, vertical to paper passing)	1-255	128
3	Vertical	Print magnification ratio adjustment (Vertical, parallel to paper passing)	1-255	128
4	Horizontal (DUPLEX)	Print magnification ratio adjustment on the back surface (Horizontal, vertical to paper passing)	1-255	128
5	Vertical (DUPLEX)	Print magnification ratio adjustment on the back surface (Vertical, parallel to paper passing)	1-255	128

50

50-1		
Purpose	Adjustment	
Function (Purpose)	Used to adjust the copy lead edge position.	
Item Picture quality Image position		

#### **Operation/procedure**

- 1. Touch the item to be adjusted.
  - The item and the currently set value are highlighted.
- Enter the adjustment value with the 10-key and press the [P] key., The display goes to the copy menu.
   When the [START] key is pressed, the display goes to the copying state and print is started.

#### (When the [P] key is pressed: Copy menu)

- 3. Select the paper feed tray and the print density. Enter the exposure level with the 10-key.
- 4. Press the [START] key.
  - Copying is started.
- Note: When this simulation is canceled, the display is shifted to the initial menu, but the machine is not reset.

#### (Adjustment procedure)

- 1. Note down the adjustment value of SIM 50-5 (Items 1, 2, 3, 4), and change the value to 99.
- 2. Set SIM 50-1 (Items 2, 3, 4, 5) to 1. (By setting to 1, there is no void.)
- 3. Place a chart with a clear lead edge (or a ruler) on the OC document table.
- Use SIM 50-1 (Item 1) to execute test print. Check the print out and adjust so that the lead edge image is printed. (1 - 99: About 0.127mm/Step)
- Reset the adjustment values of SIM 50-5 (Items 1, 2, 3, 4) to the original values, and execute test print. Check the print out and adjust so that the lead edge image is printed on the lead edge of paper. (1 - 99: About 0.127mm/Step).
- 6. Adjust SIM 50-1 (Items 2, 3, 4, 5) so that the lead edge void on the print out is the specified value. (1 99: About 0.127mm/Step)
- 7. Similar to procedure 6, adjust SIM 50-1 (Item 6, 7) so that the rear edge void is the specified value. (1 99: About 0.127mm/Step)
- 8. Similar to procedure 6, adjust SIM 50-1 (Item 8, 9) so that the left edge void is the specified value. (1 99: About 0.127mm/Step)
- 9. Make an enlargement copy (400%), and check that there is no shade of the cabinet printed at the lead edge.
- 10. If there is a shade printed at the lead edge in procedure 9, adjust SIM 50-1 (Item 10). (1 5: About 0.677mm)
  - \* If there is no problem, set to 2.

	Item	Content	Setting range	Default
1	RRC-A	Original scan start position adjustment Lead edge position adjustment value (OC)	1-99	43
2	DEN-A	Lead edge cancel adjustment (Main tray)	1-99	18
3	DEN-A-MANUAL	Lead edge cancel adjustment (Manual feed tray)	1-99	18
4	DEN-A -OPTION	Lead edge cancel adjustment (Option tray)	1-99	18
5	DEN-A -DUPLEX	Lead edge cancel adjustment (back of the machine)	1-99	18
6	DEN-B	Rear edge void adjustment	1-99	30
7	DEN-B-DUP	Rear edge void adjustment (Duplex)	1-99	50

	Item	Content	Setting range	Default
8	SIDE VOID	Left edge void adjustment (First print surface)	1-99	18
9	SIDE VOID-DUP	Left edge void adjustment (Duplex)	1-99	18
10	LOSS(OC)	Image loss amount adjustment (Lead edge image loss set value) (OC)	1-5	3

50-5			
Purpose	Purpose Adjustment		
Function	tion Used to adjust the print image position (top margin) on		
(Purpose)	the print paper in the print mode.		
Item	em Picture quality Print area		

#### **Operation/procedure**

- 1. Touch the item to be adjusted. The item and the currently set value are highlighted.
- Enter the adjustment value with the 10-key and press the [P] key., The display goes to the copy menu.
- When the [START] key is pressed, the display goes to the copying state and print is started.

(When the [P] key is pressed: Copy menu)

- 3. Select the paper feed tray and the print density. Enter the exposure level with the 10-key.
- Press the [START] key.

Copying is started.

#### Note: When this simulation is canceled, the display is shifted to the initial menu, but the machine is not reset.

	Item	Content	Setting range	Default
1	TRAY1	1st tray	0-99	
2	OPTION	Option tray		52
3	MANUAL	Manual feed	1-99	55
4	DUPLEX	Back print		

50-6			
Purpose	Adjustment		
Function	Used to adjust the print image position (top margin) on		
(Purpose)	print paper in the copy mode. (RSPF)		
Item	Picture quality Image position		

#### **Operation/procedure**

1. Touch the item to be adjusted.

The item and the currently set value are highlighted.

 Enter the adjustment value with the 10-key and press the [P] key., The display goes to the copy menu.
 When the [START] key is pressed, the display goes to the copying state and print is started.

(When the [P] key is pressed: Copy menu)

- 3. Select the paper feed tray and the print density. Enter the exposure level with the 10-key.
- 4. Press the [START] key. Copying is started.
- Note: When this simulation is canceled, the display is shifted to the initial menu, but the machine is not reset.

	Item	Content	Setting range	Default
1	SIDE1	Surface original scan start position adjustment	1-99	50
2	SIDE2	Back original scan start position set	1-99	50
3	END EDGE	Rear edge void adjustment (RSPF)	1-99	50
4	LOSS(SIDE1)	Surface image loss quantity set	1-5	3
5	LOSS(SIDE2)	Back image loss quantity set	1-5	3

Item		Content	Setting range	Default
6		Surface rear edge image	1_5	3
0	REARLOS(SIDET)	loss quantity set	1-5	3
7	BEABLOS(SIDE2)	Back rear edge image loss	1-5	3
		quantity set		Ŭ

# The adjustments on the machine side must have been normally completed.

Purpose	Adjustment
Function (Purpose)	FAX lead edge adjustment (read)
Section	FAX

The currently set value is highlighted beside the item.

- 1. Select an item to be adjusted.
- 2. Enter the set value of the lead edge adjustment with the 10 key.
- 3. Press the [START] key.

Copying is started.

Normal display	NOW PRINTING
Error display	DOOR OPEN
	JAM
	PAPER EMPTY

There is no tray selection operation.

The optimum paper tray for the scanned size is selected.

4. Select the scanning method.

Even when the SPF/RSPF is selected, if there is no original on the SPF/RSPF, the OC is scanned.

Even when the OC is selected, if there is any original on the SPF/ RSPF, the SPF/RSPF is scanned. (Setting 2)

	Item	Content	Setting range	Default
1	COPY START	Copy start	-	-
2	SCAN SELECT (OC/ SPF/RSPF)	Scan selection (1: OC, 2: SPF, 3: RSPF back)	1-3	1
3	LEAD	Scan lead edge position adjustment value of the selected method in 2.	43-57	50
4	LEFT	Scan left edge position adjustment value of the selected method in 2.	43-57	50
5	REAR	Scan rear edge position adjustment value of the selected method in 2.	43-57	50
6	RIGHT	Scan right edge position adjustment value of the selected method in 2.	43-57	50

Note: Executable only when the FAX is installed.

50-9	
Purpose	Adjustment
Function (Purpose)	FAX lead edge adjustment (print)
Section	FAX

#### **Operation/procedure**

The currently set value is highlighted beside the item.

- 1. Select an item to be adjusted.
- 2. Enter the set value of the lead edge adjustment with the 10 key.

3. Press the [START] key.

	Normal display	NOW PRINTING
		DOOR OPEN
	Error display	JAM
		PAPER EMPTY

There is no tray selection operation.

The optimum paper tray for the scanned size is selected.

When two pages are scanned, duplex print is made,

Item		Content	Setting range	Default
1	COPY START	Copy start	-	-
		Print lead edge void		
2	LEAD	adjustment value	43-57	53
		(Front surface)		
		Print left edge void		
3	LEFT	adjustment value	43-57	53
		(Front surface)		
		Print rear edge void		
4	REAR	adjustment value	43-57	53
		(Front surface)		
		Print lead edge void		
5		adjustment value	43-57	53
		(Back surface)		
		Print left edge void		
6	LEFT (DUPLEX)	adjustment value	43-57	53
		(Back surface)		
	BEAR	Print rear edge void		
7		adjustment value	43-57	53
		(Back surface)		

Note: Executable only when the FAX is installed.

50-10		
Purpose	Adjustment	
Function (Purpose)	Used to adjust the print im (Adjustment can be made section.)	age center position. for each paper feed
Section	Image processing (ICU)	
Item	Picture quality	Image position

#### **Operation/procedure**

1. Touch the item to be adjusted.

The item and the currently set value are highlighted.

 Enter the adjustment value with the 10-key and press the [P] key., The display goes to the copy menu.
 When the [START] key is pressed, the display goes to the copying state and print is started.

(When the [P] key is pressed: Copy menu)

- 3. Select the paper feed tray and the print density. Enter the exposure level with the 10-key.
- 4. Press the [START] key. Copying is started.
- Note: When this simulation is canceled, the display is shifted to the initial menu, but the machine is not reset.

Item		Content	Setting range	Default
1	BYPASS	Manual paper feed		
2	TRAY1	1st tray		
3	TRAY2	2nd tray	1.00	50
4	TRAY3	3rd tray	1-99	50
5	TRAY4	4th tray		
6	DUPLEX	Back print		

Purpose	Adjustment	
Function	Used to adjust the print image center position.	
(Purpose)	(Adjustment can be made for each document mode.)	
Section	Image processing	
Item	Picture quality Image position	

#### **Operation/procedure**

1. Touch the item to be adjusted.

The item and the currently set value are highlighted.

 Enter the adjustment value with the 10-key and press the [P] key., The display goes to the copy menu.
 When the [START] key is pressed, the display goes to the copying

state and print is started.

(When the [P] key is pressed: Copy menu)

- 3. Select the paper feed tray and the print density. Enter the exposure level with the 10-key.
- 4. Press the [START] key.

Copying is started.

Note: When this simulation is canceled, the display is shifted to the initial menu, but the machine is not reset.

	Item	Content	Setting range	Default
1	OC	OC document scan		
2		RSPF document front		
2	SFF(SIDET)	surface scan	1-99	50
2		RSPF document back		
3	SFF(SIDE2)	surface scan		

## 51

51-1	
Purpose	Adjustment
Function (Purpose)	Used to adjust the OPC drum separation pawl ON time.
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)
Item	Operation

#### **Operation/procedure**

1. Touch the item to be adjusted.

The item and the currently set value are highlighted.

2.	Enter the adjustment value with the 1		vith the 10-ke	y.
	Item	Setting range	Default	

	nonn	ootangrango	Boladit
1	145mm/s	1.00	50
2	122mm/s	1-99	50

#### 51-2

Purpose	Adjustment
Function (Purpose)	Used to adjust the contact pressure of paper onto the resist roller in each section (copier paper feed section, duplex paper feed section, RSPF paper feed section). (When the print image position varies greatly for the paper or when a lot of paper jam troubles occur, the adjustment is required.)
Section	Paper transport (Discharge/Switchback/Transport)
Item	Operation

#### **Operation/procedure**

1. Touch the item to be adjusted.

The item and the currently set value are highlighted.

2. Press the [START] key.

The display is shifted to the copy menu.

3. Select the paper feed tray and the print density. Enter the adjustment value with the 10-key.

### 4. Press the [START] key.

Copying is started.

Note: When this simulation is canceled, the display is shifted to the initial menu, but the machine is not reset.

	Item	Content	Setting range	Default
1	BYPASS	Manual feed	1-99	50
2	TRAY1	1st tray	1-99	50
3	TRAY2	2nd tray	1-99	50
4	TRAY3	3rd tray	1-99	50
5	TRAY4	4th tray	1-99	50
6	DUPLEX	Back print	1-99	70
7	SPF(SIDE1)	RSPF front surface	1-99	50
8	SPF(SIDE2)	RSPF back surface	1-99	50

51-8	
Purpose	Setting
Function	Used to set the OPC drum separation pawl operation
(Purpose)	inhibit. (ON/OFF)
Section	Image process
Section	(Photoconductor/Developing/Transfer/Cleaning)
Item	Operation

#### **Operation/procedure**

Select the set value with the 10-key.

	Item	Content	Setting range	Default
0	ON	Enable	0.1	0
1	OFF	Disable	0-1	0

51-9	
Purpose	Setting
Function (Purpose)	Used to adjust the OPC drum separation voltage ON/ OFF timing.
Section	Process (OPC drum, developing, transfer, cleaning)
Item	Operation

#### **Operation/Procedure**

1. Touch the item to be adjusted. The item and the currently set value are highlighted.

#### 2. Enter the set value with the 10-key.

Item		Content	Setting range	Default
1	SHV ON	Separation voltage ON timing * Transfer V2ON reference (Synchronized with the adjustment value of 50.)	25-90	50
2	SHV OFF	Separation voltage OFF timing * Transfer V2OFF reference (Synchronized with the adjustment value of 50.)	50-90	75

53-6	
Purpose	Adjustment
Function (Purpose)	Used to adjust the detection level of the RSPF width. The adjustment method is the 4-point system. Set the guide to Max. (A3/WLetter) position, A4R/Letter R position, A5R/Invoice R position, and Min. position for adjustment.
Section	RSPF

#### (Max. position setting)

- 1. Set the guide to the maximum position, and press the [START] key.
- 2. Set A4R and fit the guide, and press the [START] key.
- 3. Set A5R and fit the guide, and press the [START] key.
- 4. Set the guide to the minimum position, and press the [START] key.
- 5. Set the paper recognition width (+), and press the [START] key.
- 6. Set the paper recognition width (–),and press the [START] key.

If "FAILED" is displayed in the above procedure 1, 2, 3, or 4, repeat the adjustment.

#### (Middle position L/S setting)

Middle position	YES	MID-L ADJ.ON
adjustment L	NO	MID-L ADJ.OFF
Middle position	YES	MID-S ADJ.ON
adjustment S	NO	MID-S ADJ.OFF

#### 53-7

Purpose	Adjustment
Function	Used to enter the RSPF width detection adjustment
(Purpose)	value.
Section	RSPF

#### **Operation/Procedure**

- 1. Touch the item to be adjusted.
- The item and the currently set value are highlighted.
- 2. Enter the RSPF original tray size adjustment value (specified on the back of the RSPF) with the 10-key.

	Item	Content	Setting range	Default
1	MAX POSITION	Max. width		
2	POSITION 1	Adjustment point 1	0-000	0
3	POSITION 2	Adjustment point 2	0-333	U
4	MIN POSITION	Min. width		

53-8				
Purpose	Adjustment			
Function (Purpose)	Used to adjust the RSPF scan position of the mirror unit automatically. For the RSPF scan position automatic adjustment, the mirror unit is shifted to 11mm before the RSPF glass cover edge, and is operated automatically to scan images by the unit of 1 step, detecting the position up to the glass cover automatically.			

#### **Operation/Procedure**

With the RSPF or the OC cover open, put a white paper on the OC glass (the RSPF glass surface is included for the RSPF standard model), and press the [START] key.

If the adjustment is executed normally, the adjustment value is displayed and saved in the EEPROM. If an error occurs, "ERR" is displayed and the value is not saved in the EEPROM.

If the adjustment is not performed because of abnormality, "---" is displayed.

During execution of the adjustment, the operation cannot be interrupted.

#### 53-9

Purpose	Adjustment
Function (Purpose)	RSPF read position adjustment

#### **Operation/Procedure**

Press [START] key.

Item	Setting range	Default
Read position adjustment	1-99	50

53-10

Purpose	Adjustment
Function (Purpose)	RSPF exp adjustment

#### **Operation/Procedure**

1. Press [START] key.

2. Enter the adjustment value with the 10-key.

	Item	Setting range	Default
1	SPF EXPOSURE	1.00	50
2	RSPF EXPOSURE	1-99	55

## 55

55-1		
Purpose	Setting	
Function (Purpose)	Used to set the soft switch.	
Section	Operation	

#### **Operation/Procedure**

Used to enter the number of SW to be changed.

The bit to be changed is specified by 10-key. (The current value is highlighted.)  $\label{eq:constraint}$ 

When [START] key is pressed, the entered value is set.

61	

61-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the LSU (polygon motor) operation. Check speed can select 145mm/s or 122mm/s individually.
Section	LSU
Item	Operation

#### **Operation/procedure**

Press the [START] key, and the LSU test is performed.

Used to set the LSU to ON state and check that the sync signal (HSYNC/) is outputted or not.

After operation for 30 sec, the result is displayed. (Interruption cannot be made for 5 sec after starting the operation.)



63-1		
Purpose	Adjustment/setting/operation data output/check (display/print)	
Function	<b>Function</b> Used to check the result of shading correction.	
( <b>Purpose</b> ) (The shading correction data are displayed.)		
Section	Scanner (Exposure)	
Item	Operation	

Pressing the [START] key performs shading, and displays the result (center pixel).

63-7		
Purpose	Adjustment	
	Used to adjust the RSPF white correction start pixel	
Function	position automatically.	
(Purpose)	This adjustment is performed after the lens unit is	
	replaced.	
Section	Scanner	
Item	Operation	

#### **Operation/procedure**

Lift the RSPF unit to the fully open position, and press the [START] key. [] indicates the order number of the pixel of the white sheet for RSPF exposure correction in the RSPF position.

If the adjustment is normally completed, "COMPLETE" is displayed and data are written into the EEPROM.

In case of an abnormality, "ERROR" is displayed and no data is written into the EEPROM.

The RSPF white correction start pixel = Displayed pixel position -34 If the simulation is executed with the RSPF unit closed, an error will result.



64.1

04-1	
Purpose	Operation test/check
Function	Used to check the operation of the printer function
(Purpose)	(auto print operation).
Section	Printer
Item	Operation

#### **Operation/procedure**

- 1. Select the print item with the 10-key.
- Press the [START] key. The display is shifted to the copy menu.
- 3. Select the paper feed tray and the print density.
- 4. Press the [START] key.
- Copying is started.

During execution of the print test, the [SYSTEM SETTINGS] key and the [INTERRUPTION] key are invalid.

	Item	Content	Setting range	Default
1	2 BY 4 MODE	Self print is made in 2 by 4 mode (printing 2 lines and not printing 4 lines). Since scanning is not performed, when the original is set on the RSPF, this cannot be performed. * Duplex print cannot be made.	1-2	1
2	LATTICE PRINT	Lattice print (1cm, 1dot width WLT, A3 print (A3 main scan, WLT sub scan)) is performed. * Duplex print can be made.		

\* If the IMC board is not installed, the key inputs cannot be made.

65-1		
Purpose	Adjustment	
Function	Used to adjust the touch panel (LCD display section)	
(Purpose)	detection position.	
Section	Operation (Display, Operation)	

**Operation/Procedure** 

Press the keys displayed on the LCD sequentially.

Adjust the touch panel coordinates.

When the point of "+" on the LCD is pressed, it turns gray. Press all the four points of "+."

65-2	
Purpose	Adjustment/Setting/Operation data output check (Display, Print)
<b>Function</b> Used to check the touch panel (LCD display sec	
Section	Operation (Display, Operation)

#### **Operation/Procedure**

Check the touch panel coordinates.

Press the keys displayed on the LCD sequentially.

When the touch panel is pressed, the X-coordinate and the Y-coordinate (dot conversion values) are displayed.

#### 65-5

Purpose	Adjustment/Setting/Operation data output check (Display, Print)
Function (Purpose)	Used to check the key inputs of the operation panel.
Section	Operation (screen/operation)

#### **Operation/procedure**

Check the key input of the operation panel.

Press the keys displayed on the LCD sequentially.

After completion of all key entries, "COMPLETE" is displayed.

66-1		
Purpose	Setting	
Function	Licod to change and check the EAX related soft SW	
(Purpose)	Used to change and check the PAX-related soft SW.	
Section	FAX	

#### **Operation/procedure**

- 1. Enter the soft SW number to be selected with the 10-key.
- 2. Check and change the setting content of the selected soft SW.
- 3. Press the [START] key to save the set content.

The FAX-related soft SW is displayed on the LCD, and changing can be made by monitoring it.

66-2			
Purpose	Adjustment		
Function Used to clear the FAX-related soft SW.			
(Purpose) (Except for the FAX adjustment values)			
Section	FAX		

- 1. Enter the country code with the 10-key, and press the [START] key.
- When "1: (YES)" is selected, the soft SW corresponding to the country code is cleared. When "2: (NO)" is selected, the simulation is canceled.

#### Country code

Japan	: 00000000
U.S.A.	: 10110101
Australia	: 00001001
U.K.	: 10110100
France	: 00111101
Germany	: 00000100
Sweden	: 10100101
New Zealand	: 01111110
China	: 00100110
Singapore	: 10011100
Taiwan	: 11111110
India	: 01010011
Malaysia	: 01101100
Hong Kong	: 01010000
Middle east	: 11111101
SouthAfrica	: 10011111
Spain	: 10100000
Portugal	: 10001011
Russia	: 10111000
Denmark	: 00110001
Norway	: 10000010
Switzerland	: 10100110
Italy	: 01011001
Belgium	: 00001111
Luxembourg	: 01101001
Netherlands	: 01111011
Finland	: 00111100

Note: Executable only when the FAX is installed.

66-3		
Purpose	Operation test/check	
Function (Purpose)	FAX PWB memory check	
Section	FAX	
Item	Operation	

#### **Operation/procedure**

Press the [START] key.

Read/write can be checked for FAX PWB memory.

The check result is displayed separately for each memory.

1. Memory to be checked

DRAM		
SRAM		
Elech BOM	Program area	SUM check only
FIASIT NOIVI	Memory area	
Option memory		The memory size follows the automatically detected value.
PAGE		
MODEM		

#### 2. Detailed procedure

1	"55H" is written to all the addresses of each memory, and the address data are read in sequence to check that they were properly written.
2	"AAH" is written to all the addresses of each memory, and the address data are read in sequence to check that they were properly written.
3	"00H" is written to all the addresses of each memory, and the address data are read in sequence to check that they were properly written.
4	Perform checks 1 - 3 sequentially. If there is no abnormality, it is "OK." If there is any abnormality, "NG" is notified to the error address.
5	The check result is saved. New result is overwrited with each check.

Interruption cannot be made during operation.

Note: Executable only when the FAX is installed.

66-4

00-4			
Purpose	urpose Operation test/check		
Function	Signal cond mode (Signal cond lovel: Max )		
(Purpose)	Signal send mode (Signal send level: Max.)		
Section	FAX		
Item	Operation		

#### **Operation/procedure**

Select the signal number with the 10-key, and press the [START] key. The signal is sent to the line and the machine speaker. (Sending the signal is continued until the [SYSTEM SETTINGS] key is pressed.)

By entering the signal number and pressing the [START] key during execution, the signal kind can be changed.

	Item	Send signal	
1	NO SIGNAL	Signal not sent	
2	33.6 V34	33.6 V34	
3	31.2 V34	31.2 V34	
4	28.8 V34	28.8 V34	
5	26.4 V34	26.4 V34	
6	24.0 V34	24.0 V34	
7	21.6 V34	21.6 V34	
8	19.2 V34	19.2 V34	
9	16.8 V34	16.8 V34	
10	14.4 V34	14.4 V34	
11	12.0 V34	12.0 V34	
12	9.6 V34	9.6 V34	
13	7.2 V34	7.2 V34	
14	4.8 V34	4.8 V34	
15	2.4 V34	2.4 V34	
16	14.4 V33	14.4 V33	
17	12.0 V33	12.0 V33	
18	14.4 V17	14.4 V17	
19	12.0 V17	12.0 V17	
20	9.6 V17	9.6 V17	
21	7.2 V17	7.2 V17	
22	9.6 V29	9.6 V29	
23	7.2 V29	7.2 V29	
24	4.8 V27t	4.8 V27t	
25	2.4 V27t	2.4 V27t	
26	0.3 FLG	7EH Flag signal	
27	CED2100		
28	CNG1100	Tana aignal	
29	0.3 V21	ione signai	
30	ANSam		
31	RINGER	Pseudo-ringer sound ([ON HOOK] key ON)	

	ltem	Send signal	
	No MSG	Voice message (no sound)	
32		Under the state where the ring back tone can be sent to the line, keep the sound composition IC volume to 0.	
		Ring back tone (no sound)	
33	No RBT	Under the state where the ring back tone can be	
		sent to the line, keep the G/A volume to 0.	
		Dial pulse (make)	
34	DP MAKE	Maintain the make state with keeping the condition	
		to be able to send to the dial pulse line.	
	DP BRK	Dial pulse (break)	
35		Maintain the break state with keeping the condition	
		to be able to send to the dial pulse line.	

Note: Executable only when the FAX is installed.

### 66-5

Purpose	Operation test/check		
Function	Signal send mode (Signal send level soft SW setting)		
(Purpose)			
Section	FAX		
Item	Operation		

#### **Operation/procedure**

Select the signal number with the 10-key, and press the [START] key.

By setting the signal number, signals are sent to the line and the machine speaker. (Sending signals is continued until interruption command is made (by pressing [SYSTEM SETTINGS] key.)

By entering the signal number and pressing the [START] key during execution, the signal kind can be changed.

Signal number		Send signal	
1	NO SIGNAL	Signal not sent	
2	33.6 V34	33.6 V34	
3	31.2 V34	31.2 V34	
4	28.8 V34	28.8 V34	
5	26.4 V34	26.4 V34	
6	24.0 V34	24.0 V34	
7	21.6 V34	21.6 V34	
8	19.2 V34	19.2 V34	
9	16.8 V34	16.8 V34	
10	14.4 V34	14.4 V34	
11	12.0 V34	12.0 V34	
12	9.6 V34	9.6 V34	
13	7.2 V34	7.2 V34	
14	4.8 V34	4.8 V34	
15	2.4 V34	2.4 V34	
16	14.4 V33	14.4 V33	
17	12.0 V33	12.0 V33	
18	14.4 V17	14.4 V17	
19	12.0 V17	12.0 V17	
20	9.6 V17	9.6 V17	
21	7.2 V17	7.2 V17	
22	9.6 V29	9.6 V29	
23	7.2 V29	7.2 V29	
24	4.8 V27t	4.8 V27t	
25	2.4 V27t	2.4 V27t	
26	0.3 FLG	7EH Flag signal	
27	CED2100		
28	CNG1100		
29	0.3 V21	ione signai	
30	ANSam		
31	BINGER	Pseudo-ringer sound	
51	INGEN	([ON HOOK] key ON)	

Signal number		Send signal	
		Voice message (no sound)	
32 No MSG		Under the state where the ring back tone can be sent to the line, keep the sound composition IC volume to 0.	
		Ring back tone (no sound)	
33	No RBT	Under the state where the ring back tone can be	
		sent to the line, keep the G/A volume to 0.	
		Dial pulse (make)	
34	DP MAKE	Maintain the make state with keeping the condition to be able to send to the dial pulse line.	
	DP BRK	Dial pulse (break)	
35		Maintain the break state with keeping the condition to be able to send to the dial pulse line.	

Note: Executable only when the FAX is installed.

66-6			
Purpose	Purpose Data output, check		
Function (Purpose)	Printing the confidential password		
Section	FAX		
Item	Data	Confidential/Pass code	

#### **Operation/procedure**

Press the [START] key.

The confidential ID table (confidential BOX numbers, confidential BOX names, and confidential password) is printed.

The confidential data of My company mode is printed separately.

Note: Executable only when the FAX is installed.

#### 66-7

Purpose	Data output, check	
Function (Purpose)	Print the screen memory contents	
Section	FAX	
Item	Data	Image data

#### **Operation/procedure**

Press the [START] key.

Used to input all image data (including confidential reception data, remote send image, not-sent image) stored in image memory of the FAX section.

The output image is remained even after outputting.

Note: Executable only when the FAX is installed.

#### 66-10

Purpose	Adjustment/Setting/Check	
Function (Purpose)	Image data memory clear	
Section	FAX	
Item	Data	Image data

#### **Operation/procedure**

Select "1: YES" with the 10-key and press the [START] key. (When "2: NO" is selected, the simulation is canceled.)

Used to clear all image data (including confidential reception data) stored in image memory of the FAX section.

The management table is also cleared (initialized) at the same time.

\* Ilf there is any print data, the power must be turned off after clearing. Note: Executable only when the FAX is installed.

66-11		
Purpose	Operation test/check	
Function	Used to send 300bps signals.	
(Purpose)	(Signal send level: Max.)	
Section	FAX	
Item	Operation	

Select the signal number with the 10-key, and press the [START] key.

By setting the signal number, the specified signal is delivered to the line at the speed of 300bps. (The signal is continuously sent until the interruption command is provided by pressing the [SYSTEM SET-TINGS] key.)

The signal send level can be selected from 0dB or the soft SW set value. The signal send level is returned to the soft SW set value before execution of the mode after completion of the mode.

By entering the number and pressing the [START] key during execution, the signal kind can be changed.

	Item
1	NO SIGNAL
2	11111
3	11110
4	00000
5	010101
6	00001

Note: Executable only when the FAX is installed.

66-12		
Purpose	Operation test/check	
Function	Used to send 300bps signals.	
(Purpose)	(Signal send level: Set by soft SW)	
Section	FAX	
Item	Operation	

#### **Operation/procedure**

Select the signal number with the 10-key, and press the [START] key.

By setting the signal number, the specified signal is delivered to the line at the speed of 300bps. (The signal is continuously sent until the interruption command is provided by pressing the [SYSTEM SET-TINGS] key.)

The signal send level can be selected from 0dB or the soft SW set value. The signal send level is returned to the soft SW set value before execution of the mode after completion of the mode.

By entering the number and pressing the [START] key during execution, the signal kind can be changed.

Item		
1	NO SIGNAL	
2	11111	
3	11110	
4	00000	
5	010101	
6	00001	

Note: Executable only when the FAX is installed.

66-13		
Purpose	Setting	
Function (Purpose)	Used to register the dial numbers.	
Section	FAX	
Item	Operation	

#### **Operation/procedure**

Enter the number with the 10-key, [\*] key, and [#] key. Press the [CLEAR] key to return to the initial state. Press the [START] key to register the entered number. Note: Executable only when the FAX is installed.

#### 66-14

_	
Purpose	Operation check/test
Function (Purpose)	Used to perform the dial test. (10 PPS send test)
Section	FAX
ltem	Operation

#### **Operation/Procedure**

- 1. Select the item with the 10-key, and press the [START] key.
- 2. Set the make time with the 10-key.

The dial is sent with the set value + 26ms.

The sending dial cannot be interrupted.

	Item	Content	Setting range
0	EXECUTE	Execution	-
1	MAKE TIME	Dial pulse make time setting	0-15

Note: Executable only when the FAX is installed.

66-15	
Purpose	Operation check/test
Function (Purpose)	Used to perform the dial test. (20 PPS send test)
Section	FAX
ltem	Operation

#### **Operation/Procedure**

- 1. Select the item with the 10-key, and press the [START] key.
- 2. Set the make time with the 10-key.
- The dial is sent with the set value + 9ms.

The sending dial cannot be interrupted.

	ltem	Content	Setting range
0	EXECUTE	Execution	-
1	MAKE TIME	Dial pulse make time setting	0-15

Note: Executable only when the FAX is installed.

66-16		
Purpose	Operation check/test	
Function	Used to perform the dial test (DTFM signal send test)	
(Purpose)	bed to perform the dial test. (DTT W sight send test)	
Section	FAX	
Item	Operation	

#### **Operation/Procedure**

1. Select the item with the 10-key, and press the [START] key.

2. Enter the set value with the 10-key.

The sending dial cannot be interrupted.

Item		Content	Setting range
0	EXECUTE	Execution	-
1	HIGH (SW)	High group	0-15
2	HIGH-LOW (SW)	High group, Low group	0-15

#### 3. Select the soft SW reflection.

	Item	Content
1	NO STORE TO SW	Not reflected.
2	STORE TO SW	Reflected. (Shift SW value changed.)

Purpose	Operation check/test
Function	Used to check the DTFM signal send operation.
(Purpose)	(Signal send level: Max.)
Section	FAX
Item	Operation

#### **Operation/procedure**

Enter the DTFM signal (1 digit (1 to 9, 0, \*, #)) and press the [START] key. When the [SYSTEM SETTINGS] key is pressed during execution, the simulation is terminated.

Note: Executable only when the FAX is installed.

#### 66-18

Purpose	Operation check/test
<b>Function</b> Used to check the DTFM signal send operation.	
(Purpose) (Signal send level: Set by soft SW.)	
Section	FAX
Item	Operation

#### **Operation/Procedure**

Enter the DTFM signal (1 digit (1 to 9, 0,  $^*$ , #)) and press the [START] key. When the [SYSTEM SETTINGS] key is pressed during execution, the simulation is terminated.

Note: Executable only when the FAX is installed.

66-19			
Purpose	Back up		
Function	Used to write the SBAM data to the Elash BOM		
(Purpose)			
Section	FAX		
Item	Data		

#### **Operation/Procedure**

Select "1: YES" with the 10-key, and press the [START] key. The data are backed up. (When "2: NO" is selected, the simulation is canceled.)

\* The AR-FX5 data cannot be written into the AR-FX7. If it is executed, data are initialized and deleted. In addition, the AR-FX7 data cannot be used in the AR-FX5.

Note: Executable only when the FAX is installed.

66-20		
Purpose	Back up	
Function (Purpose)	Used to write the Flash ROM data to the SRAM.	
Section	FAX	
Item	Data	

#### **Operation/Procedure**

Select "1: YES" with the 10-key, and press the [START] key. The Flash ROM data are read out and written into the SRAM. (When "2: NO" is selected, the simulation is canceled.)

\* The AR-FX5 data cannot be written into the AR-FX7. If it is executed, data are initialized and deleted. In addition, the AR-FX7 data cannot be used in the AR-FX5.

Note: Executable only when the FAX is installed.

#### 66-21

00 21		
Purpose	Check	
Function (Purpose)	FAX information print	
Section	FAX	
Item	Data	

#### **Operation/procedure**

- 1. Select the item to be printed.
- 2. Press the [START] key.

The information of the selected item is printed.

Item		Content	
1	USER SW.LIST	User setting list	
2	SOFT SW.LIST	Soft SW list	
3	SYSTEM ERROR	System error list Used to print the system error log (error number and time).	
4	PROTOCOL	Protocol error list Regardless of soft SW38-1 status, the protocol monitor of the preceding communication is printed. (Printing is allowed at any time before starting the next communication.) For this operation, the protocol monitor of one communication is always buffered.	
5	PARTIAL SRAM CLEAR	Clear the FSS area in the SRAM.	

Note: Executable only when the FAX is installed.

66-22	
Purpose	Setting
Function (Purpose)	Handset sound volume adjustment (Japan only)
Section	FAX
Item	Operation

#### Operation/procedure

- 1. Select the sound volume to be set.
  - (MAX: Large, MIDDLE: Medium, MIN: Small)
- 2. Press [START] key.

Selection of 1, 2, and 3 can be made even during execution of the simulation.

A sound is generated during execution of the simulation.

Note: Execution is possible only when FAX is installed.

66-24				
Purpose	Data clear			
Function	Lised to clear the EAST storage data (SEC only)			
(Purpose)	Used to clear the PAST storage data. (SEC only)			
Section	FAX			
Item	Data	Initializing		

#### **Operation/procedure**

Select "1: YES" with the 10-key and press the [START] key. The FAST storage data are cleared. (When "2: NO" is selected, the simulation is canceled.)

66-30		
Purpose	Operation test/check	
Function (Purpose)	Used to set the TEL/LIU.	
Section	FAX	
Item	Operation	

When the relay state of the polarity reverse relay, the handset hook switch, or the external telephone hook switch is changed, the content of change is displayed regardless of the soft SW setup (real time). The display of change is kept until an interruption command is supplied by pressing the [SYSTEM SETTINGS] key.

ltom	Notification contents	
nem	Signal low	Signal high
HS2	ON	OFF
HS1	ON	OFF
RHS	ON	OFF
EXHS	ON	OFF

Note: Executable only when the FAX is installed.

66-31	

Purpose	Setting
Function (Purpose)	Used to set the TEL/LIU.
Section	FAX
Item	Operation

#### **Operation/Procedure**

- 1. Enter the set value. (Valid only 1 to 5)
- 2. The entered bit is alternatively switched between "0" and "1" and the target signal name is highlighted.
- 3. Press the [START] key to send the signal.

When the [CUSTUM SETTINGS] key is pressed, the output is terminated. Note: Executable only when the FAX is installed.

66-32		
Purpose	Operation test/check	
Function (Purpose)	Receive data check	
Section	FAX	
Item	Operation	

#### **Operation/procedure**

The fixed data received from the line are checked and the result is displayed. When data are coincident, "OK" is displayed. When not, "NG" is displayed. Note: Executable only when the FAX is installed.

#### 66-33

Purpose	Operation test/check
Function (Purpose)	Signal detection check
Section	FAX
Item	Operation

#### **Operation/Procedure**

Signal detection is checked and the result is displayed. Note: Executable only when the FAX is installed.

#### 66-34

Purpose	Operation test/check
Function (Purpose)	Communication time measurement display
Section	FAX
Item	Operation

#### **Operation/procedure**

The send/receive test is performed, and the time required for send/ receive of the image data in the test is measured and displayed.

Setup on the user side when executing communication		Communication means: Memory sendPicture quality: Normal CharacterDensity: LighterECM: ONSender information: OFF		
Measuring	Send	From flag reception before sending of image data until sending of RCP frame		
range	Receive	From flag reception before reception of image data until reception of RCP frame		
Mode when measuring		Used to make communication not in a simulation process but in the normal screen and measure the time.		
How to check the time		Enter the simulation for communication time check and check the time.		
Measuring unit		msec		

When there are two or more send/receive operations of image data in one communication, only the time of the last send/receive data near the end is measured.

Note: Executable only when the FAX is installed.

# 66-37

Purpose	Adjustment/Setting/Check
Function (Purpose)	Speaker sound volume adjustment
Section	FAX

#### **Operation/procedure**

The following test sound is delivered to the line and the speaker to adjust the sound kind and volume.

The send level to the line is the set value of soft SW.

The set values of the selected sound kind and volume are written to each soft SW.

1. Sound kinds pattern

Sound kinds (Test sound)		Sound volume set value			
RINGER	Call sound	DEF. LAR. MED. SMA			SMA.
	Line monitor sound (Test	DEE	IAR	MED	SMA
	signal sound)	521.	<b>L</b> ) u t.	MED.	0117.0
	On-hook (Test sound,				
ON HOOK	communication signal	DEF.	LAR.	MED.	SMA.
	sound)				
SCAN FINISH	Scan finish sound	DEF.	LAR.	MED.	SMA.
TX/BX FINISH	Communication finish	DEE	ΙΔR	MED	SMA
	sound	DLI.	LAN.		SIVIA.
DTMF	DTFM send sound	DEF.	LAR.	MED.	SMA.

LAR: (MED. Value + 1)

MED: (SMA value +1) - (LAR value - 1)

SMA: 1 - (MED. Value + 1)

2. Sound volume pattern

66-41	
Purpose	Adjustment/Setting/Check
Function (Purpose)	CI signal check

When the [START] key is pressed, the call signal from CI pin is detected to deliver the call sound to the line and the speaker. The volume of call sound follows the soft SW.

Signal detection and delivery of pseudo-call sound at detection are executed until the interruption command is provided by pressing the [SYSTEM SETTINGS] key.

Note: Executable only when the FAX is installed.

66-52	
Purpose	Operation test/check (Japan only)
Section	FAX
Item	Operation
Function (Purpose)	Pseudo-ringer check

#### **Operation/procedure**

Press [START] key.

The call sound of the machine and the pseudo-ring are generated.

## [7] SELF DIAG AND TROUBLE CODE

### 1. Trouble code list

Trouble code			Trouble
Main	Sub	Trouble contents	detection
code	code	code	
A0	01	Security incompatibility error	
E1	00	IMC PWB communication trouble	MCU
	10	IMC PWB trouble	
	11	IMC PWB ASIC error	
	12	IMC PWB CODEC IC error	
	13	IMC PWB flash ROM error	
	14	IMC PWB expaned memory module (DIMM) error	
	15	IMC PWB page memory error /SRAM error	
	16	IMC PWB standard compression memory error	
	17	IMC PWB smoothing IC error	
	80	IMC PWB communication trouble (protocol)	
	81	IMC PWB communication trouble (Parity)	
	82	IMC PWB communication trouble (Overrun)	
	84	IMC PWB communication trouble (Framing)	
	88	IMC PWB communication trouble (Time-out)	
E7	02	LSU trouble	
	10	CCD black level error	
	11	CCD white level error	
	12	Shading trouble	
F1	00	Finisher communication trouble	FIN
	03	Delivery roller lift motor trouble	
	10	Staple motor trouble	
	15	Tray lift motor trouble	
	19	Paper alignment motor F trouble	
	20	Paper alignment motor R trouble	
	37	RAM data trouble	
	50	Incompatible trouble	
	95	Paper exit option configuration error	
F2	02	Toner supply failure	
	04	Model error	
		Type error	
		Destination error	
		Data abnormality	
		Misc error	
	05	CRUM chip communication error	
F5	02	Copy lamp (xenon lamp) error	
F6	00	FAX control PWB communication trouble	MCU
-	10	FAX control PWB trouble	
	80	FAX control PWB communication trouble	
		(Protocol)	
	81	FAX control PWB communication trouble (Parity)	
	82	FAX control PWB communication trouble (Overrun)	
	84	FAX control PWB communication trouble	
	88	(Framing) FAX control PWB communication trouble	
		(Time-out)	
	96	Combination error between the MCU and the FAX firmware.	
	99	FAX control PWB destination error	
F9	00	Printer PWB communication trouble	MCU
	10	Printer PWB trouble	

Trouble code			Troublo
Main	Sub	Trouble contents	detection
code	code		detection
F9	80	Printer PWB communication trouble (Protocol)	
	81	Printer PWB communication trouble (Parity)	
	82	Printer PWB communication trouble (Overrun)	
	84	Printer PWB communication trouble (Framing)	
	88	Printer PWB communication trouble (Time-out)	
H2	00	Main heater lamp thermistor open hard detection	
	01	Sub heater lamp thermistor open hard detection	
H3	00	Main heater lamp abnormally high temperature hard detection trouble	
	01	Sub heater lamp abnormally high temperature hard detection trouble	
	10	Main heater lamp abnormally high temperature soft detection trouble	
	11	Sub heater lamp abnormally high temperature soft detection trouble	
H4	00	Main heater lamp abnormally low temperature detection	
	01	Sub heater lamp abnormally low temperature detection	
	20	Main heater lamp abnormally low temperature detection	
	21	Sub heater lamp abnormally low temperature detection	
H5	01	10 times of continuous detection of the lower paper exit sensor (POD1) lead edge jam or the upper paper exit sensor (POD2) lead edge jam or the duplex sensor (PPD2) rear edge jam	
L1	00	Scanner feed trouble	
L3	00	Scanner return trouble	
L4	01	Main motor trouble	
	11	Shifter motor trouble	
	31	VFM trouble	
	32	DCFM or DCFM2 trouble	
	33	VFM2 trouble	
L6	10	Polygon motor trouble	
L8	10	Power abnormality detection trouble	
U1	01	FAX battery error	
	02	PANEL LOW battery error	
U2	04	EEPROM communication error	
	20	Machine speed code data error	
U7	00	RIC communication trouble	
09	00	trouble	OPE
	80	Operation control PWB communication trouble (Protocol)	
	81	Operation control PWB communication trouble (Parity)	
	82	Operation control PWB communication trouble (Overrun)	
	84	Operation control PWB communication trouble (Framing)	
	88	Operation control PWB communication trouble (Time-out)	
	99	Operation panel destination error	

Trouble code			Trouble	
Main	Sub	Trouble contents	detection	
code	code		detection	
EE	EL	Developer adjustment trouble		
		(Over-toned abnormality)		
	EU	Developer adjustment trouble		
		(Under-toned abnormality)		
PF	00	PF trouble		

### 2. Details of trouble code

Trouble			
Main	Sub		Details of trouble
code	code		
A0	01	Content	Security incompatibility error
		Details	When the PCL or the FAX control PWB is
			installed, it does not match with
			PWB security.
		Cause	The security compatibility/incompatibility of
			the installed PCL or FAX control PWB
		Check	Cheek the security compatibility/
		and	incompatibility of each board. Match the
		remedy	security compatibility/incompatibility of the
F1	00	Content	IMC PWB communication trouble
	00	Details	Communication trouble between MCU and
			IMC PWB
		Cause	IMC PWB connector disconnection.
			Motherboard connector pin breakage.
		- · ·	IMC PWB ROM defect, data failure.
		Check and	Check the connectors of the IMC PWB and MCU PWB.
		remedy	Check the grounding of the copier.
			Check the ROM of the IMC PWB.
	10	Content	IMC PWB trouble
		Details	IMC PWB hardware abnormality
		Cause	IMC PWB abnormality
		Check	Replace the IMC PWB
		and remedy	
	11	Content	IMC PWB ASIC error
		Details	ASIC abnormality on IMC PWB
		Cause	IMC PWB abnormality
		Check	Replace the IMC PWB
		and	
	10	Contont	
	12	Details	CODEC IC (JBIG chin) abnormality on
		Detailo	IMC PWB
		Cause	IMC PWB abnormality
		Check	Replace the IMC PWB
		and remedy	
E1	13	Content	IMC PWB flash ROM error
		Details	Flash ROM abnormality on IMC PWB
		Cause	IMC PWB abnormality
		Check	Replace the IMC PWB.
		and	When the program download is abnormally
		remedy	terminated, a error may occur. In this case,
		Remarke	Program BOM abnormality
L		riemants	r rogram now abnormality

Trouble				
code		Dataila of traubla		
Main Sub		Details of trouble		
code	code			
E1	14	Content	IMC PWB expanded memory module (DIMM) error	
		Details	IMC extended compression memory module (DIMM) installation error.	
			IMC extended compression memory module (DIMM) access error.	
		Cause	IMC expanded memory module installation trouble	
			IMC expanded memory module trouble.	
			IMC expanded memory contact trouble. IMC PWB abnormality.	
		Check and	Check installation of the expanded memory module. (Spec: Added to Slot 1.)	
		remedy	Replace the expanded memory module.	
		Remarks	Extend memory abnormality for compressed image store (DIMM module)	
	15	Content	IMC PWB page memory error /SRAM error	
		Details	IMC PWB page memory or work SRAM	
		Cause	IMC PWB abnormality	
		Check	Replace the IMC PWB	
		and remedy		
		Remarks	Print buffer page memory or work SRAM abnormality	
	16	Content	IMC PWB standard compression memory error	
		Details	Access error of standard compression memory on IMC PWB	
		Cause	IMC PWB abnormality	
		Check and	Replace the IMC PWB	
		remedy		
		Remarks	Standard compression image store memory abnormality	
	17	Content	IMC PWB smoothing IC error	
	-	Details	IMC PWB smoothing IC abnormality	
		Cause	IMC PWB abnormality	
		Check	Replace the IMC PWB	
		and remedy		
	80	Content	IMC PWB communication trouble	
		Details	Communication trouble between MCU and IMC PWB (Protocol error)	
		Cause	IMC PWB connector disconnection.	
			Motherboard connector pin breakage.	
			IMC PWB ROM defect, data failure.	
		Check and	Check the connectors of the IMC PWB and MCU PWB.	
		remedy	Check the grounding of the copier.	
	01	Contont	Check the ROM of the IMC PWB.	
	81	Details	Communication trouble between MCU and	
			printer IMC (Parity error)	
		Cause	IMC PWB connector disconnection.	
			Mounerboard connector pin breakage.	
		Check	Check the connectors of the IMC PWB and	
		and	MCU PWB.	
		remedy	Check the grounding of the copier.	
			Uneck the HOM of the IMC PWB.	

Trouble				
code		Details of trouble		
Main	Sub			
E1	code 82	Content	IMC PWB communication trouble	
		Details	Communication trouble between MCU and	
		Cause	IMC PWB connector disconnection.	
			Motherboard connector pin breakage.	
			IMC PWB ROM defect, data failure.	
		Check and	Check the connectors of the IMC PWB and MCU PWB.	
		remedy	Check the grounding of the copier. Check the ROM of the IMC PWB.	
	84	Content	IMC PWB communication trouble (Framing)	
		Details	Communication trouble between MCU and IMC PWB (Framing error)	
		Cause	IMC PWB connector disconnection.	
			Motherboard connector pin breakage.	
			IMC PWB ROM defect, data failure.	
		Check and	Check the connectors of the IMC PWB and MCU PWB.	
		remeay	Check the grounding of the copier.	
	00	Contont	Check the ROM of the IMC PWB.	
	88	Content	(Time-out)	
		Details	Communication trouble between MCU and IMC PWB (Time-out error)	
		Cause	IMC PWB connector disconnection.	
			Motherboard connector pin breakage.	
		Check and	Check the connectors of the IMC PWB and	
			MCU PWB.	
		Temedy	Check the grounding of the Copier.	
F7	02	Content	LSU trouble	
L,		Details	BD signal from LSU is not detected in a	
		Cauco	constant cycle (Kept OFF or ON)	
		Cause	trouble or disconnection.	
				Polygon motor rotation abnormality.
			Laser does not illuminate.	
			MCU PWB failure.	
		Check and remedy	Check for disconnection of the LSU	
			Check the LSU operation with SIM 61-1	
			Check that the polygon motor rotates	
			normally.	
			Check laser LED lighting.	
			Replace the LSU unit.	
	10	Contont	Replace the MCU PWB.	
	10	Details	CCD black reference plate scan level	
			abnormality when the copy lamp turns off.	
		Cause	Flat cable installation failure to CCD unit. CCD unit error.	
		Check	Check flat cable installation to the CCD	
		and	unit. Check CCD unit	
L		remeuy		

Trouble				
code		Details of trouble		
Main	Sub		Details of trouble	
code	code			
E7	11	Content	CCD white level error	
		Details	Improper CCD white reference plate reading level for copy lamp lighting	
		Cause	Flat cable installation failure to CCD unit. Dirt on the mirror, lens, and reference white plate. Copy lamp lighting trouble. CCD unit abnormality. MCU PWB abnormality. (Occurred in the BSPE scan position)	
		Check and remedy	Clean the mirror, the lens, and the reference white plate. Check the copy lamp light quantity and its operation. (SIM 5-3) Check CCD unit. Check MCLI PWB	
	12	Content	Shading trouble	
	12	Details	White correction is not completed in the	
		Cause	specified number of times. Flat cable installation failure to CCD unit. Dirt on the mirror, lens, and reference. white plate. Copy lamp lighting trouble. CCD unit abnormality. MCU PWB abnormality.	
		Check and remedy	Clean the mirror, the lens, and the reference white plate. Check the copy lamp light quantity and its operation. (SIM 5-3) Check CCD unit. Check MCU PWB.	
F1	00	Content	Finisher communication trouble	
		Details	Communication line test error occurs when power is turned on or after the exit of a simulation mode. Error in finisher communication	
		Cause	Connection trouble or disconnection of the connector and harness between the body and the finisher. Finisher control PWB trouble. Control PWB failure. Malfunction by noises.	
		Check and remedy	Canceled by turning OFF/ON the power. Check the connectors and the harness of communication line. Replace the finisher control PWB.	
	03	Content	Delivery roller lift motor trouble	
		Details	Paper exit roller lift-up motor operation abnormality	
		Cause	Motor lock. Motor rpm abnormality. Overcurrent to the motor. Finisher control PWB trouble.	
		Check and remedy	Use SIM3-3 to check the delivery roller lift motor operation	
	10	Content	Staple motor trouble	
		Details	Staple motor operation abnormality	
		Cause	Motor lock. Motor rpm abnormality. Overcurrent to the motor. Finisher control PWB trouble	
		Check and remedy	Use SIM 3-3 to check the staple motor operation.	
Trouble				
---------	------	---------------------	--	
code			Details of trouble	
Main	Sub			
code	code	<b>A</b> <i>i i</i>	<b>T</b> 116	
F1	15	Content	Iray lift motor trouble	
		Details	The finisher lift-up motor does not reach	
		Cause	Lift-up motor abnormality	
		ouuoo	Lift-up motor upper limit sensor	
			abnormality.	
			Finisher PWB abnormality.	
		Check	Use SIM 3-3 to check the lift-up motor	
		and	operation	
	10	remedy	Den ev eligen entre etc. E trevible	
	19	Detaile	Alignment motor P trouble	
		Causa	Alignment motor operation abnormality	
		Cause	Motor rom abnormality	
			Overcurrent to the motor	
			Finisher control PWB trouble	
		Check	Use SIM3-3 to check the alignment (E)	
		and	motor operation.	
		remedy		
	20	Content	Paper alignment motor R trouble	
		Details	Alignment motor operation abnormality	
		Cause	Motor lock.	
			Motor rpm abnormality.	
			Overcurrent to the motor.	
			Finisher control PWB trouble.	
		Check	Use SIM3-3 to check the alignment (R)	
		remedy		
	37	Content	RAM data trouble	
		Details	Backup RAM contents are disturbed	
		Cause	Finisher control PWB trouble.	
			Malfunction by noise.	
		Check	Replace the finisher control PWB.	
		and		
	50	Contont	Incompatible trauble	
	50	Dotaile	Speed doos not coincide between finisher	
		Details	and main unit	
			A finisher which is not applicable is	
			installed.	
		Cause	Connection of a finisher incompatible with	
			the machine is detected.	
		Check	Connect the MX-FN13 to the machine.	
		remedv		
	95	Content	Paper exit option configuration error	
		Details	An improper option is installed.	
		Cause	Configuration of the paper exit option is	
			improperness.	
		Check	Install a proper option.	
		and		
F2	02	Content	Toper supply failure	
	52	Details	The value judged from the actual toner	
		Dotailo	supply hysteresis differs greatly from the	
			toner sensor value	
		Cause	Developing unit trouble.	
			Toner supply abnormality caused by	
		Ohaal	Installation of unpacked toner cartridge.	
		Check	Replace the developing unit.	
		remedv	Use SIM 25-1 to perform DV stirring.	
I	1			

Trou	uble		
CO	ae		Details of trouble
code	code		
F2	04	Content	Model error
			Type error
			Destination error
			Data abnormality
			Misc error
		Details	(Model error)
			When the boot program model code does
			information
			(Type error)
			When the CRUM type is other than
			[Genuine/Conversion/Production rotation]
			(Destination error)
			The destination of the body differs from that of the CRUM
			(Data abnormality)
			The initial check information includes an
			erroneous value.
			When the max, toner supply time is 00.
		Cause	CBUM chip failure
		Cullo	Erroneous TNCA.
		Check	Replace the CRUM chip.
		and	Replace the TNCA.
	0.5	remedy	
	05	Content	CRUM chip communication error
		Cause	Developing unit contact trouble
			MCU PWB failure
		Check	Check installation of the developing unit.
		and remedy	Replace the MCU PWB.
F5	02	Content	Copy lamp (xenon lamp) error
		Details	The copy lamp does not light up
		Cause	Copy lamp abnormality.
			Copy lamp harness abnormality.
			CCD PWB harness abnormality.
		Check	Check the copy lamp. (SIM 5-3)
		remedy	When the lamp lights: Check the harnesses and connectors
		-	between the CCD unit and the MCU PWB.
			When the lamp does not light:
			the copy lamp and the MCU PWB
			Replace the copy lamp unit.
			Replace the MCU PWB.
F6	00	Content	FAX control PWB communication trouble
		Details	Communication trouble between MCU and
		Cause	FAX control PWB connector
			disconnection.
			PWB and MCU PWB.
			Motherboard connector pin breakage.
		<u>.</u>	FAX control PWB ROM defect/Data failure.
		Check	Check the connectors and the harness of EAX control PWB and MCLLPWB
		remedy	Check the arounding of the copier.
			Check FAX control PWB ROM.
	10	Content	FAX control PWB trouble
		Details	FAX control PWB abnormality
		Cause	FAX control PWB defect
		Check	Replate the FAX control PWB
		remedv	

Trouble			
CO	de		Details of trouble
code	code		
F6	80	Content	FAX control PWB communication trouble (Protocol)
		Details	Communication trouble between MCU and FAX control PWB (Protocol error)
		Cause	FAX control PWB connector disconnection
			Harness trouble between FAX control PWB and MCU PWB.
			Motherboard connector pin breakage. FAX control PWB ROM defect/Data failure.
		Check and	Check the connectors and the harness of FAX control PWB and MCU PWB.
		remedy	Check the grounding of the copier.
			Check FAX control PWB ROM.
	81	Content	FAX control PWB communication trouble (Parity)
		Details	Communication trouble between MCU and FAX control PWB (Parity error)
		Cause	FAX control PWB connector disconnection
			PWB and MCU PWB.
			Motherboard connector pin breakage. FAX control PWB ROM defect/Data failure.
		Check and	Check the connectors and the harness of FAX control PWB and MCU PWB.
		remedy	Check the grounding of the copier.
			Check FAX control PWB ROM.
	82	Content	FAX control PWB communication trouble (Overrun)
		Details	Communication trouble between MCU and FAX control PWB (Overrun error)
		Cause Check and	FAX control PWB connector disconnection.
			Harness trouble between FAX control PWB and MCU PWB.
			Motherboard connector pin breakage.
			FAX control PWB ROM defect/Data failure.
			Check the connectors and the harness of FAX control PWB and MCU PWB.
		remeay	Check the grounding of the copier.
	84	Content	FAX control PWB communication trouble
		Details	(Framing) Communication trouble between MCU and
		Cause	FAX control PWB (Framing error) FAX control PWB connector
			disconnection. Harness trouble between FAX control
			PWB and MCU PWB. Motherboard connector pin breakage.
			FAX control PWB ROM defect/Data failure.
		Check and	Check the connectors and the harness of FAX control PWB and MCU PWB.
		remedy	Check the grounding of the copier. Check FAX control PWB ROM.

Irou	aldu		
Main	Sub		Details of trouble
code	code		
F6	88	Content	FAX control PWB communication trouble (Time-out)
		Details	Communication trouble between MCU and FAX control PWB (Time-out error)
		Cause	FAX control PWB connector
			disconnection. Harness trouble between FAX control
			PWB and MCU PWB.
			FAX control PWB ROM defect/Data failure.
		Check	Check the connectors and the harness of
		and remedy	FAX control PWB and MCU PWB.
			Check FAX control PWB ROM.
	96	Content	Combination error between the MCU and the FAX firmware.
		Details	The version of the FAX firmware is not changed "04 xx" or later
		Cause	The version of the FAX firmware is not
		Ohaali	proper.
		and remedy	"04.xx" or later.
	99	Content	FAX control PWB destination error
		Details	The machine destination setup does not
			coincide with the FAX control PWB destination setup.
		Cause	The machine destination setup (Sim 26-6) does not coincide with the FAX control
		Check	Check the variety of FAX LIU PWB
		and	Check the machine destination setup (Sim
		remedy	22-6) and FAX country code (Soft SW table).
F9	00	Content	Printer PWB communication trouble
		Details	Communication trouble between MCU and printer PWB
		Cause	Printer PWB connector disconnection.
			and the MCU PWB.
			Motherboard connector pin breakage. Printer PWB ROM defect/Data failure.
		Check	Check the connectors and the harness of
		and remedy	the printer PWB and MCU PWB.
		loniouj	Check ROM on printer PWB.
	10	Content	Printer PWB trouble
		Details	Printer PWB abnormality
		Cause	Printer PWB defect
		and	neplace the printer FWB
		remedy	
	80	Content	(Protocol)
		Details	Communication trouble between MCU and printer PWB (Protocol error)
		Cause	Printer PWB connector disconnection. Harness trouble between the printer PWB
			and the MCU PWB.
			Printer PWB ROM defect/Data failure.
		Check and	Check the connectors and the harness of the printer PWB and MCU PWB.
		remedy	Check the grounding of the copier.
			Check ROM on printer PWB.

Trouble				
со	de	Details of trouble		
Main	Sub			
code F9	code 81	Content	Printer PWB communication trouble	
		Details	Communication trouble between MCU and	
		Cause	Printer PWB (Parity error) Printer PWB connector disconnection.	
			Harness trouble between the printer PWB	
			Motherboard connector pin breakage.	
			Printer PWB ROM defect/Data failure.	
		Check and	Check the connectors and the harness of the printer PWB and MCU PWB.	
		remedy	Check the grounding of the copier.	
			Check ROM on printer PWB.	
	82	Content	Printer PWB communication trouble (Overrun)	
		Details	Communication trouble between MCU and printer PWB (Overrun error)	
		Cause	Printer PWB connector disconnection.	
			Harness trouble between the printer PWB and the MCU PWB.	
			Motherboard connector pin breakage. Printer PWB ROM defect/Data failure.	
		Check and	Check the connectors and the harness of the printer PWB and MCU PWB.	
		remedy	Check the grounding of the copier.	
		<u> </u>	Check ROM on printer PWB.	
	84	Content	Printer PWB communication trouble (Framing)	
		Details	Communication trouble between MCU and printer PWB (Framing error)	
		Cause	Printer PWB connector disconnection.	
			Harness trouble between the printer PWB and the MCU PWB.	
			Motherboard connector pin breakage. Printer PWB ROM defect/Data failure.	
		Check	Check the connectors and the harness of	
		and remedy	the printer PWB and MCU PWB.	
		Tomody	Check ROM on printer PWB.	
	88	Content	Printer PWB communication trouble (Time-out)	
		Details	Communication trouble between MCU and printer PWB (Time-out error)	
		Cause	Printer PWB connector disconnection.	
			Harness trouble between the printer PWB and the MCU PWB.	
			Motherboard connector pin breakage. Printer PWB ROM defect/Data failure.	
		Check	Check the connectors and the harness of the printer PWB and MCLI PWB	
		remedy	Check the grounding of the copier.	
110	00	Occurs 1	Check ROM on printer PWB.	
H2	00	Content	detection	
		Details	Main heater lamp thermistor open detection.	
		Course	Fusing unit not installed.	
		Cause	wan thermistor detect.	
			Fusing section connector contact failure.	
			Fusing unit not installed.	
		Check	Check the harness and the connector of the thermistor and the MCL	
		remedy		

Tro	uble		
CO	de		Details of trouble
Main	Sub		
H2	01	Content	Sub heater lamp thermistor open hard
			detection
		Details	Fusing sub thermistor open detection. Fusing unit not installed.
		Cause	Sub thermistor defect.
			Control PWB failure.
			Fusing section connector contact failure.
		Check	Fusing unit not installed.
		and remedy	the thermistor and the MCU.
H3	00	Content	Main heater lamp abnormally high temperature hard detection trouble
		Details	The fusing main heater thermistor causes abnormally high temperature
		Cause	Main thermistor defect. Control PWB failure. Fusing section connector contact failure.
		Check	Check the main heater lamp blinking with
		and remedy	SIM 5-2-1. When the lamp blinks normally:
		-	Check the thermistor and the harness.
			circuit.
			If lamp lights and stays lit: Check the power circuit and the lamp control circuit on MCU PWB.
			Clear the display of self-diagnostics with SIM 14.
	01	Content	Sub heater lamp abnormally high temperature hard detection trouble
		Details	The fusing sub thermistor causes abnormally high temperature
		Cause	Sub thermistor defect. Control PWB failure. Fusing section connector contact failure.
		Check	Check the sub heater lamp blinking with
		and remedy	SIM 5-2-2. When the lamp blinks normally:
			Check the thermistor and the harness. Check the MCU PWB thermistor input
			If lamp lights and stays lit:
			Check the power circuit and the lamp
			Clear the display of self-diagnostics with
			SIM 14.
	10	Content	Main heater lamp abnormally high temperature soft detection trouble
		Details	A/D value the fusing main thermistor causes abnormally high temperature (over 230°C).
		Cause	Main heater lamp thermistor defect.
			Fusing section connector contact failure.
		Check	Check the main heater lamp blinking with
		and remedv	SIM 5-2-1. When the lamp blinks normally:
		<b> </b>	Check the MCU PWB thermistor input
			If lamp lights and stays lit:
			Check the power circuit and the lamp control circuit on MCU PWB.
			Clear the display of self-diagnostics with
			UIWI 14.

Trouble							
code		Details of trouble					
Main	Sub	Details of trouble					
code	code						
H3	11	Content	Sub heater lamp abnormally high temperature soft detection trouble				
		Details	A/D value the fusing sub heater lamp thermistor causes abnormally high temperature (over 230°C).				
		Cause	Sub heater lamp thermistor defect. Control PWB failure. Fusing section connector contact failure.				
		Check and	Check the sub heater lamp blinking with SIM 5-2-2.				
		remedy	When the lamp blinks normally: Check the thermistor and the harness. Check the MCU PWB thermistor input circuit.				
			If lamp lights and stays lit: Check the power circuit and the lamp control circuit on MCU PWB.				
			Clear the display of self-diagnostics with SIM 14.				
H4	00	Content	Main heater lamp abnormally low temperature detection				
		Details	The setup temperature (about 90°C) is not reached within the specified time (about 20sec) from turning on the power.				
			When the temperature of main heater lamp thermistor falls below 140°C in the standby mode or printing.				
			When the temperature of main heater lamp thermistor falls below 50°C in the pre-heat mode.				
		Cause	Main heater lamp thermistor defect				
			Main heater lamp failure				
							Main thermostat failure
		Check	Check the heater lamp blinking with SIM 5-2.				
		and	When the lamp blinks normally:				
		remeay	Check the thermistor and the harness.				
			Check the MCU PWB thermistor input circuit.				
			It lamp lights and stays lit: Check for disconnection of the heater lamp and thermostat.				
			Check the interlock switch.				
			Check the power circuit and the lamp control circuit on MCU PWB.				
			Clear the display of self-diagnostics with SIM 14.				

Trouble				
Main	Sub	-	Details of trouble	
code	code			
H4	01	Content	Sub heater lamp abnormally low temperature detection	
		Details	The setup temperature (about 90°C) is not reached within the specified time (about 20sec) from turning on the power.	
			When the temperature of sub heater thermistor falls below 140°C in the standby mode or printing.	
			When the temperature of sub heater lamp thermistor falls below 50°C in the pre-heat mode.	
		Cause	Sub heater lamp thermistor defect. Sub heater lamp failure.	
			Sub thermostat failure.	
			Control PWB failure.	
		Check and	Check the sub heater lamp blinking with SIM 5-2-2.	
		remedy	When the lamp blinks normally: Check the thermistor and the harness.	
			Check the MCU PWB thermistor input circuit.	
			If lamp lights and stays lit: Check the power circuit and the lamp control circuit on MCU PWB.	
			Clear the display of self-diagnostics with SIM 14.	
	20	Content	Main heater lamp abnormally low temperature detection	
		Details	The setup temperature (about –25°C: Sim 43-1-1) is not reached within the specified time (about 40sec) from turning on the power.	
			A/D value of fusing main thermistor is not reached within the specified temperature. (specified temperature : SIM43-1 (600dpi) -25°C )	
		Cause	Main thermistor defect.	
			Main heater lamp failure.	
			Main thermostat failure.	
		<u>.</u>	Control PWB failure.	
		Check and remedy	Check the main heater lamp blinking with SIM 5-1.	
			When the lamp blinks normally: Check the thermistor and the harness. Check the MCU PWB thermistor input circuit.	
			If lamp lights and stays lit: Check the power circuit and the lamp control circuit on MCU PWB.	
			Clear the display of self-diagnostics with SIM 14.	

Trouble			
code			Details of trouble
Main	Sub		
H4	21	Content	Sub heater lamp abnormally low temperature detection
		Details	The setup temperature (about -25°C: Sim 43-1-1) is not reached within the specified time (about 40sec) from turning on the power. A/D value of fusing sub thermistor is not reached within the specified temperature (specified temperature : SIM43-1 (600dpi) -25°C)
		Cause	Sub thermistor defect. Sub heater lamp failure. Sub thermostat failure.
			Control PWB failure.
		Check and	Check the sub heater lamp blinking with SIM 5-2-2.
		remedy	When the lamp blinks normally: Check the thermistor and the harness.
			Check the MCU PWB thermistor input circuit.
			If lamp lights and stays lit: Check the power circuit and the lamp control circuit on MCU PWB.
			Clear the display of self-diagnostics with SIM 14.
			Check that there is no foreign material in the contact section between the thermistor and the heat roller.
H5	01	Content	10 times of continuous detection of the lower paper exit sensor (POD1) lead edge jam or the upper paper exit sensor (POD2) lead edge jam or the duplex sensor (PPD2) rear edge jam
		Details	After supplying the power, one of the above jams occurs 10 times continuously in printing
			Counting is started on supplying the power. When any one of the above jams occurs, one count is made. When paper entry to the POD1 or POD2 is detected, the counter is cleared.
		Cause	A paper jam (paper rounding, etc.) near the duplex sensor (PPD2) on the fusing unit is not canceled completely. POD1, POD2, PPD2 sensor breakdown or harness connection trouble
			Fusing unit installation failure
		Check and remedy	Check for jam paper in the fusing section. (paper winding, etc.)
			Check the POD1, POD2 or PPD2 sensor. Clear the trouble with SIM 14.

Trouble			
code			Details of trouble
Main	Sub		
code	code		
L1	00	Content	Scanner feed trouble
		Details	Scanner feed is not completed within the specified time.
		Cause	Mirror unit defect.
			Scanner wire disconnection.
			Origin detection sensor error.
			Mirror motor harness abnormality.
		Check and	Check the scanning operation with SIM 1- 1.
		remedy	When the mirror not feeds: Check for disconnection of the scanner wire.
			Check the harness and connector between the mirror motor and the MCU PWB.
			Replace the mirror unit.
			Replace the MCU PWB.
			When the mirror feeds:
			with SiM 1-2.
L3	00	Content	Scanner return trouble
		Details	Scanner return is not completed within the specified time.
			When OC copying with the mirror at the home position, the mirror is not in the
		0	nome position.
		Cause	Mirror Unit defect.
			The scanner wire is disconnected.
			Origin detection sensor error.
		Chook	Mirror motor narness abnormality.
		and	
		remedy	When the mirror fails to return: Check for disconnection of the scanner wire.
			Check the harness and connector between the mirror motor and the MCU PWB.
			Replace the mirror unit.
			Replace the MCU PWB.
			When the mirror feeds: Check the mirror home position sensor with SiM 1-2.
L4	01	Content	Main motor trouble
		Details	The main motor does not rotate.
			The motor lock signal is detected for 1sec or more after the main motor rotates.
			The motor lock signal is detected for 1sec during rotation of the main motor.
		Cause	Main motor defect.
			Main motor connection, harness trouble or disconnection.
			MCU PWB failure.
		Check and	Check the main motor operation with SIM 25-1.
		remedy	Check connection of the main motor
			harness and connector.
			Replace the main motor.
			Replace the MCU PWB.

Trouble				
code		Details of trouble		
Main	Sub			
	11	Content	Shifter motor trouble	
L4		Details	The shifter home position detection signal is not detected when the shifter is operating.	
		Cause	Shifter motor trouble or harnes connection trouble and disconnection.	
			Shifter home position sensor trouble.	
		Check and	Check the shifter motor operation with SIM 3-11.	
		remedy	Check connection of the shifter motor harness/connector.	
			Replace the shifter motor.	
	31	Content	VEM fan trouble	
	51	Details	5 sec after starting the fan motor rotation	
		Details	the motor lock signal is detected for 1 sec.	
			lock signal is detected for 1 sec.	
		Cause	Fan motor trouble.	
			Fan motor connection harness connection trouble or disconnection.	
			MCU PWB trouble.	
		Check and	Use SIM6-2 to check the operation of the fan motor.	
		remedy	Check connection of the fan motor	
			harness and connector.	
			Replace the fan motor.	
			Replace the MCU PWB.	
	32	Content	DCFM or DCFM2 fan trouble	
		Details	b sec after starting the fan motor rotation, the motor lock signal is detected for 1 sec.	
			lock signal detected for 1 sec.	
		Cause	Fan motor trouble.	
			Fan motor connection harness connection trouble or disconnection.	
		Check	Lise SIM6-2 to check the operation of the	
		and	fan motor.	
		remedy	Check connection of the fan motor harness and connector.	
			Replace the fan motor.	
			Replace the MCU PWB.	
	33	Content	VFM2 fan trouble	
		Details	5 sec after starting the fan motor rotation, the motor lock signal is detected for 1 sec.	
			During rotation of the fan motor, the motor lock signal detected for 1 sec.	
		Cause	Fan motor trouble.	
			Fan motor connection harness connection trouble or disconnection.	
			MCU PWB trouble.	
		Check and	Use SIM6-2 to check the operation of the fan motor.	
		remedy	Check connection of the fan motor	
			Replace the fan motor	
			Replace the MCU PWB.	

Trouble				
code		Details of trouble		
Main	Sub			
code	code	-		
L6	10	Content	Polygon motor lock trouble	
		Details	The polygon motor does not rotate.	
			The motor lock signal is detected for 18sec	
			The motor lock signal is detected for 1sec	
		Cause	during rotation of the polygon motor. Polygon motor unit failure	
			Polygon motor connection, harness trouble	
			or disconnection	
			MCU PWB failure	
		Check and	Check the polygon motor operation with SIM 61-1.	
		remedy	Check the connectors and the harness of	
			Portigion motor	
			Replace the MCU PWB.	
L8	10	Content	Power abnormality detection trouble	
		Details	The power status monitoring signal keeps	
			specified time (2sec).	
		Cause	Circuit around the power status monitoring signal (PSSTS) failure	
		Check	Check whether power status monitoring	
		and	signal (PSSTS) on MCU PWB is OPEN or	
		remedy	not.	
			Replace MCU PWB.	
U1	01	Content	FAX battery error	
		Details	control PWB falls.	
		Cause	The SRAM backup battery voltage on FAX control PWB falls.	
		Check	Check voltage of the SRAM back up	
		and remedy	Dattery.	
	02	Contont	PANEL LOW battery error	
	02	Detaile	The voltage of the papel clock function	
		Details	battery falls.	
		Cause	The voltage of the panel clock function battery falls.	
		Check	Check voltage of panel clock function	
		remedy	Beplace the battery	
U2	04	Content	FEPBOM communication error	
	•	Details	EEPROM communication error	
		Cause	EEPROM defect.	
			ICU PWB EEPROM access circuit failure.	
		Check	Check that the EEPROM is properly set.	
		and	Clear trouble with SIM 16.	
		remedy	Replace the MCU PWB.	
	20	Content	Machine speed code data error	
		Details	The machine boot speed information is not identical to the model code speed	
			information	
		Cause	EEPROM defect.	
			SIM operation error.	
		Check	Check for matching of the machine and	
		and	model information setting in SIM26-57.	
		remedy		

Trouble										
code		Details of trouble								
Main	Sub									
code	code	Content BIC communication trouble								
07	00	Details	Error in communication with BIC							
		Details	Error in communication test after turning on the power or canceling SIM.							
		Cause	Connector harness contact trouble or disconnection. RIC control PWB trouble. MCU PWB failure. Malfunction by noises.							
		Check and remedy	Check the communication cable, connectors from the RIC box to the main body.							
U9	00	Content	Operation control PWB communication trouble							
		Details	Communication trouble between MCU and the operation control PWB							
		Cause	Operation control PWB connector disconnection							
			Harness failure of the operation control PWB and the MCU PWB							
		Check and	Check the connectors and the harness of the operation control PWB and MCU PWB.							
		remedy	Check the grounding of the copier. Check ROM on the operation control PWB.							
	80 0		Operation control PWB communication trouble (Protocol)							
		Details	Communication trouble between MCU and the operation control PWB (Protocol error)							
		Cause	Operation control PWB connector disconnection.							
			Harness failure of the operation control. PWB and the MCU PWB.							
		Check and	Check the connectors and the harness of the operation control PWB and MCU PWB.							
	81	Content	Check the grounding of the copier. Operation control PWB communication							
		Details	Communication trouble between MCU and							
		Cause	Operation control PWB connector							
					Harness failure of the operation control PWB and the MCU PWB.					
		Check and	Check the connectors and the harness of the operation control PWB and MCU PWB.							
		remedy	Check the grounding of the copier.							
	82	Content	Operation control PWB communication trouble (Overrun)							
		Details	Communication trouble between MCU and the operation control PWB (Overrun error)							
		Cause	Operation control PWB connector disconnection.							
			Harness failure of the operation control PWB and the MCU PWB.							
		Check	Check the connectors and the harness of							
		remedy	Check the grounding of the copier.							

Irouble								
Main	Sub	- Details of trouble						
Code U9	code 84	Content	Operation control PWB communication					
		Details	Communication trouble between MCU and					
		Cause	Operation control PWB connector					
			disconnection. Harness failure of the operation control					
		Chook	PWB and the MCU PWB.					
		and remedy	the operation control PWB and MCU PWB.					
	88	Content	Operation control PWB communication trouble (Time-out)					
		Details	Communication trouble between MCU and the operation PWB (Time-out error)					
		Cause	Operation control PWB connector					
			Harness failure of the operation control PWB and the MCU PWB.					
		Check and	Check the connectors and the harness of the operation control PWB and MCU PWB.					
		remedy	Check the grounding of the copier.					
	99	Content Details	Operation panel destination error					
		Detailo	destination of the operation panel and the main body.					
		Cause	Erroneous connection the operation panel unit.					
		Chaole	SIM setup error.					
		and remedy	operation panel unit and the MCU. (Sim26-6/22)					
EE	EL	Content	Developer adjustment trouble (Over-toned abnormality)					
		Details	An abnormality occurred in execution of automatic developer adjustment.					
		Causa	Sample data was detected over-toner.					
		Cause	Toner concentration trouble.					
			Developing unit trouble.					
		<u> </u>	MCU PWB failure.					
		and remedy	developer adjustment.					
	EU	Content	Developer adjustment trouble (Under- toned abnormality)					
		Details	An abnormality occurred in execution of automatic developer adjustment.					
		Causa	Sample data was detected under-toner.					
		Cause	Toner concentration trouble.					
			Developing unit trouble.					
1		Ohaal	MCU PWB failure.					
		and remedv	developer adjustment.					
PF	00	Content	PF trouble					
		Details	The copy inhibit command from RIC is received.					
		Cause	Judged by the host.					
1		and	inform to the nost.					
		remedy						

# [8] MAINTENANCE

## 1. Maintenance list (For 26cpm)

# X: Check (Check, clean, replace or adjust according to necessity.)

O: Cleaning ▲: Replace ☆: Lubricate

Unit	Parts	75k	150k	225k	300k	375k	450k	525k	600k	Note
Process	Drum									
	Cleaner blade									
	Seal F/R	×	×	×	×	×	×	×	×	
	Drum frame unit (Toner reception sheet)	×	×		×	×		×	×	Usable for three PM cycles
	MC unit									
	Separation pawl unit	×		×		×		Х		
	Star ring									
DV	Developer									
	Toner filter unit									
	DV blade	×		×		×		Х		
	DV side sheet F	×		×		×		Х		
	DV side sheet R	×		×		×		×		
	Toner sensor	×	×	×	×	×	×	×	×	
Fusing	Upper heat roller	0		0		0		О		
_	Lower heat roller	О	О	О		О	0	0		
	Upper separation pawl	0		0		0		О		
	Upper cleaning pad	×		×		×		×		
	Lower separation pawl	О	О	О		О	0	0		
	Thermistor	0	0	0	О	0	0	О	0	
	Fuser gear	☆		☆		☆		☆		
	Upper heat roller bearing	×		×		×		×		
	Lower fuser bearing	×	×	×		×	×	X		
	Thermistor cleaning pad	×		×		×		×		
	Paper guide	0	0	0	О	0	0	О	0	
Paper feed	Pickup roller	×	×	×	X	×	×	X	X	Changing criteria for parts: 100k
	Paper feeding sheet	×	×	×	X	×	×	X	X	
	Pickup roller and feed roller (RSPF)	×	×	×	×	×	×	×	×	
Transport	Transport roller unit	О		0		0		0		
-	Gear	×	_	Х	-	Х	_	Х	-	
Others	Paper feed rollers	0	0	0	0	0	0	0	0	
	Gears	☆	☆	☆	☆	☆	☆	☆	☆	
	Ozone filter									

# (For 31cpm)

X: Check (Check, clean, replace or adjust according to necessity.)

O: Cleaning ▲: Replace ☆: Lubricate

Unit	Parts	100k	150k	200k	300k	400k	450k	500k	600k	Note
Process	Drum		×				×			
	Cleaner blade		×				×			
	Seal F/R	×	×	Х	×	×	×	Х	×	
	Drum frame unit (Toner reception sheet)	×	×	×		×	×	×		Usable for three PM cycles
	MC unit		×				×			
	Separation pawl unit	×		×		×		×		
	Star ring									
DV	Developer		×				×			
	Toner filter unit		×				×			
	DV blade	×		×		×		×		
	DV side sheet F	×		×		×		×		
	DV side sheet R	×		×		×		×		
	Toner sensor	×	-	×	×	×	_	×	×	
Fusing	Upper heat roller	О		О		0		О		
_	Lower heat roller	О	0	0		0	0	0		
	Upper separation pawl	О		О		О		О		
	Upper cleaning pad	×		×		×		×		
	Lower separation pawl	О	О	0		О	0	0		
	Thermistor	О	0	0	О	0	0	0	О	
	Fuser gear	☆		\$		\$		\$		
	Upper heat roller bearing	×		X		×		X		
	Lower fuser bearing	×	×	×		×	×	×		
	Thermistor cleaning pad	×		×		×		×		
	Paper guide	О	О	О	О	О	0	О	О	
Paper feed	Pickup roller	×	×	×	×	×	×	×	×	Changing criteria for parts: 100k
	Paper feeding sheet	×	×	×	×	×	×	×	×	
	Pickup roller and feed roller (RSPF)	×	×	×	×	×	×	×	×	
Transport	Transport roller unit	О		О		О		О		
-	Gear	×	-	X	-	X	-	X	-	
Others	Paper feed rollers	О	0	0	0	0	0	0	0	
	Gears	\$	☆	☆	☆	☆	☆	☆	☆	
	Ozone filter									

# 2. Details of Maintenance

Unit		F	Parts	\$				
A. Process unit	(1)	Drum						
	(2)	Drum section	a.	Main charger				
	. ,		b.	Cleaning blade				
			c.	Drum frame unit				
			d.	Moguette F/R				
			e.	Separation pawl				
B. Developing unit	(1)	Developer						
	(2)	Toner filter unit						
	(3)	DV side sheet F	/ DV	side sheet R				
	(4)	DV blade						
	(5)	Toner sensor						
C. Fusing section	(1)	Thermostat						
	(2)	Thermistor						
	(3)	Paper guide						
	(4)	Fusing separation pawl (lower)						
	(5)	Lower heat roller Heater lamp Upper cleaning pad Fusing separation pawl (upper)						
	(6)							
	(7)							
	(8)							
	(9)	Upper heat roller						
	(10)	Thermistor clear	Thermistor cleaning pad					
D. Optical section	(1)	CCD unit	1					
	(2)	Lamp unit	a.	Lamp				
			b.	PWB				
			C.	Wire				
			d.	Mirror motor				
E. Paper feed	(1)	Paper feed sole	noid					
section	(2)	Tray sensor PWB						
	(3)	Manual P-in sensor/Manual empty sensor						
	(4)	Multi manual	a.	Paper feed roller/				
		paper feed	<b>I</b> 4	pickup roller				
			D.	Reverse sensor				
			С. d	Separation sheet				
	(5)	Lippor E00	u.	Cluich/solenoid				
	(3)	sheets trav	a.	nickun roller				
		paper feed	h	Separation sheet				
	(6)	Lower 500	a.	Paper feed roller/				
	(-)	sheets trav		pickup roller				
		paper feed	b.	Separation sheet				
			C.	Lift up unit				
			d.	Transport clutch				
			e.	Paper feed clutch				
			f.	Transport clutch				
			g.	Solenoid				
			h.	Sensor PWB				
F. Side door unit	(1)	Transport roller	unit					
	(2)	Transport roller						
	(3)	DUP transport r	oller					
	(4)	DUP motor						
G. 1st paper exit unit	(1)	Cooling fan						
	(2)	Transport/exit ro	ller					
H. Laser unit	(1)	LSU						
I. Power unit	(1)	Power source						
J. PWB	(1)	Option CN PWE	3					
	(2)	IMC PWB						
	(3)	MCU PWB						
	(4)	Motherboard PV	VB					
	(5)	Second interfac	e PV	VB				
K Ozone filter	1							

Unit	Parts							
L. Drive section	(1) DUP reverse motor							
	(2)	Main drive motor						
	(3)	) Toner motor						
	(4) PS transport clutch							
	(5)	(5) Paper feed clutch						
	(6) Drive unit							
	(7)	Lift up motor						
M. Transport section	(1)	Transport roller						
N. Operation section	(1)	Operation section						
	(2)	OPU PWB						
	(3)	Key PWB						
	(4)	LCD unit						
O. Switch	(1)	Power switch						
P. RSPF	(1)	Document tray	a.	Document tray unit				
		section	b.	Document length				
				sensor				
			c.	Document width				
				resistor PWB				
	(2)	Paper feed unit	a.	Paper feed clutch				
		section	b.	Pickup roller				
			C.	Paper feed roller				
			d.	Paper feed unit				
			e.	Separation sheet				
	(3)		f.	Sensor				
		Transport	a.	Transport unit				
		section	b.	PS clutch				
			c.	Pressure release				
				solenoid				
			d.	RSPF motor				
			e.	Transport roller				
			f.	Roller				
			g.	Sensor				
	(4)		h.	Roller				
			i.	Koller				
		Base section	a.	Interface PWB				
			b.	Solenoid				
			С.	Book sensor				
			d.	Sensor				

#### A. Process unit

(Note for servicing the OPC drums)

1. Prevention of oily dirt attachment

Note:

- Be careful not to attach fingerprints or oily dirt on the OPC drum surface. (Keep the unit away from oils and dust.)
- When replacing the OPC drum, cover the OPC drum with the protection sheet and hold the protection sheet.

If it is required to hold the OPC drum directly, use enough care not to touch the cleaning blade area, 5mm inside from both edges of the OPC drum. (If a fingerprint or oily dirt is attached to the cleaning blade area of the OPC drum, the cleaning blade may flip.)



#### [Countermeasures]

If a fingerprint is attached to the OPC drum surface erroneously, perform the following countermeasures.

- 1) Use dry cloth to clean and remove the dirt.
- 2) Apply KYNAR to prevent blade flip.

#### [Check method]

Check to confirm that the OPC drum is free from fingerprints or oily dirt and that the cleaning blade is completely cleaned by the following method.

 Make a print of a half tone image on all the surface of A4 (11" x 8.5") paper, and check the printed paper for any abnormality in the image.

#### 2. Prior exposure prevention

Note:

- Avoid servicing in a place where there is strong light.
- Do not expose the unit to light for a long time.
- Cover the OPC drum with light-blocking material. (When using paper, use about 10 sheets of paper to block light.)

[Countermeasures]

If the OPC drum is erroneously exposed to light too much (prior exposure), perform the following countermeasures.

- Print half tone images on the whole surface of A4 (11" x 8.5") paper, and check to confirm that there is no irregular density area in the previously exposed section.
- Damages due to prior exposure may be recovered by keeping the OPC drum for several hours. If, however, image are not recovered, replace the OPC drum.

#### (1) Drum



Note: When installing the process unit in the main unit after replacing the drum, process unit may not be able to install by reason of the drum drive coupling position.

In this case, rotate the drum about 45 degrees and install again.

#### (2) Drum section

a. Main charger



b. Cleaning blade



c. Drum frame unit





Note: If it disturbs the blade movement, replace it and attach new one.

#### e. Separation pawl

Disassembly\* Hold the tip of the separation pawl and remove it.



Assembly\* Press the center of the separation pawl and install it.





- B. Developing section
- (1) Developer



Rotate the MG roller to discharge developer.





(2) Toner filter unit With the guide AS (cover) removed, replace it.





[DV side sheet F/ DV side sheet R attachment reference]



#### (4) DV blade



#### [DV blade attachment reference]



#### (5) Toner sensor

- Execution of cleaning the sensor must be made after discharging used DV in DV replacement.
- Without removing the MG roller, use waste cloth to remove toner from the sensor surface in the arrow direction.



• Clean the sensor only after removing used DV when replacing DV.

## C. Fusing section





## (1) Thermostat

Note: When securing the lamp harness and the thermostat, the tightening torque of the screw (4 positions) is 6-9 kgs.



(2) Thermistor



(3) Paper guide



(4) Fusing separation pawl (lower)



(5) Lower heat roller







(7) Upper cleaning pad





(8) Fusing separation pawl (upper)



(9) Upper heat roller





(10) Thermistor cleaning pad

















#### d. Mirror motor



## E. Paper feed section



A	Paper feed roller
В	Pickup roller
С	Separation sheet

(1) Paper feed solenoid



(2) Tray sensor PWB



(3) Manual P-in sensor/Manual empty sensor



- (4) Multi manual paper feed
- a. Paper feed roller/pickup roller



c. Separation sheet



Installation \* Install so that the cam transmit arm (1) comes under the roller arm (2).



b. Reverse sensor





\* Slightly apply grease GP501MR (UKOG-0012QSZZ) around the axis. One rice grain for each.

#### d. Clutch/solenoid

(Clutch)





(Solenoid)









## (5) Upper 500 sheets tray paper feed

a. Paper feed roller/pickup roller







Note: With the toner cartridge installed, do not tilt or shake the developer cartridge.







\* When replacing, be careful not to adhere conduction grease (black) to the drive section.

Slightly apply grease GE676 (UKOG-0013QSZZ) to the drum boss.



b. Separation sheet





1



- \* Slightly apply grease GP501MR (UKOG-0012QSZZ) around the axis. One rice grain for each. Grease should not come out when assembling.
- (6) Lower 500 sheets tray paper feed
- a. Paper feed roller/pickup roller





b. Separation sheet







\* Slightly apply grease GP501MR (UKOG-0012QSZZ) around the axis. One rice grain for each.

Grease should not come out when assembling.







#### e. Paper feed clutch



#### f. Transport clutch





g. Solenoid



- h. Sensor PWB
- F. Side door unit
- (1) Transport roller unit



\* Check that two springs are securely inserted into the transfer roller unit bosses.







## (3) DUP transport roller





(4) DUP motor























Note: Check to confirm that the solenoid shaft is in the gate bracket, and fix with the screw.



#### H. Laser unit

Note: Do not disassemble the LSU unit.

## (1) LSU

- 1) Turn OFF the machine power, and disconnect the power plug from the power outlet.
- 2) Remove the left cabinet and exit tray.
- 3) Disconnect the LSU connector, and remove the securing screws to remove the LSU.







- I. Power unit
- (1) Power source







- J. PWB
- (1) Option CN PWB







## (3) MCU PWB





(4) Motherboard PWB

























## L. Drive section

(1) DUP reverse motor



## (2) Main drive motor



(3) Toner motor



## (4) PS transport clutch







## (6) Drive unit



Drive unit (Grease application part)



## (7) Lift up motor





- M. Transport section
- (1) Transport roller







- N. Operation section
- (1) Operation section





(2) OPU PWB



(3) Key PWB











## P. RSPF

- (1) Document tray section
- a. Document tray unit







b. Document length sensor



(2) Paper feed unit section

a. Paper feed clutch



b. Pickup roller





#### c. Document width resistor PWB











d. Paper feed unit





e. Separation sheet







## (3) Transport section

## a. Transport unit





3 (1)

c. Pressure release solenoid



## d. RSPF motor



b. PS clutch

f. Roller



<Note for disassembling the motor>

The motor is positioned by the jig. Use the mark when assembling it to the original position.

#### e. Transport roller














### i. Roller







b. Solenoid





c. Book sensor





## 3. Other related items

### A. Counter clear

Item	SIM	Remarks
Maintenance cycle setting	SIM 21-1	
Jam/trouble counter clear	SIM 24-1	
Paper feed counter clear	SIM 24-2	
Scan/Stapler counter clear	SIM 24-3	
Maintenance counter clear	SIM 24-4	*
Developing counter clear	SIM 24-5	After execution of SIM25-2,
		this counter is cleared.
Copy counter clear	SIM 24-6	
Drum counter clear	SIM 24-7	At drum replacement
Printer, IMC, Duplex, other	SIM 24-9	
counter clear		
FAX counter clear	SIM 24-10	
Scanner mode counter clear	SIM 24-15	

\* 31 sheet model: When maintenance message is displayed, replace consumption part reaching the number of sheets of maintenance, then clear the replaced part's counter only.

## [9] FIRMWARE UPDATE

## 1. Firmware update procedure

### (Necessary items for update)

- A Personal computer
- B RS232C cross cable (D-sub 9pin to D-sub 9pin, or D-sub 25pin to D-sub 9pin)
- C Software for version-up

### (Target PWB)

- 1 MCU PWB
- 2 Panel PWB
- 3 IMC PWB
- 4 Finisher PWB



### Prepare following files necessary for program update

- Maintenance software: maintenance.exe
- Andromeda module file: ProcModelR.mdl
- Maintenance tool driver: SFZEJENU.inf

# A. Firmware update method (for Copier, and fax firm)

Following operational procedures are for:

- Copier firm
- fax firm
- 1) Make sure copier is off, and connect it to PC with download cable beforehand.
- 2) Start up the maintenance program on PC. Select the model name from the model selection dialogue box.

🔆 Select Model		×
	Select( <u>S</u> )	Cancel

 Make sure only "Printer Control Board" tree is visible under "Simulation Command List".

Integration Maintenance Program	_ 🗆 ×
Field Option() Help(H)  Field Option() Help(H)  Finder Control Board  Finder Control Board	
The copier is not turned on.	Port [COM1] Baud Rate [38400bps]

- 4) Turn on the copier. The machine starts up in the download mode.
- Additional tree will be visible when downloading maintenance program on PC.
- \* Make sure to start up maintenance program before turn on the machine.

Integration Maintenance Program	×
File(E) Option(0) Help(H)	
Simulation Command List     Special(Copier)     FAX     Printer Control Board     Ready to sta     when these t	rt download process trees appear.
Service Man Mode	Port [COM1] Baud Rate [38400bps]

6) When downloading copier firm, expand "Special(Copier)", and double-click on "All Data areas Download".



7) Select download file(\*.dat), and press "Open" button.

Select Downloa	d File				? ×
Look jn:	andromeda		•	- È 💣	
History	Amd8598JPN				
Desktop					
My Documents					
My Computer					
	File <u>n</u> ame:	Amd8598JPN		•	<u>O</u> pen
My Network P	Files of type:	Download File(*.)	dat)	•	Cancel

8) Download procedure starts automatically.



- 9) Notice message "Download is complete. Check the copier panel to make sure the download is complete." will appear on PC.
- 10) Close the maintenance program, and turn off the copier. Turn on the copier again after pulling the plug.
- This is the end of download procedure.
- \* It is possible that download process somehow went wrong if the copier does not start up properly. In that case, start up the copier and maintenance program in download mode by repeating the step 1)-5) again. And then, Expand "Special", and double-click on "Confirm Error Status". If any of the message besides "No error has been occurred" appears, it means that download is incomplete, so please try again.

## B. Others (Troubleshooting)

Followings are the error possibly occur during the download process and troubleshooting method.

No	Warning/error message	Detail
1	Incorrect destination. Continue with the	Destination of download file and copier doesn't match.
	download process?	Possible to select either continue or cancel the job.
		[TROUBLESHOOTING]
		To change destination, select "Yes". If not, select "No" and cancel download process.
2	Incorrect download file.	Invalid download file for the machine is selected, or the file format is not correct.
		[TROUBLESHOOTING]
		Confirm the download file. Possibly the improper download file is selected.
3	No downloadable data included.	Unable to find appropriate data in selected download file.
		[TROUBLESHOOTING]
		Confirm the download file. Possibly the improper download file is selected.
4	This option not available.	Download procedure is executed on uninstalled optional kit.
		[TROUBLESHOOTING]
		Confirm installed optional kit.
		Confirm the download file. Possibly the improper download file is selected.
5	The data size exceeds the Flash ROM size.	Panel flash ROM size is not enough to execute download procedure.
	Try again with the appropriate size of data.	[TROUBLESHOOTING]
		Confirm the download file. Possibly the improper download file is selected.
		Exchange the flash ROM to the one which has more capacity.
6	Time out error.	Transmission error
		Unable to receive data from the machine among the certain period of time.
		[TROUBLESHOOTING]
		Restart maintenance program after confirming communication port or communication cable.
7	Communication (incoming) error.	Incorrect download procedure.
		The machine did not proceed download procedure correctly.
		[TROUBLESHOOTING]
		Restart maintenance program after confirming communication port or communication cable.
		Make sure the communication device of PC(either COM or parallel) is under right condition.
8	Checksum error.	Transmission error
		The check sum value of the transmission data is mismatch.
		[TROUBLESHOOTING]
		Restart maintenance program after confirming communication device of PC (either COM or
		parallel) is under right condition.
9	Error during the download process. Error	Download data file operation error.
	code: 0xXXXXXXXX	[TROUBLESHOOTING]
		Restart maintenance program after confirming the selected download file is not abnormal and
		not using other application.
10	An error. [0xXXXXXXX]	The error occurred except the above errors.
		[TROUBLESHOOTING]
		Restart maintenance program after confirming communication device of PC(either COM or
		parallel) is under right condition.

## [10] ELECTRICAL SECTION

- 1. Block diagram
- A. SYSTEM BLOCK DIAGRAM



## 2. Actual wiring chart

### A. MCU - Panel unit, Optical base plate sensor section





### B. MCU - Optical base plate 2, OP I/F PWB, 1st paper exit unit, 2nd paper exit unit



### D. 2nd tray unit section



### E. Fusing unit, Power supply unit section







## 3. Signal list

Signal name	Nama	Eurotian/Operation	Connec	Connector level		Din No	DWP nome	NOTE
Signal name	Name	Function/Operation	"L"	"H"	No.	FILLINO.	FVD hame	NOTE
CL	Copy lamp	Controls ON/OFF of the copy lamp.	ON	OFF	CN26	3	MCU	
CLH	RSPF clutch	Controls ON/OFF of the RSPF paper feed roller.	ON	OFF	CN5	13	RSPF interface	
COVER	RSPF cover open/close detection	Detects open/close of the RSPF cover.	OPEN	CLOSE	CN5	2	RSPF interface	
CSS1	Tray 1 installation detection	Detects installation of	NO	YES	CN15	22	MCU	
CSS2	Tray 2 installation detection	Detects installation of tray 2.	NO	YES	CN7	1	Standard tray I/F	
CSS3	Tray 3 installation detection	Detects installation of tray 3.	NO	YES	CN7	1	Option tray I/F	
CSS4	Tray 4 installation detection	Detects installation of tray 4.	NO	YES	CN4	8	Option tray I/F	
DPX	Duplex motor	Controls the duplex motor.	I	-	CN1	2,3,4,5	MCU	
DRS2	Door open/close detection (Tray 2)	Detects door open/close.	OPEN	CLOSE	CN8	5	Standard tray I/F	
DRS3	Door open/close detection (Tray 3)	Detects door open/close.	OPEN	CLOSE	CN8	5	Option tray I/F	
DRS4	Door open/close detection (Tray 4)	Detects door open/close.	OPEN	CLOSE	CN4	5	Option tray I/F	
DUP2SEN	DUP2 paper delivery sensor	Detects paper delivery in the reverse path.	YES	NO	CN15	12	MCU	
EHUD	Humidity sensor	Senses the humidity.	-	-	CN503	2	MCU	Analog detection
ERTH	Temperature sensor	Senses the temperature.	-	-	CN503	4	MCU	Analog detection
GSOL	Gate solenoid	Reverses the paper exit gate in ON operation.	ON	OFF	CN4	2	RSPF interface	
HLOUT1	Heater lamp main	Turns ON/OFF the heater lamp main.	OFF	ON	CN10	10	MCU	
HLOUT2	Heater lamp sub	Turns ON/OFF the heater lamp sub.	OFF	ON	CN10	12	MCU	
HPEMPTY	Manual feed paper presence detection	Detects presence of paper for manual paper feed.	YES	NO	CN15	16	MCU	
HPIN	Manual feed paper entry detection	Detects paper entry for manual feed.	NO	YES	CN15	26	MCU	
HPSIZE1	Manual feed paper length detection	Detects the length of manual feed paper.	NO	YES	CN15	17	MCU	
HPSIZE2	Manual feed paper size detection (Longitudinal direction)	Detects the size of manual feed paper. (longitudinal direction)	NO	YES	CN15	23	MCU	
HPSOL	Manual paper feed solenoid	Controls the manual paper feed solenoid.	ON	OFF	CN15	7	MCU	
HPTRAY1	Manual paper feed tray	Detects the length of manual feed tray paper	LONG	SHORT	CN15	9	MCU	
HPTRAY2	Manual paper feed tray	Detects the length of manual feed tray paper.	SHORT	LONG	CN15	13	MCU	
HPWS	Manual feed paper width detection	Detects the width of manual feed paper.	_	-	CN15	31	MCU	
KEEPSOL	Right paper exit gate	Drives the right paper	ON	OFF	CN17	8,9	MCU	
LUD1H	Lift-up motor upper limit detection	Detects the upper limit of the lift-up motor.	Not detected	Detected	CN14	8	MCU	
LUD2	Lift-up motor upper limit detection (Tray 2)	Detects the upper limit of the lift-up motor.	Not detected	Detected	CN8	6	Standard tray I/F	
LUD3	Lift-up motor upper limit detection (Trav 3)	Detects the upper limit of the lift-up motor.	Not detected	Detected	CN8	6	Option tray	
LUD4	Lift-up motor upper limit detection (Tray 4)	Detects the upper limit of the lift-up motor	Not	Detected	CN4	6	Option tray	
LUM1H	Lift-up motor	Drives the lift plate of the paper tray.	OFF	ON	CN15	6	MCU	

Signal name	Namo	Eurotion/Operation	Connec	ctor level	Connector	Din No	DW/R name	NOTE
Signal name	Name	Function/Operation	"L"	"H"	No.	FILLINO.	FWD hame	NOTE
LUM2D	Lift-up motor	Drives the lift plate of the paper tray.	OFF	ON	CN1	1	Standard tray I/F	
LUM3D	Lift-up motor	Drives the lift plate of the paper tray.	OFF	ON	CN1	1	Option tray	
LUM4D	Lift-up motor	Drives the lift plate of the paper tray.	OFF	ON	CN4	14	Option tray	
МНР	Mirror home position sensor	Corrects the initial position of the scanner.	Other than home position.	Home position	CN23	33	MCU	
MIRMOD	Mirror motor	Controls the mirror operation.	_	-	CN906	1,2,3,4	OP I/F PWB	
MMD	Main motor	Controls the main motor.	ON	OFF	IC215	3	MCU	
MMRDY	Main motor lock	Detects lock of the main motor.	Rotation	Lock	IC215	2	MCU	
OCCOVER	OC cover open/close detection	Detects open/close of the OC cover.	OPEN	CLOSE	CN23	29	MCU	
OZNFANOUT	Ozone fan	Controls the ozone fan.	OFF	ON	CN502	10	MCU	
PAP1H	Paper pass sensor (Trav 1)	Detects paper pass.	YES	NO	CN14	6	MCU	
PAP2	Paper pass sensor (Tray 2)	Detects paper pass.	YES	NO	CN8	4	Standard	
		····· [ ··· [ ····		_			tray I/F	
PAP3	Paper pass sensor (Tray 3)	Detects paper pass.	YES	NO	CN8	4	Option tray I/F	
PAP4	Paper pass sensor (Tray 4)	Detects paper pass.	YES	NO	CN4	4	Option tray I/F	
PAPER	Paper entry sensor	Detects paper entry.	YES	NO	CN5	18	SPF interface	
PCL1H	Paper feed clutch (Tray 1)	Controls ON/OFF of the paper feed roller.	ON	OFF	CN15	2	MCU	
PCL2	Paper feed clutch (Tray 2)	Controls ON/OFF of the paper feed roller.	ON	OFF	CN3	1	Standard tray I/F	
PCL3	Paper feed clutch (Tray 3)	Controls ON/OFF of the paper feed roller.	ON	OFF	CN3	1	Option tray I/F	
PCL4	Paper feed clutch (Tray 4)	Controls ON/OFF of the paper feed roller.	ON	OFF	CN4	10	Option tray I/F	
PCS1H	Paper feed solenoid (Tray 1)	Controls ON/OFF of the paper feed roller.	ON	OFF	CN14	2	MCU	
PCS2	Paper feed solenoid (Tray 2)	Controls ON/OFF of the paper feed roller.	ON	OFF	CN8	7	Standard tray I/F	
PCS3	Paper feed solenoid (Tray 3)	Controls ON/OFF of the paper feed roller.	ON	OFF	CN8	7	Option tray I/F	
PCS4	Paper feed solenoid (Tray 4)	Controls ON/OFF of the paper feed roller.	ON	OFF	CN4	12	Option tray I/F	
PDPX	Duplex sensor	Detects paper presence for duplex.	YES	NO	CN19	3	MCU	
PFULL2	No. 2 paper exit full sensor	Detects paper full in the No. 2 paper exit unit.	YES	NO	CN21	5	MCU	
PFULL2_R	Right paper exit full sensor	Detects paper full in the right paper exit unit.	YES	NO	CN17	5	MCU	
PGSOL	Paper exit gate solenoid	Controls the paper exit gate.	ON	OFF	CN22	2,3	MCU	
PIN	Paper entry sensor	Detects paper entry.	YES	NO	CN14	4	MCU	
POUT1	No. 1 paper exit sensor	Detects paper exit of the No. 1 paper exit unit.	NO	YES	CN32	6	MCU	
POUT2	No. 2 paper exit sensor	Detects paper exit of the No. 2 paper exit unit.	YES	NO	CN21	2	MCU	
POUT2_R	Right paper exit sensor	Detects paper exit of the right paper exit unit.	YES	NO	CN17	2	MCU	
POUTCOV	Paper exit cover open/close detection	Detects open/close of the paper exit cover.	OPEN	CLOSE	CN21	10	MCU	
POUTFANOUT	Paper exit cooling fan	Cools the fusina unit.	OFF	ON	CN504	3.6	MCU	
POUTFANRDY	Paper exit cooling fan lock detection	Detects lock of the paper exit cooling fan.	Rotation	Lock	CN504	2,5	MCU	
PPD2	Paper pass sensor (Tray 2)	Detects paper pass.	YES	NO	CN8	2	Standard tray I/F	

			Connec	tor level	Connector			
Signal name	Name	Function/Operation	"L"	"H"	No.	Pin No.	PWB name	NOTE
PPD3	Paper pass sensor (Tray 3)	Detects paper pass.	YES	NO	CN8	2	Option tray I/F	
PPD4	Paper pass sensor (Tray 4)	Detects paper pass.	YES	NO	CN4	2	Option tray I/F	
PREMSOL	Paper separation solenoid	Controls the paper separation solenoid.	ON	OFF	CN11	2	MCU	
PSFANOUT	PS fan	Drives the PS fan.	OFF	ON	CN29	3,6	MCU	
PSFANRDY	PS fan lock detection	Detects lock of the PS fan.	Rotation	Lock	CN29	2,5	MCU	
PSOL	PS solenoid	Controls ON/OFF of the PS roller.	ON	OFF	CN5	11	SPF interface	
PSRSOL	Resist roller solenoid	Controls the resist roller.	ON	OFF	CN15	4	MCU	
RSOL	Reverse solenoid	Reverses the paper exit gate in ON operation.	ON	OFF	CN5	15	SPF interface PWB	
RTH1	Thermister 1	Detects the fusing temperature.	-	-	CN19	4	MCU	
RTH2	Thermister 2	Detects the fusing temperature.	-	-	CN19	6	MCU	
SFTD	Shifter motor	Offsets paper.	-	_	CN2	3,4,5,6	MCU	
SFTHP	Shifter home position sensor	Detects the home position of the shifter.	Other than home position.	Home position	CN32	4	MCU	
SPFOPEN	SPF cover open/close sensor	Detects open/close of the SPF cover.	OPEN	CLOSE	CN5	24	SPF interface	
SPFOUT	SPF paper exit sensor	Detects paper exit of the SPF.	YES	NO	CN3	1	SPF interface	
SPFWS	SPF document width detection	Detects SFP documents.	-	-	CN2	9	SPF interface	Analog detection
TFANOUT	Fusing fan	Drives the fusing fan.	OFF	ON	CN32	10,12	MCU	
TFANRDY	Fusing fan lock detection	Detects lock of the fusing fan.	Rotation	Lock	CN32	14,16	MCU	
TMD	Toner motor	Controls the toner motor.	-	-	CN3	1,2	MCU	
TONER	Toner sensor	Detects the toner density.	-	-	CN502	6	MCU	Analog detection
TRCL2	Vertical transport clutch	Controls ON/OFF of the vertical transport roller.	ON	OFF	CN2	1	Standard tray I/F	
TRCL3	Vertical transport clutch	Controls ON/OFF of the vertical transport clutch.	ON	OFF	CN2	1	Option tray I/F	
WO	Paper empty sensor	Detects paper empty.	YES	NO	CN5	1	SPF interface	

## LEAD-FREE SOLDER

The PWB's of this model employs lead-free solder. The "LF" marks indicated on the PWB's and the Service Manual mean "Lead-Free" solder. The alphabet following the LF mark shows the kind of lead-free solder.

#### Example:



<Solder composition code of lead-free solder>

Solder composition	Solder composition code
Sn- <u>A</u> g-Cu	а
Sn-Ag- <u>B</u> i Sn-Ag- <u>B</u> i-Cu	b
Sn- <u>Z</u> n-Bi	Z
Sn-In-Ag-Bi	i
Sn-Cu- <u>N</u> i	n
Sn-Ag- <u>S</u> b	S
Bi-Sn-Ag-₽ Bi-Sn-Ag	р

### (1) NOTE FOR THE USE OF LEAD-FREE SOLDER THREAD

When repairing a lead-free solder PWB, use lead-free solder thread.

Never use conventional lead solder thread, which may cause a breakdown or an accident.

Since the melting point of lead-free solder thread is about 40°C higher than that of conventional lead solder thread, the use of the exclusive-use soldering iron is recommendable.

### (2) NOTE FOR SOLDERING WORK

Since the melting point of lead-free solder is about 220°C, which is about 40°C higher than that of conventional lead solder, and its soldering capacity is inferior to conventional one, it is apt to keep the soldering iron in contact with the PWB for longer time. This may cause land separation or may exceed the heat-resistive temperature of components. Use enough care to separate the soldering iron from the PWB when completion of soldering is confirmed.

Since lead-free solder includes a greater quantity of tin, the iron tip may corrode easily. Turn ON/OFF the soldering iron power frequently. If different-kind solder remains on the soldering iron tip, it is melted together with lead-free solder. To avoid this, clean the soldering iron

tip after completion of soldering work.

If the soldering iron tip is discolored black during soldering work, clean and file the tip with steel wool or a fine filer.

# SHARP PARTS GUIDE

## CODE:00ZMXM310P002

# デジタル複合機 Digital Multifunction System

# MX-M260/N/FG/FP MX-M310/N/FG/FP AR-5726/5731

MX-VR10 (Except North America, Japan, Argentina)

(North America, Japan, Argentina is standard)

MODEL MX-TR11 (Japan is standard)

**MX-RP10** 

### CONTENTS

- 1 外装部 1(Exteriors 1)
- 2 外装部 2(Exteriors 2)
- 3 操作部 (Operation panel unit)
- 4 フレーム部 (Frame section)
- 5 איבי (Lamp unit)
- 6 光学フレーム 1(Optical frame 1)
- 7 光学フレーム 2(Optical frame 2)
- 8 中間フレーム部 (Middle frame section)
- 9 550 カセットユニット (550 cassette unit)
- 10 給紙部 (Paper feed section)
- 11 搬送部 (Paper transfer section)
- 12 שורי א' זבייא (Side door unit)
- 13 マルチ手差しトレイユニット (Multi manual paper feed tray unit)
- 14 手差し給紙エット (Multi manual paper feed unit)
- 15 DV ב=ット (DV unit)
- 16 7° นีชมีนายาง (Process unit)
- 17 定着ユニット 1(Fusing unit 1)
- 18 定着ユニット 2(Fusing unit 2)
- 19 駆動ユニット (Drive unit)
- 20 第一排紙ユニット 1(1st delivery paper unit 1)
- 21) 第一排紙ュニット 2(1st delivery paper unit 2)
- 22 基板部 (PWB section)
- 23 後フレーム部 (Rear frame section)

- 24 2nd 外装 (2nd exteriors)
- 25 2nd 550 カセットユニット (2nd 550 cassette unit)
- 26 2nd 給紙部 (2nd paper feed section)
- 27 2nd 搬送部 (2nd paper transfer section)
- 28 2nd 駆動部 (2nd drive section)
- 29 יוסא (Lift up unit)
- 30 MX-RP10 外装部 1(MX-RP10 RSPF Exteriors 1)
- 31 MX-RP10 外装部 2 (MX-RP10 RSPF Exteriors 2)
- 32 MX-RP10 給紙部 (MX-RP10 RSPF Paper feeding section)
- ③ MX-RP10 搬送部 1 (MX-RP10 RSPF Transport section 1)
- [34] MX-RP10 搬送部 2 (MX-RP10 RSPF Transport section 2)
- 35 MX-TR11 第二排紙ユニット (MX-TR11 2nd delivery paper unit)
- 36 MX-TR11 ジョプセパレーターユニット (MX-TR11 Job-separater unit)
- ③ 梱包及び付属品 (Packing material & accessories)
- 38 MX-VR10 梱包及び付属品 (MX-VR10 Packing material & accessories
- 39 MX-RP10 梱包及び付属品 (MX-RP10 Packing material & accessories)
- MX-TR11 梱包及び付属品 (MX-TR11 Packing material & accessories)

# SHARP CORPORATION

This document has been published to be used for after sales service only. The contents are subject to change without notice. <修正パーツガイド活用時の注意>

・部品の互換性は下表の通り、No1~6で表現しております。

1	Б	场	性	>
`	ᅭ	1哭	11	/

1	新・旧の互換性有り。
2	新の代わりに旧は使用可。 旧の代わりに新は使用不可。
3	新の代わりに旧は使用不可。 旧の代わりに新は使用可。
4	新・旧の互換性無。
5	旧(a, b, c…) どうしー対、又は 新(a, b, c…) どうしー対で、 互換性有。
6	その他

・部品の追加・変更・廃止・員数の増減等の変更は下表のマークで表現しております。

〈変更	区分〉
新規追加	$\mathbb{N}$
変 更	$\mathbf{\mathfrak{O}}$
廃 止	$\square$
員数増・その他	₹
員数減	*
パーツ修正	

・変更時期のランニングチェンジは、R/Cとして記載しています。

	〈変更時期〉
R / C	ランニングチェンジ

<Note for use of the revised Parts Guide>

### • Interchangeability of parts is expressed by No1~6 as shown in the table below.

<Interchangeability>

1	Interchangeable.
2	Current type can be used in place of new type. New type cannot be used in place of current type.
3	Current type cannot be used in place of new type. New type can be used in place of current type.
4	Not interchangeable.
5	Interchangeable if replaced with same types of releted parts in use.
6	Others.

• New & Addition, Change, Abolition, and Quantity change are expressed with the marks shown in the table below.

<change division="" of="">         w &amp; Addition       N         ange       ♥         blition       ⊠         antity (increase) /Others       ☆         antity (decrease)       ★         rection       ©</change>			
New & Addition	$\square$		
Change	Č.		
Abolition	$\boxtimes$		
Q'uantity (increase) /Others	$\Delta$		
Q'uantity (decrease)	*		
Correction			

• Running Change of Effective Time is expressed as R/C.

<effective time=""></effective>									
R / C	Running Change								

補修部品のランク付 市場における補修部品の在庫管理が、適正に運営出来る手助けとなることを、目的とします。

- Aランク : メンテナンスパーツ、メンテナンスパーツには入っていないがメンテナンスパーツに近い消耗パーツ。
- Bランク : 性能・機能パーツ (センサー、クラッチ等の電気パーツ)、消耗パーツ。
- Eランク :基板含むユニットパーツ。
- Dランク : 整備パーツ (外装、パッキング、同梱パーツ)。
- Cランク : 上記ランク以外のパーツ(基板の子部品を除いたもの)。

### DEFINITION

- Rank A : Maintenance parts, and consumable parts which are not included in but closely related to maintenance parts
- Rank B : Performance/function parts (sensors, clutches, and other electrical parts), consumable parts
- Rank E : Unit parts including PWB
- Rank D : Preparation parts (External fitting, packing, parts packed together)
- Rank C : Parts other than the above (excluding sub components of PWB)

### 安全性・信頼性確保のため部品は、必ず正規のものをご使用下さい。

▲印の商品は、安全上重要な部品です。交換をする時は、安全及び性能維持のため必ず指定の部品をご使用下さい。

Because parts marked with " $\Delta$ " is indispensable for the machine safety maintenance and operation, it must be replaced with the parts specific to the product specification.

- 当モデルのサービス資料には、この資料以外にサービスマニュアル(回路図含む)があります。合わせてご利用下さい。
- O Other than this Parts Guide, please refer to documents Service Manual (including Circuit Diagram) of this model.
- Please use the 13 digit code described in the right hand corner of front cover of the document, when you place an order.
- For U.S. only-Use order codes provided in advertising literature. Do not order from parts department.

▲:定期交換が必要なメンテナンスパーツ

▲ : Maintenance parts for which the periodic replacement is necessary.

### 1 外装部 1(Exteriors 1)

		Inter- PF	RICE R	RANK	NEW/	PART			Effective
NO.	PARTS CODE	change E	Ex.	Ja. M	MARK	RANK	DESCRIPTION	TR No.	time
1	GCAB-0081QST1		AL	EB		D	Optical left cabinet 光学左キャビ		
2	GCAB-0080QST1	A	AM	EG		D	Optical right cabinet 光学右キャビ		
2	CFiX-0013QS11	A	AM	EG		D	Glass fixing plate (Except Japan) ガラス押え		
3	CF i X-0013QS12		AL	EB		D	Glass fixing plate (Japan) ガラス押え		
4	PSHEZ0220QSZ1	l A	AK	DX		С	Shading sheet ジェーデ・ィング・シート		
5	LX-BZ0082QSPZ	l A	AA	DD		С	Screw(3×8) Ľ λ		
6	GCAB-0084QST1	l A	AS	EQ		D	Rear cabinet upper 後神ビ上		
7	CG i DM0 1 1 6 QS 0 5	l A	AK	DX		С	OR guide unit (Except Japan) OR ガイドユニット		
	CG i DM0 1 1 6 QS 0 4	A	AH	DX		С	OR guide unit (Japan) OR ガイドユニット		
				DV		р	OC fixing glass		
0	LFIX-0011QSAC		An			Б	(Except North America, Japan, Argentina) OC ガラス押え		
11	PGLSP0003QSZZ	E	BA	FX		В	Table glass ริ-ว ้ แก่ รุง		
17		,	лц	DV			SPF fixing glass		
17	LFIX-0012Q3AC		АП			D	[MX-RP10,North America,Japan,Argentina] SPF ガラス押え		
18	PSHE702210577	1	۸C	ы		C	White revise sheet LPD		
10	1 3112202210322	· · · · · · · · · · · · · · · · · · ·		03		Ŭ	[MX-RP10,North America,Japan,Argentina] 白補正シート LPD		
10	RCI \$800040\$77		^ Y	FG		В	SPF slit glass		
19	FGE3F0004Q322		~~	10		Б	[MX-RP10,North America,Japan,Argentina] SPF スリットガラス		
20	PSHE702070577		AC	ы		C	SPF glass sheet F		
20	1 3112 2 2 0 7 0 3 2 2			00		Ŭ	[MX-RP10,North America,Japan,Argentina] SPF ガラスシート F		
21	PSHE702220877	A	AC	D.I		С	Glass fixing sheet		
- ·						Ŭ	[MX-RP10,North America,Japan,Argentina] ガラス固定シート		
22	PCUSS00110S77		AB	D.I		С	Glass cushion		
				20		Ŭ	[MX-RP10,North America,Japan,Argentina]		
23	PSHEZ0208QSZZ	A	AC	DJ		С	Glass sheet R		
		-				-	[MX-RP10,North America,Japan,Argentina] ガ ラスシート R		
24	PCUSS0027QSZZ	A	AA	DJ		С	Glass cushion C		
0.5				<u>.</u> .		_	[MX-RP10,North America,Japan,Argentina] 1 77/9992 C		
25	C PSHEZ0088QSZ2	- /	AD	DJ		C	Table glass sheet [Missing parts code] 7-7 1/1 72/-1		1st lot
26	PMLI-0093QSZZ	ļ	АВ	DJ		C	Rear cabinet upper cushion 後种上 上 制 ト		
27	PSHEZ0474QSZZ	A	AD	DJ		С	Glass fixing sheet		
							MX-RP10,North America,Japan,Argentina  177,固定2-1		
501	N>CF i X-0012RS54	- A	AU	ΕZ		Е	SPF Glass fixing unit SPF <i>h</i> 77		1st lot
							[MX-RP10,North America,Japan,Argentina] 押えニット		
		+							
		$\vdash$							
		$\vdash$							
		$\vdash$							
		+							
				1					





PRP03901

## 2 外装部 2(Exteriors 2)

NO.	PARTS CODE	Inter- change	Ex.	Ja.	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective time
1	GCAB-0042QSTF		AP	EQ		D	Rear cabinet left (Except Japan) 後	针北"左		
	GCAB-0042QSTG		AP	EQ		D	Rear cabinet left (Japan) 後	<u>後キャビ左</u>		
4	GCAB-0145QSZZ		AU	EZ		C	SCREW(3×8) [ Delivery tray cabinet rear 排	∧ ル紙トレイキャビ後		
5	GCOV-00560ST1		٨G	ns		D	Rear cabinet maintenance cover 後	会书和上"		
			A.M.	50			<u>لار</u>	ンテナンスカハー		
6	GCAB-0043QSTC GCAB-0152QSZZ		AM	EG		D	Rear cabinet lower (100V Series) 後 Rear cabinet lower (200V Series) 後	をキャビート ミキャレジア		
7	XEBS740P10000		AA	DD		C	Screw(4×10)	ُکر ا		
_	GCAB-0085QST5		AY	FQ		D	Rear cabinet right (Except Japan) 後	针忙 右		
8	$\bigcirc$ GCAB-0085QST6	1	AY	FG		D	Rear cabinet right (Except Japan) 後			09/10 R/C
9	GCOV-0034QSTC		AK	DX		C	Rear cabinet right (Japan) 後 Rear cabinet memory cover 後	<u>ミキヤロ イコ</u> 会キャト゛メチリーカハ゛ー		
10	PCOVP0130QSZZ		AM	EG		D	Delivery dummy cover (Except Japan) 排	『「●●●●●●●●●●		
11	MSPRD0189QSZZ		AB	DJ		С	Right cabinet spring 右	<u>゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙゙</u>		
12	$\bigcirc$ MLEVP0069QSTZ	-	AD	DJ		C	Right cabinet lever [Missing parts code] 右	<u> ニキャヒ゛レハ゛ー</u>		1st lot
14	NROLP1060FCZZ	-	AF	DS		C	U-turn roller U	1476 N J 19-20-5-		151101
15	MSPRT0229GCAZ		AC	DJ		С	FU spring R FL	U スプリング R		
16	C GCAB-0039QSTC	-	AS	EZ		D	Right cabinet [Missing parts code] 右	5+72		1st lot
17	BEIL Z00160SZZ		AX AS	FG		D B	Option PWB cover 17	7`ション基板カバー		
19	GCOV-0086QSZZ		AN	EG		C	Delivery cover #	ク フフィルター 上紙カハ゛ー		
21	GCAB-0149QSZZ		AV	FG		С	Left cabinet (Japan) 左	EŦヤĽ		
21	C GCAB-0149QSZ1	-	AV	FG		C	Left cabinet [Missing parts code](Except Japan) 左	EŦヤĽ		1st lot
23	GCAB-0142QSZZ		AL AW	EB		C	Front cabinet right 前			
24	GCAB-0148QSZ1	3	AW	FG		C	Right cabinet front [Improve reliability] 右	コキャビ 刖 「キャト゛前		09/08 Mid
25		_	AC	П		C	Front cabinet band A2R 前	<u> 111 日本</u> 前キャヒ <sup>*</sup>		
23			AT	53		0		`		
26	GCAB-0141QSZZ		AI	ΕZ		C	Front cabinet III Energy star label IMX-M260(Except Argentina)	ĪŢŦヤĽ		
27	TLABZ5148FCZZ		AC	DJ		D	/M260FG/M260FP/M310(Except Argentina)			
							/M310FG/M310FP,AR-5726/5731(East Europe)] 1	ナシ゛ースターラヘ゛ル		
37	LX-BZ0082QSPZ		AA	DD		С	Screw(3×8) Ľ	<sup>2</sup> λ		
39			AC	DJ		D	Service caution label (Except Japan) #-	-ビス注意ラベル =フ_1_=ベル_NIE\ハ/		
40	TLABG5005FCZZ		AC	DJ		D	Class 1 label JPN (Japan) //	<u>フス 1 ラベル JPN</u>		
44	TLABH0483QSZZ		AC	DJ		D	Warm heater label (Japan) 保	k温ヒーターラベル		
49	MARMP0050QSZZ		AF	DS		D	Paper fixing arm 用	月紙押え7-4		
50			AE	DS D.I		D	FAX connector cover (Japan) FA	AX 177970 -		
52			PC	0			Service caution label PO	-ビス注意ラベル		
53	ICAUHIU/IFCZZ		ы	GD		D	(Germany,Switzerland,East Europe) PC	0		
54	TLABZ5048FCZZ		AB	DJ		D	WEEE mark label [Germany,Switzerland,East Europe,			
	PSHEZ0568QSZZ		AD	DJ		С	R cabinet sheet 右	5++E*5-F		
61	☑ PSHEZ0568QSZZ	-	AD	DJ		С	R cabinet sheet 右	<b>ゴキャヒ゛シート</b>		09/11
63	PCOVP0142QSZZ		AE	DS		С	Fan cover 77	ระวาท์ -		
65	GCAB-0144QSZZ		AK	DX		С	Delivery tray joint cabinet	F 紕トレイ f 糸圭キャト <sup>°</sup>		
66	PCOVP0144QSZZ		AD	DJ		С	R cabinet lever cover (Except Japan) 右	<u>゠ホロイャレ</u> ゔキャヒ゛レハ゛ーカハ゛ー		
67	HBDGD0058FCZZ		AT	EQ		С	Front cabinet badge [MX-M Series] 前	方キャヒ゛ハ゛ッシ゛		
	CBDGD0062FC35		AH	DX		C	Model name plate [MX-M260] 機	<u>と種名プレート</u>		
			AFI	DX		C	IVIODELINAME PIATE [MX-M310] 機 Modeliname plate [MX-M2600] #	<u>8悝名フ レート</u> #種名プレート		
	CBDGD0062FC38		AG	DX		Č	Model name plate [MX-M310N] 機	<u>≈₁±₁ı) ν r</u> 態種名プレート		
68	CBDGD0062FC42		AG	DX		С	Model name plate [MX-M260FP] 機	<b>ἕ種名プレート</b>		
	CBDGD0062FC40		AG	DX		C	Model name plate [MX-M310FP] 機	ἕ種名プレート ᢂ種名プレート		
	CBDGD0062FC43		AG	DX		C	Model name plate [MX-M260FG] 機 Model name plate [MX-M310FG] 樺	<u>&amp;1里石ノレート</u> 巻種名プレート		
	CBDGD0004QS01		AN	EQ	L	Č	Model name plate [AR-5726] 機	<u>~:±::,                                  </u>		
L	CBDGD0004QS02		AN	EQ		С	Model name plate [AR-5731] 機	<b>ἕ種名プレート</b>		
69	PBOX-0006QSZ1		AE	DS		D	Delivery sensor BOX 排	<u>⊧紙センサ−末゙ックス</u> * ¬		
70	VHPGP1S73P+-18		AF	DS		B	Photo sensor(GP1S73P) 7+			
70	MI EVPODEROST7					-	Delivery tray actuator 排	非紙トレイ		
12				53		Ŭ	77	ŊŦュエ-9-		
73	DHA i - 0 3 7 0 QSP Z		AF	DS		С	Delivery paper detect sensor harness 排	F紙紙検知センサー -ネス		
74	GCAB-0143QSZZ		BA	FX		D	Delivery tray cabinet 排	TA 非紙トレイキャビ		
75	PSHE703920S71		AR	ו.ח		С	Paper feed solenoid sound proof B 給	合紙ソレノイド		
70						Š	门			
/9	ILADZ3059F6ZZ		AB	DJ		U	BIVI IINK IADEI [MX-M260FP/M310FP] BN	ivi リンクフヘ ル		



## 3 操作部 (Operation panel unit)

NO.	PARTS CODE	Inter- change	Ex.	Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	PSHEZ0646QSPZ	0	AE	DJ		С	PWB protect sheet 基板保護シート		
2	XEBS730P08000		AC	DD		С	Screw(3×8) L <sup>*</sup> λ		
3	DHAI-0503QSPZ		AE	DS		С	KEY PWB harness KEY 基板小- ね		
	CPWBX0211QSF2		BR	LX		Е	Indonesia.India.Special country.Malavsia.		
						_	Singapore,Argentina) OPU 基板		
	CPWBX0211QSF4		BR	LX		Е	OPU PWB (Europe,U.kingdom) OPU 基板		
4	CPWBX0211QSF5		BR	LX		E	OPU PWB (Germany,Switzerland,East Europe) OPU 基板	-	
	CPWBX02110SE7		BR	ıх		F	West Africa Morocco Jordan Lebanon LIAF		
			BIX	2/1		-	Yemen,Oman,Qutar,Kuwait,Bahrain,Saudi Arabia) OPU 基板		
	CPWBX0211QSF3		BR	LX		Е	OPU PWB (Japan) OPU 基板		
5	MSPRP3009FCZZ		AD	DJ		C	LCD earth plate LCD 用7-7板		
6			AK BV	EB RB		B	LCD holder B LCD #I/9 - B		
8	LHLDZ0118QSZZ		AL	EB		C			
9	PSHEZ5764FCZZ		AC	DJ		С	Touch panel sheet タッチパ ネルシート		
10	HPNLH0264FCZZ		BF	GN		В	Touch panel 8.1 タッチパ 礼 8.1		
	CPNLC0072QS05		AX	FG		С	Operation panel B EX (Except Germany, Switzerland,		
11							Coperation panel AS [Missing parts code]	-	
	C C P N L C 0 0 7 2 Q S 0 3	-	AX	FG		С	(Germany.Switzerland.East Europe) 操作パネル AS		1st lot
	CPNLC0072QS04		AX	FG		С	Operation panel B J (Japan) 操作パネル B J		
14	PLNS-0016QSZZ	<u> </u>	AD	DJ		В	FAX Lens (Japan) FAX $\nu \lambda^*$		
15	CPNLC0070QS02		AR	EQ		С	Uperation panel 8.1 EX (Except Japan) 操作パネル		
10	CPNLC0070QS01		AT	EZ		С	Operation panel 81.1 (Japan) 操作パネル Δ811		
18	JBTN-0071QSA1	1	AR	EQ	1	Č	Mode key E-I <sup>*</sup> F-	1	
19	CBTN-0290FC01		AK	DX		С	Ten key 704-		
20	CBTN-0292FC03		AR	EQ		C	Interrupt key 割り込みキー		
21			AK	EB		C	Copy key ring IL <sup>*</sup> -F-1)27	-	
_ 22	CBTN-0291FC02		AG	DX		C	Power supply key lens CA key EX (Except Japan) CA た EX		
23	CBTN-0291FC01		AG	DX		C	CA key J (Japan) CA + J		
24	JBTN-0284FCAZ		AR	EQ		С	Copy key IL°-‡-		
	CPWBF0234QSE2		AX	FG		Е	Key PWB (MX-M Series except Japan) KEY 基板		
25	CPWBF0234QSE1		AZ	FX		E	Key PWB (Japan) KEY 基板	-	
26			AT	FQ FZ		E C	Key PWB (AR-57 Series) KEY 基板 Operation base plate A 描作台版 A		
27	QCNW-0249FCPZ		AZ	FQ		C	LCD-FFC P2 LCD-FFC P2		
20	LDA i U0038QSZZ		AQ	EQ		C	Operation base plate B 操作台板 B		
20	😋 LDA i U0 0 3 8 QSZ 1	1	AQ	EQ		С	Operation base plate B 操作台板 B		09/08 mid
29	XEBS740P10000		AA	DD		C	Screw(4×10) L <sup>*</sup> X		
30			AD AF	DJ		C	Operation panel side plate left 架作/ 孙側板左		
- 51	CPNLH0073QS01		AZ	FQ		C	Key sheet [English for FAX(MX-M Series)] キシート		
	CPNLH0073QS02		AP	EQ		С	Key sheet [English no FAX(MX-M Series)] キッート		
32	CPNLH0073QS03		AP	EQ		С	Key sheet [French for FAX(MX-M Series)] 누가나		
02	CPNLH0073QS04		AS	EQ		C	Key sheet [French no FAX(MX-M Series)] 누가	-	
	CPNLH0073QS22		AN Δ7	EQ FX			Key sheet [English(AR-57 Series)] 1-1-1-		
501	C) CHLDZ0118RS51	-	BX	RR		E	I CD unit [Missing parts code]   CD 12%		1st lot
Ľ	(Unit)								
					[	_	Operation panel unit [MX-M Series(North America,	1	
1	CPNLC0070RS51		CC	UB		E	Australia, New Zealand, Philippines, Thailand,		
901	CPNLC0070BS53		CC	UB	<u> </u>	E	Indonesia,India,Special Country)  保作小 初二ット		
	CPNLC0070RS52	1	CC	UB		E	Operation panel unit [MX-M260FP/M310FP] 操作小 私工ット		
	CPNLC0070RS54		CC	UB		E	Operation panel unit [MX-M260FG/M310FG] 操作パネルユニット		
<u> </u>		<u> </u>							
┣──									
<u> </u>		1		1	1			1	
L									
┣									
<u> </u>								1	
<u> </u>		<u> </u>		<u> </u>	<u> </u>			1	
<u> </u>									
┣—		<u> </u>		┣───	┣───				
<u> </u>		1							
	<u> </u>							<u>1                                    </u>	
┣									
			1	1	1	1		1	

3 操作部 (Operation panel unit)



- 6 -

## 4 フレーム部 (Frame section)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	LPLTM0163QSZZ		AK	EB		С	Left reinforce plate lower 左補強板下		
2	XHBS730P08000		AB	DD		С	Screw(3×8) Ľ λ		
3			AU	EQ		C	Frame reinforce plate R フレーム補強板 R		
4	XEBS740P10000		ΑΧ				Corner frame RL 3-7-70-4 RL		
			~~	00		0	DUP drive idle plate And2 Ref [Missing parts code] DUP 馭動7化		
6	C CPL 1 M0 5 2 9 Q S 0 1	-	AG	DS		С	<sup>7</sup> μ−h And2 Ref	:	1st lot
7	PSHE705070877		۵۵	וח		C	Pulley flange sheet N プーリーフランジ		
	1 311220307 0322		~~	00		Ŭ	≶-⊦N		
9	NPLYZ0036QSZZ		AD	DJ		С	DUP idle pulley TLPD DUP711 I/ I/ I/ - I/-		
11	LDAI-00230STE		BG	GT		D	Base plate 会振		
14	LHLDW1757FCPZ		AC	DJ		C	Wire saddle(HL-18-0)		
15	XHBS740P10000		AA	DD		C	Screw(4×10)		
16	LPLTM0333QSZ2		AX	FG		С	Frame reinforce plate F 7レーム補強板 F		
18	XRESP40-06000		AA	DD		С	E type ring(E4) E שילי E שילי		
19	NBLTT0026QSZZ		AF	DS		B	DUP drive belt DUP 駆動ベルト		
20			AS	EZ		C	Front reinforce plate 前補強板		
21			AC	DJ		C	Interlock cover 129-1197777 -		
23	CFRM-0044QS03		BB	FX		č	Right frame unit 右刀にしていた おうしん たいしん おうしん しょう おうしん しょうしん ちっしん しょうしん しょうしょう しょうしょうしょう しょうしょう いっしょう しょうしょう しょう		
24	LPLTM0251QSZ1		AE	DS		C	PS earth plate PS 7-3板		
25	NSFTZ0048QSPZ		AF	DS		С	Cassette collar shaft // // // // // // // // // // // // //		
26	NKOM-0005QSZZ		AC	DJ		С	Cassette guide collar		
27	XBPS730P08KS0		AB	DD	<u> </u>	C	Screw(3×8KS) L <sup>*</sup> λ	ļ	
28		<u> </u>	AC	DD 20		C	Screw(3×6) L <sup>*</sup> λ		
29				05			Right reinforce angle (Japan) 右補強アングル	-	
40	PSHEZ03330SZZ		AC.	D.I		C.	SCIEW(4×0) (Japan) Ľ Å		
41	PSHEZ0325QSZZ		AB	DJ		c	Frame lower sheet		
40					1	<u> </u>	DU motor fixing plate ASS'Y DU モーター取付板	1	
42	CPLIM0342QS01		AH	DX		C	組品		
43	NGEBH01740S71		AD	D.J		С	DUP drive gear TLPD DUP 駆動ギヤ		
			7.5	0			TLPD		
44	C RMOIS0056QSP1	-	BD	GJ		В	DUP reverse motor [Missing parts code] DUP 反転モター		
45	NBLTT0038QSZZ		AF	DS		В			
46	LPLTM0332QSZZ		AE	DJ		С	Fusing unit earth plate 定着ユニットアース板		
47				ы		C	Power supply switch fixing plate And2 Ref 電源スイッチ取付板		
47	LFL1M0493Q322		AE	DJ		C	And2 Ref		
48	XEBS740P12000		AA	DD		С	Screw(4×12) Ľ λ		
55	PML1-0091QS21		AD	DJ		C	Right frame cushion A 571-4711 A		
00 61	NPL X200150877		AC				OP holder cushion  Except MX-M310FG  OP ポルタ ークッション		
01	NFET20013Q322		AC	DJ		0	Pulley(S2M201) ノーリー Manual paper feed clutch spring A 手美し方河子		
62	MSPRC1315FCZ1		AD	DJ		С	Manual paper leed clutch spring A テ定でパパ スプリング A		
63	NGERH0066QSZZ		AD	DJ		С	1 way gear(17T) 1 ウェ/ギヤ		
64	PSHEZ0432QSZZ		AA	DJ		С	PS front sheet 2 PS 前シート 2		
65	LBSHC0009QSPZ		AC	DJ		C	Edge bush(CE-012 L15)		
66			AA	00		C	Clamp(UAMS-05S-2) 7577		
68	NEANP00200SP7		ΔP	EO		B	Optical bottom sheet And 光字底マイフー And		
69	XBPS730P30KS0		AC	DD		C	Screw(3×30KS) +* 1		
70			A <b>F</b>			-	DUP drive rotation plate And2 Ref [Missing parts code] DUP駆動回転板		
70	C CPLIM0530QS01	-	AF	05		C	And2 Ref		1 St lot
71	MSPRT0147QSZZ		AC	DJ		С	Stopper arm spring 21-7-4		
70			AC	יי		<u> </u>			
12			AC	טט			Step screw 段L 入		
									<u> </u>
			1					1	
								<u> </u>	
L									
								-	
		<u> </u>						1	-
								1	
<u> </u>									
								ł	
<u> </u>		<u> </u>		<u> </u>	<u> </u>	<u> </u>			
			1					1	
1			1	1	1	1		1	



## <u>5 דער (Lamp unit)</u>

	NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
Ī	1	PREFL0004QSZZ		AP	EQ		В	Reflector リフレクター		
$\wedge$	2	RLMPU0012QSZZ		BG	GT		В	Lamp 577°		
ŀ	3	LHLDZ0047QSZ3		AW	FG		C	Base ^ X		
ŀ	4	MSLI-0138FCZZ		AC	DJ		C	Slider 2个 り材		
ŀ	с 6	MSPBP01450S77		AE	DS		C	Protection cushion 防振/リソソヨン		
ŀ	7	PM i R - 0 0 0 9 QSZZ		AS	EQ		B	1st mirror 1st 5-		
ŀ	8	DUNTK0034QSP3		BK	HC		Е	Inverter unit		
Ī	9	DHAi-0200QSZZ		AS	ΕZ		С	CL harness CL n-ネス		
	10	LFiX-0009QSZZ		AF	DS		D	Harness fixing ハー祝押え		
	11	PCUSS0033QSZZ		AC	DJ		C	Mirror cushion ริวิ-ทางั่งว		
-	12	XEBS830P06000		AB	DD		C	Screw(3×6) Ľ λ		
ŀ	14				05			Wire fixing plate F リイヤー取付板 F		
ŀ	16	C XEPS830P06K00	-	AC			C	High temperature caution label 一両温注息パル Screw/(3∨6K) [Missing parts codel 比 7 (3∨6K)		1st lot
ŀ	17	C XEPS830P08K00	-	AC	DD		Č	Screw(3×8K) [Missing parts code] L × (3×8K)		1st lot
		(Unit)								
	901	C C R E F L 0 0 0 4 Q S 3 8	-	BR	MJ		Е	Copy lamp unit [Missing parts code] コピーランフ゜ュニット		1st lot
-										
ŀ										
┟										
ŀ										
ľ										
Ī										
ļ										
ŀ										
⊦										
ŀ										
ŀ										
Ī										
ŀ										
ŀ										
ŀ										
ŀ										
Ī										
[										
-										
ŀ										
ŀ										
ŀ										
Ī										
I										
ļ										
┟										
┟										
ŀ										
ŀ										
Ī										
ļ										
ŀ										
╞										
ŀ										
ŀ										
ľ										
Ī										
ļ										
ŀ										
┟										
ŀ										
ŀ										
ľ	_									
[										
ļ										
╞				L		L				
┝										
ŀ										
ŀ										
ŀ										



## 6 光学フレーム 1(Optical frame 1)

NO.	PARTS CODE	Inter-PRICE	RANK	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	PWiR-0006QSPZ	AZ	FQ		С	MB wire F MB 7/17- F		
2	CDA i U0 0 1 2 Q S 1 5	BG	GT		С	Optical base plate 光学台板		
3	NPLYZ0016QSZZ	AF	DS		С	Pulley 定プーリー		
4	NPLYZ0006QSZ1	AD	DJ		C	L pulley L 7°-IJ-		
5	PWiB-00050SP1	AA 47	FO		C	E type ring(E4) E 1/27		
7	CM i B - 0 0 0 8 Q S 3 6	BB	GD		E	WID WITE R         WID //1/- R           2/3 mirror unit         2/3 \$5-1-**		
8	C CREFL0004QS38	- BR	MJ		E	Copy lamp unit [Missing parts code] It -527 III		1st lot
9	XBPS740P06K00	AA	DD		С	Screw(4×6K) Ľ <sup>*</sup> λ		
10	LHLDZ0056QSZZ	AC	DJ		С	Wire holder 7/17-#ル9 <sup>*</sup> -		
11	LX-BZ0004QSPZ	AB	DD		C	Screw Ľž		
12		AG			C	MB-B rail R MB-B I-II F		
14	XBPS730P05K00	AA	DD		C	NIB-B Tall F         NIB-D V-N F           Screw(3×5K)         1° 3		
15	RMOTP0027QSZZ	BG	GT		В	Mirror motor S7-E-9-		
16	MSPRC0040QSZZ	AB	DJ		С	MB drive spring MB 駆動スプリング		
17	CPLTM0084QS02	AK	DX		C	Mirror motor fixing plate ミラーモーター取付板		
18		AL	EB		C	Protection rubber 防振工ム		
20	PGUMS00040S77		D.I		C	SCIEW(4×10KS) $E \lambda$		
21	XRESP50-06000	AA	DD		C	E type ring(E5) E リンゲ		
22	NBRGP0012QSZZ	AC	DJ		С	Winder bearing R 巻取り軸受 R		
23	NPLYZ00040877	AG	DX		С	Winder drive shaft pulley 巻取り駆動軸		
						<b>7°−I</b> J− Min des sulles:	ļ	
24		AL AR		<u> </u>		winder pulley  を取りブーリー Scrow		
26	XPSSJ30-12000	AB	DD		c	Spring pin(\$3-12)         C λ           27° ΙΙν, ή <sup>*</sup> κ <sup>*</sup> ν		
27	NSFTZ0028QSZ1	AS	EQ		C	Winder drive shaft 券取り駆動軸		
28	L X - B Z 0 3 2 4 F C P Z	AA	DD		С	Screw L' A		
29	NBLTT0002QSZZ	AH	DX		В	Winder drive belt 巻取り駆動ベルト		
30	NGERH0027QSZZ	AH	DX		С	Mirror motor idle gear		
31		AC	חח		C	Pit IF P		
32	XRESP70-08000	AA	DD		C	E type ring(E7)		
33	NBRGP0011QSZZ	AC	DJ		C	Winder bearing F 巻取り軸受 F		
34	LX-BZ0082QSPZ	AA	DD		С	Screw(3×8) Ľ λ		
35	PGiDM0108QST1	AG	DX		С	Hinge guide L ヒンジ が イト・ L		
36	XHBS730P08000	AB	DD		C	Screw(3×8) <u> <u> </u> </u>		
37		AG			C	Hinge guide R ビジガイト R		
00		7.0	00		0	Panel reinforce angle R パーパーク が 礼補命アング ル		
39	LANGF0021QSZZ	AF	DS		C	R		
40	XHBS740P10000	AA	DD		С	Screw(4×10) μ <sup>*</sup> λ		
<u> </u>								
<u> </u>								
<b> </b>			1					
<b> </b>								
				<u> </u>				
				L				
L			L					
┣───				<u> </u>				
<u> </u>			<u> </u>	<u> </u>				
			1					
L							ļ	
<u> </u>			┣───	<u> </u>				
<u> </u>				<u> </u>				
			1	1				

6 光学フレーム 1(Optical frame 1)



## 7 光学フレーム 2(Optical frame 2)

NO.	PARTS CODE	Inter-PRICE	RANK	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	PCOVP0075QSZZ	AE	DS		D	Harness cover ハーネスカバー		
2	XNES730-24000	AA	DD		С	Nut(M3) +ット		
3	VHPGP2D03//-18	AZ	FX		В	Photo sensor(GP2D03) (Inch Series) 771274-		
	VHPGP2D0777-18	BA	FX		В	Photo sensor(GP2D07) (AB Series) フォトセンサー		
4	DHA i - 0 3 4 6 QSP Z	AN	EQ		C	Optical sensor harness (Inch Series) 光学セルールーネス		
5	LHLDW1009ACZZ	AA	DD		C	Clamp(UAMS-05S-2) クランプ		
6	XBBS830P08000	AA	DD		С	Screw(3×8) Ľ λ		
7	CPWBF0083QSE5	AU	EZ		E	Sensor PWB センサー基板		
8		BG	GT		C	Optical base plate 光学台板		
10	XHBS730P06000	AA	DD		C	Table glass cushion         T-7 M/ 7A/771           Screw(3×6)         t* 1		
	VHPGP2D032/-18	BA	FX		B	Photo sensor(GP2D032) (Inch Series) 7t 1/2/9-		
11	RSNSZ0001QSPZ	BA	FX		В	Photo sensor(GP2D071) (AB Series) フォトセンサー		
12	XBPS730P08X00	AA	DD		С	Screw(3×8X) L <sup>*</sup> λ		
13	LPLTP0230QSZZ	AF	DS		C	Open/close sensor fixing plate         開閉センサー取付板		
14	MSPBD02320S77	AF AB			B	Photo sensor(GP1S73P) 7才校功- Poture spring 復居72° 出版		
16	MLEVP0077QSZZ	AC	DJ		C	Qpen/Close actuator 開閉7/f1I-9-		
17	LCRA-0002QSZZ	AC	DJ		C	Mini clamp ミニクランプ		
18	TLABH0461QSZZ	AG	DS		D	Clean caution label (U.S.A,Canada) 清掃注意ラベル		
10	TLABH0267QSZZ	AD	DJ		D	Clean caution label (Japan) 清掃注意ういい		
19		AD	DJ		C	CL lead holder CL J-h th/9 -		
20	FUILLULIOUSLL	AC	<u>ل</u> ات		- U	Euge protect sheet A エック 保護シートA		
21	PSHEZ0217QSZZ	AC	DJ		С	COD namess protect sneet D COD n <sup>-</sup> 林 保護シート R		
22	PSHEZ0448QSZZ	AA	DJ		С	Optical bottom sheet And 光学底?15- And		
24	PCASZ0010QSZZ	AL	EB		С	Dark box 暗箱		
26	RCORF0002QSZZ	AE	DS		C	Core(HF57SH35*1) 37		
28		BP			E	Lens unit USA IIV		
30	DHA i = 0.3450S77	AG	DX		C			
31	PSHEZ0108QSZZ	AC	DJ		C	Optical base plate bottom sheet A 光学台板底沪-A		
32	PSHEZ0219QSZZ	AC	DJ		С	Edge protect sheet B エッジ 保護シート B		
33	LX-BZ0031GCPZ	AB	DD		С	Screw Ľ λ		
34	PSHEZ0254QSZZ	AC	DJ		С	Optical bottom sheet         光学底シート C		
38	PSHEZ0273QSZZ	AB	DJ		С	CCD harness protect sheet A CCD パーネス 保護シート A		
39	PGSK-0008QSPZ	AF	DS		С	Gasket 1 t Ztyl		
40	XWHS740-08100	AA	DD		С	Washer (AB Series) ปรีวิทางัง		
41	PMLT-0094QSZZ	AC	DJ		С	Cushion ORG 표사 ORG		
42	C PSHEZ0443QSZZ	- AC	DJ		С	OP harness protect sheet F [Missing parts code] OP //-ネス		1st lot
43	PSHEZ0420QSZZ	AC	DJ		С			
4.4		10	DI		0	OP harness fixing tape OP ν-λλ		
44	F1FE-0031Q322	AC	DJ		C	固定テープ		
45	PSHEZ0426QSZZ	AB	DJ		С	OP harness protect sheet B OP ハーネス		
					_			
46	PTPE-0063QSZZ	AD	DJ		C	していた。 固定テープA2		
48	DHA i - 0 6 1 0 QSP 1	BF	GN		С	Operation PWB FFC 操作基板 FFC		
49	PTPE-0050QSZZ	AA	DJ		C	Core fixing tape コ7固定テープ		
50	PSHEZ0665QSZZ	AC	DJ		U	Optical frame sheet (Japan) 光字フレームマイフー		
<u> </u>		├──						
		<u>├</u>						
<b></b>								
<u> </u>								
<u> </u>		<u>├</u>			$\left  - \right $			
<u> </u>								
<u> </u>					$\vdash$			
<u> </u>								
<b></b>								
		<u>├</u>			$\left  - \right $			



## 8 中間フレーム部 (Middle frame section)

NO.	PARTS CODE	Inter- change	PRICE	RANK	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective time
1	DUNTK0616RSZZ		BV	NU		E	LSU unit(Include No.101)	LSU ユニット		
2	XEPS730P14X00		AB	DD		С	Screw(3×14X)	L 7		
5	MARMP0025QSZZ		AD	DJ		С	Separator pawl arm	剥離爪アーム		
6	XEBS730P10000		AC	DD		С	Screw(3×10)	ビス		
7	CHA i - 0 3 5 6 R S 5 1		AL	EB		С	MC harness	MC ハーネス		
8	CHA i - 0 6 0 3 R S 5 1		AN	EQ		С	GRID-MCFB harness	GRID-MCFB		
q			ΔН	אם		C	High voltage terminal holder P	/祆 克⊏랟ヱ+=」がP		
10	DHA i - 0 5 0 6 QSPZ		AQ	EQ		C	I SI I interface barness			
			4.5			-	High voltage terminal holder spring saw teeth I	高圧端子制が一		
11	MSPRD0190QSZ2		AD	DJ		C	· · · · · · · · · · · · · · · · · · ·	スプリング鋸歯 L		
12	MSPBD01910S72			Ы		C	High voltage terminal holder spring grid L	高圧端子ホルダー		
			7.0	20		Ŭ		<u> </u>		
13	MSPRD0192QSZ2		AD	DJ		С	High voltage terminal holder spring case L	高圧端子制ダー		
							AN2P II SW/ interface barness [Missing parts code]	AN 20 11 SW		
14	C DHA i -0606QSPZ	-	BT	MW		С		中継ハーネス		1st lot
15	LX-BZ0020QSPZ		AB	DD		С	Step screw	段ビス		
16				ום		C	CRUM connector fixing plate	CRUM コネクター		
10			7.0	50		Ŭ		取付板		
18	XRESP50-06000		AA	DD		C	E type ring(E5)	E リンク゛		
19	PCLC-0030QSZZ		AQ	EQ		в	PS clutch	PS 1797		
20	C DHA i - 0 5 9 0 Q S P Z	-	BT	NE		С	AN2R DV interface harness TW [Missing parts code]	AN2R DV 中继小-オフ TM		1st lot
27	XBBS730P05000		AA	DD		С	Screw(3×5)	<u>中和本ハーホス IVV</u> ド 7		
28	LHLDZ0085QSZZ		AE	DJ		Č	TR terminal holder	<u>し、</u> TR 端子ホレダー		
29	LPLTM0248QSZ1		AD	DJ		С	TR terminal plate	TR 端子板		
20	NRŌLR0089QSZ3		AY	FQ		С	PS transport roller Ref (Except Japan)	PS 搬送中ラー Ref		
30	NRŌLR0135QSZ2		AZ	FQ		С	PS transport roller Ref (Japan)	PS 搬送마카 Ref		
31	NBRGC0018QSZZ		AD	DJ		С	Bearing	軸受		
32	PCOVP0062QSZZ		AD	DJ		D	ILSW cover	ILSW カバ-		
33			AD	DJ		C	Right door stopper	右下 7ストッハー		
34	MSPRC0220QSZZ		AB	DJ		C	Stopper spring	<u>ストッハースフリンク</u>		
36	CSW-M0007BS56	-		FO	-	B	ILSW lever	ILSVV VN -		
37			AF	DS		C	II SW bolder	177-497/197 ILSW #14*-		
39	MSPRT0221QSZZ		AB	DJ		C	II SW spring	ILSW 77° 1/24		
40	JKNBZ0006QSZZ		AD	DJ		D	PS knob	PS /7		
41	XBPS730P08KS0		AB	DD		С	Screw(3×8KS)	Ľ ک		
42	XBPSC30P06ES0		AA	DD		С	Screw(3×6ES)	ビス		
43	LFRM-0037QSZ6		BA	GD		D	Middle frame	中間フレーム		
44	XRESP60-08000		AA	DD		С	E type ring(E6)	E リンク		
47	RMOTD0023QSZZ		AZ	FX		В	Toner motor	<u> </u>		
40	MSPRC0024QS21		AC	DJ			Hopper spring	$\frac{\pi y}{1} - \frac{1}{27} - \frac{1}{27}$		
43	BPI U-00240S77		AM	FG		B	Pawl solenoid	<u>myu</u> myu		
50	RPLU-0024QSPZ	1	AM	EG		В	Pawl solenoid	<u> </u>		09/09
51	MSPRC1318FCZ1		AA	DJ		С	Manual paper feed spring B	<u>所がい</u> 手差しスプリングB		
	LPiNS0025QSZZ		AC	DJ		С	TN guide pin A (Inch series,AB Series agency)	TNガイドピンA		
52	LPiNS0026QSZZ		AC	DJ		С	TN guide pin B (Except Inch series, AB Series agency)	TNガイドピンB		
50	LPiNS0028QSZZ		AD	DJ		C	TN guide pin C (Japan)	TNガイドピンC		
53	XEBS740P10000	-	AA		-	0	Screw(4×10)	<u>E' X</u>		
55	DHAi = 03540SP7	-	AA		-	C	Screw(3×6)			
56	C DHA i = 0.6050SPZ	-	BS	MW		C	DHV barness [Missing parts code]			1st lot
63	MSPRC0271QSZZ		AC	DJ		C	Earth spring	7-222 비ング		
64	XEPS723P12000		AA	DD		С	Screw(3×12)	<u>ل ک</u>		
65	PSHEZ0394QSZ1		AB	DJ		С	Solenoid sound proof sheet	ソレ/イド消音材		
66	QSW-B0017QSZZ		AF	DS		В	Tray detect switch	トレイ検知スイッチ		
	CPLTM0160RS59		BH	нс		Е				
67							[MX-M260/M260N/M260FG/M260FP,AR-5726]	馬込 里刀ユニット		
	CPLTM0160RS60		BH	HC		Е	IMX_M310/M310N/M310EG/M310ED AB-57311	EIZ 重わっ F ット		
70	PSPAZ0041QSZZ		AA	DJ		С	Solenoid spacer	////////////////////////////////////		
74	BML T-01200871		A1	ED		C	Fusing cushion A			
74	PML1-0120QS21		AL	ED		C	[MX-M310/M310N/M310FG/M310FP,AR-5731]	定着モルト A		
75	PMLT-0116QSZZ		AE	DJ		C	Fan cover cushion L	ファンカハ・ーモルトレ		
76	PML T - 0 1 1 7 QSZZ		AD	DJ		C	Fan cover cushion R	ファンカハ゛ーモルトR		
11		<u> </u>	AK		<u> </u>		Fan cover	<u>ファンカハー</u>		
70	XHBS730P20000		AD AR	סס		0	SUIEW	<u>しん</u> しらし 冷却ファンレップ		
80	NFANP0081FC77		BA	FX		В	I SU cooling fan	<u>LOU </u> (1 SU ) 合知770 A		
81	LPLTM0392QSZZ	<u> </u>	AK	DX	<u> </u>	C	Fan plate	772° U-1		
82	QCNCM1000FCPZ		AC	DJ		Ċ	Interface connector(BU03P-TR-PH)	中継コネクター		
83	LBNDJ0071FCZZ		AC	DJ		С	Cable band(RSG-100)	ケーフ゛ルハ゛ント゛		
84	PTPE-0062QSZZ		AD	DJ		С	Fan plate tape	FAN 7° レートテーフ°		
85	XEBS740P12000		AA	DD		C	Screw(4×12)	<u> </u>		
86	XEPS730P14X00		AB			C	Screw(3×14X)	<u>t'</u> <u>z</u>		
87				EG			LSU cover			
80	PMI T-01480877		AB	D.1		C	LOU COVER CUSHION L			
		1			I	<u> </u>			L	

## 8 中間フレーム部 (Middle frame section)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective time
91	PCŌVP0143QSZZ		AH	DX		D	Process air intake duct cover	プロセス吸気ダクト カバー		
92	PDUC-0010QSZZ		AH	DX		D	Process air intake duct	プロセス吸気ダクト		
93	DHA i - 0 6 0 9 Q S P Z		AK	DX		С	AN2R PS fan harness	AN2R PS ファンハーネス		
101	RMŌTN0055QSPZ		BL	HG		В	Polygon motor(for LSU)	木゚リゴンモーター		

8 中間フレーム部 (Middle frame section)



## 9 550 ליביי (550 cassette unit)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	LPLTP0159QSZZ		AD	DJ		С	Cassette rear edge plate		
2	LHLDW1226FCZZ		AB	DJ		С	Turn fastener ターンファスナー		
3	LPLTM0179QSZ1		AR	EQ		C	Rotation plate 回転板		
4			AC	DJ		C	Rotation plate sheet 回転板シート	+	
5 6			ΔΜ	FA			550 Cassette 550 7171		
7	C PTPE-0021QSZ1	-	AA	DJ		C	GID tane [Missing parts code] GID 面面于-7		1st lot
. 8	LPLTM0181QSZ1		AB	DJ		C	Side plate guide F 個板扩化下	-	101101
9	PGiDM0071QSZZ		AL	EB		D	Guide R が作 R	1	
10	LX-BZ1144FCPZ		AA	DD		С	Screw Ľ λ		
11	NGERH0193FCZZ		AB	DD		С	UC manual paper feed gear UC 手差しギャ		
12	MSPRC2631FCZZ		AC	DJ		С	Fusing pressure spring 定着加圧		
- 10	ML EX(D0.355560.34					-	スプリング		
13			AE	DJ		C C	Side plate Flever 側板 F レハー	+	
14	PSHE702440S72		AC	וס		C	Cassotta shoot	+	
16	XBESP70-08000		AA	DD		C C	E type ring(E7)	+	
17	NGERH0108QSZZ		AD	DJ		C	Lift gear(22T)	-	
18	MSPRC0354QSZZ		AC	DJ		С	Lift gear spring	1	
19	NSFTZ0047QSZ1		AK	EB		С	Lift shaft リフトシャフト		
20	LPLTM0180QSZ1		AE	DS		С	Lift plate リフトフ゜レート		
21	NBRGP0041GCZZ		AD	DJ		С	Bearing 軸受		
22	XEBS740P10000		AA	DD	<u> </u>	С	Screw(4×10) L <sup>*</sup> X	┿	ļ
23	GCOV-0282FCZZ		AH	DX		D	Cassette handle cover P2  加ット取手加、-		
24	XBPS740P08KS0		AR	חח		С	Screw(4×8KS)	+	
25	PSHEZ5948FC77		AD	D.I		c C	しいけw(+×0NO) [人 Cassette handle sheet P2 hhwに町ギシートロ	2	
27	LPLTM02770SZ7		AC	DJ		č	Side plate guide R 個板がパパマトア	+	
28	JHNDP0013QSZZ		AT	EZ		Č	Cassette panel AN2R มีช่วงการ การ	2	
29	XEBS730P08000		AC	DD	L	С	Screw(3×8) Ľ λ		
	C> TCADZ0549QSZZ	-	AE	DS		D	Size display card [Missing parts code](Inch Series) サイズ表示カード		1st lot
30	TCADZ0550QSZZ		AE	DS		D	Size display label (AB Series except Japan) サイズ表示カード		
	TCADZ0551QSZZ		AE	DS		D	Size display label (Japan) サイズ表示カード		
31	TLABZ0335QSZZ		AD	DJ		D	Paper seal label (Japan) 用紙封止ラベル、	<u> </u>	
501	CCASP0006RS79	-	BF	GN		Е	2nd 550 cassette unit[Missing parts code] 2nd 550 カセット		1st lot
	(LInit)						1_7/F	+	
				<u></u>		-	550 cassette unit/Without No 30) 550 カヤットュニット	+	
901	CCASP0006RS59		вн	GX		E	(No.30 を除く	)	
								+	
								-	
								1	
<u> </u>								+	
<u> </u>								+	
┣───								+	
<u> </u>								+	
<u> </u>								+	-
					1			1	
								+	
<u> </u>								<u> </u>	
								+	
<u> </u>	<u> </u>				<u> </u>			+	
<u> </u>					<u> </u>			+	
		1						+	
L					L			่	
L								+	
┣───								+	
								+	
	1				<u> </u>			+	
<b> </b>								+	
L				l				1	1
9 550 カセットユニット (550 cassette unit)



### 10 給紙部 (Paper feed section)

	NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective time
ŀ	1	XEBS730P10000	Ŭ	AC	DD		С	Screw(3×10)	ビス		
	2	CPWBF0081QSE2		AP	EQ		Е	Cassette sensor PWB	カセットセンサー基板		
	3	MLEVP0064QSZZ		AD	DJ		С	Paper detect actuator	紙検知アクチュエーター		
	4	MLEVP0063QSZ1		AD	DJ		С	Upper limit detect actuator	上限検知		
-	5	ML EVP00560SZZ		AC.	D.I		С	P-IN actuator	<u> アリナユエーダー</u> D_INI アカチュ エーター		
ŀ	0			1.0	50		0	Paper feed in actuator spring	入紙アクチュエーター		
	6	MSPRD0201QSZZ		AC	DJ		C	· · · · · · · · · · · · · · · · · · ·	スフ <sup>°</sup> リンク゛		
	7	PCOVP0064QSZZ		AD	DJ		D	Solenoid cover	ソレノイト゛カハ゛ー		
	8	RPLU-0026QSZ1	4	AR	EQ		В	Paper feed solenoid	給紙ソレノイド		00/00
-	0	MARMP00260S77	1	AR	EQ		В	Paper feed solenoid	<u>給紙ソレ/イト</u>		09/09
ŀ	10	NBOL B01330S77		AM	FG		A		<u> ///1ト /-4</u> ドッカアッフ゜ローラー		
ŀ	11	MARMP0019QSZZ		AD	DJ		C	Pick up arm F	<u> </u>		
	13	NGERH0990FCZZ		AB	DJ		С	Gear(16T)	ギャ		
	14	NRŌLR0132QSZ1		AR	EQ		С	Paper feed roller AND2	給紙ローラー AND2		
-	15	MARMP0021QSZZ		AD	DJ		C	Pick up arm R	<u>Ľックアッフ アーム R</u>		
ŀ	10				עט		C	Spring pin(\u00e92-8)	んノ リンク ヒ ン 絵紙+* ゎ		
ŀ	17				00		0	Pick up roller pressure spring	<u>ホロホムイ ヽ</u> ト゜ックアッフ゜ローラー		
	18	MSPRD0389QSZZ		AC	DJ		С		加圧スプリング		
Į	19	NBRGC0100FCZ1		AC	DJ		С	Bearing 6	ベアリング6		
ļ	20	NGERH0097QSZZ		AF	DS		C	2nd joint gear	<u>2nd 連結ギヤ</u>		
-	21	DHAI-0350QSPZ		AG	DX		C	Cassette sensor harness	カセットセンサーハーネス		
ŀ	22	NGERH01560877			03		C.	Paper feed clutch depr(42T)	トレ1使知ぶ1ツナ 絵紙カミッエモ゛ゎ		
ŀ	24	MSPRC02090SZ1		AC	DJ		C	Solenoid spring	<u>小口 ホムソ フッテキ イイ</u> ソレノイト゛スフ゜リック゛		
ŀ	25	XRESP40-06000		AA	DD		č	E type ring(E4)	E 1)2/		
ŀ	27	XRESP50-06000		AA	DD		С	E type ring(E5)	E <u>1)20</u>		
	28	PCLC-0024QSZZ		AX	FG		В	Paper feed clutch(42T)	給紙クラッチ		
	29	NSFTZ0080QSZ1		AG	DS		С	Paper feed roller shaft	給紙ローラー軸		
	30	VHPSG2481++-1		AE	DS		В	Photo sensor(SG2481)	<u>フォトセンサー</u>		
	31	DHA i - 0 3 9 9 Q S P Z		AF	DS		С	Manual paper feed empty harness	于左し エンプティーハーネス		
ŀ	33	XEBS730P08000		AC	DD		С	Screw(3×8)	± <u>,,,,,,,,,,,,,,,,</u> Ľ,,		
Ē	34	LPLTP0192QSZZ		AK	DX		С	Dehumidify heater fixing plate (Japan)	除湿ヒーター取付板		
$\wedge$	35	RHET-0006QSZZ		AQ	EQ		В	Dehumidify heater (Japan)	除湿ヒーター		
	36	PSHEZ0391QSZ1		AC	DJ		С	Paper feed solenoid sound proof A	給紙ソレノイド		
-								Dener feed coloneid cound preef D	<u>消首材 A</u>		
	37	PSHEZ0392QSZ1		AB	DJ		С	Paper leed solehold sound proor B	枯和70/11 当音材 B		
	20	DSHE702020871		۸ A	Ы		C	Paper feed solenoid sound proof C	給紙ソレノイド		
	30	F3HE20393Q321		AA	DJ		C	-	消音材 C		
-											
ŀ											
ŀ											
ŀ											
ļ											
ļ											
ļ											
ŀ											
ŀ											
ŀ											
Ē											
ļ											
ļ											
ŀ											
ŀ											
ŀ											
t											
ļ											
ļ											
ŀ											
ŀ											
ŀ											
ľ											
<u> </u>											
ļ											
ŀ											
			1								

10 給紙部 (Paper feed section)



### 11 搬送部 (Paper transfer section)

NO.	PARTS CODE	Inter-PRICE	RANK	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective
1	XEBS740P12000	AA	DD		С	Screw(4×12)	۲ <sup>°</sup> ス		
2	PCOVP0053QSZ6	AK	EB		D	Middle frame cover	中間フレームカバー		
3	MSPRD0194QSZ1	AD	DJ		С	PS earth spring LP	PS 7-2		
4	MSPBC02910SZZ	AC	D.J		С	PS pressure spring	<u> んノ リンク LP</u> PS 加圧 スプリング		
5	NSFTZ0065QSZ1	AD	DJ		C	PS sub shaft	<u>PS</u> 従動軸		
6	NKŌM-0006QSZZ	AC	DJ		С	PS collar(\u00e913.5)	PS II		
7	PSHEZ0133QSZZ	AD	DJ		С	Paper feed sheet	給紙用シート		
8	XEBS740P10000	AA	DD		C	Screw(4×10)			
9	PGIDM008/QSII	AP	EQ		C	Base plate paper feed guide			
10	MSPRD0233QSZ1	AC	DJ		С	ini actuator spring	スフ <sup>°</sup> リンク <sup>*</sup>		
11	MLEVP0023QSZZ	AE	DS		С	MF actuator	MF 7091-9-		
12	MLEVP0044QSZZ	AE	DS		С	MF actuator 2	MF 70711-9-2		
13		AC	DJ		C	Separator plate	<u>捌きプレート</u>		
14	PETA-00190SZZ	AD	DS			Pressure plate cover	<u> 上宿板(/ )//</u> 圧差振萎		
16	XEBS730P10000	AC	DD		C	Screw(3×10)	<u>上省 仮 <u></u> ビ ス</u>		
17	PSHEZ0242QSZ1	AH	DX		C	Pressure plate sheet	<u>上</u> 圧着板シート		
18	LRALP0008QSZ2	AN	EG		С	Base plate rail R	台板レールR		
19	VHPGP1S73P+-18	AF	DS		В	Photo sensor(GP1S73P)	フォトセンサー		
20	DHA i - 0 3 9 8 QSP Z	AE	DS		С	Manual paper feed P-IN harness	<u>手差しP-IN/-祝</u>		
21	MSPBD02020S77	AB	וח		C	Manual paper feed P-IN actuator spring	手差し P-IN		
21		7.0	55		Ŭ		, ッテュエーッー スフ <sup>°</sup> リンク <sup>°</sup>		
22		10	ים		~	Manual paper feed P-IN actuator	<u></u> 手差し P-IN		
_ 22	WILEVPUU5/QSZZ	AC	DJ		C	• •	アクチュエーター		
23	PSHEZ0515QSZZ	AG	DX		A	Separator sheet	捌きシート		
24	LPLTP0409QSZZ	AC	DJ		C	Separator plate AND2	捌きプレートAND2		
25	PCOVP0088QS21	AD	DJ		D	Plate cover			
26	MSPRC0270QSZZ	AB	DJ		С	Separator plate spring	がさ ノ レート えつ゜リック゛		
27	NKOM-0005QSZZ	AC	DJ		С	Cassette guide collar	<u>, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,</u>		
28	NSFTZ0048QSPZ	AF	DS		С	Cassette collar shaft	カセットコロ軸		
29	XBPS730P08KS0	AB	DD		С	Screw(3×8KS)	ビス		
33	PSHEZ0301QSZZ	AC	DJ		С	Rail R side sheet F	<u>レール R サイト・シート F</u>		
34	PSHEZ0302QSZZ	AC	DJ		C	Rail R side sheet R	<u> </u>		
30	PSP0-00260577	AD AA	DJ		C	Front separator sheet	<u> 削捌ざソート</u> ME_ACT フ+゚ンル゙		
38	LHLDZ0094QSZZ	AC	DJ		C	PS pressure holder			
20	MERECORDEZZ	A.C.			0	PS follower connect spring	PS 従動接続		
39	MSPRC0292QSZZ	AC	DJ		C	3	スプリング		
40	MSPRD0287QSZZ	AC	DJ		С	Paper feed sub roller spring	給紙補助		
41			Ы		C	Den en faard auk vallen			
41	NSETZ01010SZZ	AD	DJ D.I		C C	Paper feed sub roller	- 粘松相助□-7- - 給紙補助□-5 軸		
12		7.6	50		0	Toner protect sheet N	トナー飛散封止		
43	PSHEZ0314QSZ2	AF	DS		C	· · · · · · F · · · · · · · · · · · · ·	717- N		
44	LBBC-00120S77	AD	D.I		С	Manual paper feed sub collar bracket	手差し補助コロ		
45		7.8	DU		0		<u>ブラケット</u>		
45		AC	DJ		C C	Manual paper feed sub collar	<u> 手差し補助コ</u>		
40		AC	DJ		0	Manual paper feed sub roller spring			
47	MSPRD0340QSZZ	AC	DJ		С	Manual paper reeu sub roller spring	SP		
48	XEBS730P08000	AC	DD		С	Screw(3×8)	<u>۲</u> ۲		
51	LPLTM0396QSZ1	AD	DJ		С	Separator guide plate	捌きガイトプレート		
52		AA	DD		C	Push nut(M3)	7		
53		AK	אט ו			Cover guide	<u> 7/1 -7/1 -1 -1 -1 -1 -1 -1 -1 -1 -1 -1 -1 -1 -1</u>		
		AU	5		-	Base plate paper feed quide unit [Missing parts code]	<u>1VI4 / V=r N</u> 台板給紙		
501	C CG i DM0067RS56	- AX	FG		E		<u>ה האי</u> ר אין דער ה לרי בבייר		1st lot
502		- 49	F7		F	Middle frame cover unit [Missing parts code]	中間フレーム		1st Int
502		A.5	- <u>-</u> -				カハ・ーユニット		i at i dt
503		- AN	EQ		E F	Plate cover unit [Missing parts code]	<u>フレートカハーユニット</u>		1st lot
504	CPLIP0409R551	AN	EG		E	Separation plate unit	<u> 分離フ レートユニット</u>		
				l					
<b> </b>									
					$\vdash$				
<u> </u>									
			1						
<u> </u>			L						
┣──					$\vdash$				



### 12 שווי זי זיביא (Side door unit)

NO.	PARTS CODE	Inter-	Fx	.la	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective
1	MLEVP0058QSTZ	onango	AD.	DJ		C	l ock lever	ロックレハ゛ー		
2	$\overline{C}$ GDOR - 0002QSTD	-	AV	FG		D	Right door [Missing parts code]	<u>ニッパパー</u> 右ドア		1st lot
3	XRESP40-06000		AA	DD		С	E type ring(E4)	E リング		
4	LBSHZ0303FCZZ		AC	DJ		С	M bushing C	M ブッシング C		
5			۸D	וח		C	DUP roller drive gear	DUP P-7-		
5	NGEHI10074Q322		AD	DJ		C		駆動ギヤ		
6	LPiNS0133FCZZ		AA	DD		С	Pin(2×10)	ヘイコウヒ゜ン		
7	PTME-0020QSZ1		AC	DJ		C	Lock pawl	ロック爪		
8	MSPRD0222QSZZ		AC	DJ		C	Lock pawl spring	<u> </u>		
9	MARMP0043QSZZ		AC	DJ		C	Lock pawl arm	በック爪アーム		
10	NSF120055QS23		AH	DX		C	Lock pawl shaft	<u>ロック爪シャフト</u>		
11	XRESP30-06000		AA	DD		C	E type ring(E3)			
12	NRULPUU36QSZZ		AP	EQ			DUP transport roller	<u>DUP 搬运中7-</u>		
13	XPSSJ20-07000		AA	עט		C	Spring pin( $\phi$ 2-7)	<u> スプリング ビン</u>		
14	MSPRT0279QSZ1		AC	DJ		С	DUP follower spring	DUP 促到		
15			ΔF	DS		C	PS upper roller	x7 979 DS En_5_		
10	LEBM-00400SZ3		AS	FQ		D	Right door inner (Excent Japan)			
16	LFBM-00400S74		AS	FQ		D	Right door inner (Lacept Sapan)	右じ アインナー		
17	MSPRC0349QSZZ		AD	DJ		C	High voltage spring B	高圧スプリングB		
18	MSPRC0348QSZZ		AD	DJ		C	High voltage spring A	高圧スプリングム		
19	LPLTM0102QSZZ		AD	DJ		C	DUP roller earth plate	DUP ローラーアース板		
			<b>۸</b> Γ	<b>D</b> 0		0	TR terminal interface holder	TR 端子		
20		LI	AE	05				中継ホルダー		
21	XEBS730P06000		AA	DD		С	Screw(3×6)	Ľ ک		
22	MSPBC02060S77			20		C	TR pressure spring R	TR 圧接		
22	MGT 1100230Q322		ורי	53		Ŭ		スプリング R		
23	MSPRC02950877	l I	AF	DS		С	TR pressure spring F	TR 圧接		
								<u> </u>		
24	XHBS730P10000		AD	DD		C	Screw(3×10)	<u>Ľ 7</u>		
25	XHBS/30P16000		AA			C	Screw(3×16)	E' X		
27	XEBS/30P10000		AC			C	Screw(3×10)			
28			AE	DJ			Inner reinforce plate F			
29	LPLIMUU9IQSZI		AE	DJ		C	Inner reinforce plate R	<u>1ンナー補強板 R</u>		
30	MSPRD0205QSZZ		AE	DS		С	IC ground spring	107 72F		
31			ΔН	РΥ		C	Pight door roll	<u> </u>		
32			AF	DS	-	C C	Right door fall			
02	CHLDZ0150BS52		BF	GN		A	TC unit (Except Japan)			
33	CHLDZ0150BS51		BF	GN		A	TC unit (Lxcept Japan)			
34	PSHEZ0307QSZ1		AB	DJ		C	Right door sheet	<u> </u>		
36	PSHEZ0431QSZ1		AF	DS		C	Right door DUP sheet	<u>右ドアDUP シート</u>		
38	LX-BZ0084QSPZ		AB	DD		С	Screw	L' Z		
39	NGERH0243QSZZ		AD	DJ		С	TC gear(20T)	TCギヤ		
40	XEBS730P08000		AC	DD		С	Screw(3×8)	ĽХ		
11	MSPRC02800S77		٨D			C	TC roller spring R REF	転写ローラー		
41	M3FHC0289Q322		AD	DJ		C		スプリング R REF		
42	MSPBC02800SZZ		AC	D.I		С	TC roller spring F	転写ローラー		
								スプリング F		
43	LSUPP0003QSZ1		AD	DJ		C	Right door roller rib	右ドアローラーリブ		
44	PCLR-0014QSZ1		AD	DJ		C	TC roller collar A2R	<u>TC ローラーカラー A2R</u>		
46	PGiDH0093QSZ3		AN	EG		С	IR front paper guide	IK <del>前</del> からたいた		
<u> </u>							Transfer holder And Def	<u> ヘーハ カイト</u> まってまました		
49	LHLDZ0150QSZ1		AK	DX		С	I ransfer holder And2 Ref	戦与ホルダー And2 Ref		
50	L PL TM03650877		AD	D.1	<u> </u>	C	TR electrode plate	TR 雪極垢		
51	NROLR01590871	<u>├</u>	AY	FQ		č	Transfer roller AN3	<u></u>		
52	NBRGP00230SZ7	1 1	AD	DĴ		Č	Roller bearing			
54	LPLTM0245QSZ2		AG	DX		C	TR reinforce plate	TR 補強板		
55	LX-BZ1181FCZZ		AB	DD		С	Screw(3×6K)	Ľλ		
56	LPLTM0512QSZZ		AG	DX		С	Separate discharge sheet	 剥離除電シート		
57	LPLTM0247QSZZ	1	AC	DJ		С	Separate electrode plate	剥離電極板		
Ę٥	PML T - 0 0 4 4 QSZ Z		AA	DJ		С	TR cushion [MX-M Series]	TR ŧルŀ		
58	<u> PMLT-004</u> 4QSZZ	<u> </u>	AA	DJ		С	TR cushion [MX-M Series]	TR ŧルŀ		09/11 mid
59	PSEL-0163QSZ1		AH	DX		С	Transfer cleaner pad	転写クリーナーパット		
60	LHLD701510877	I T	AF	DS		С	Separate holder And2 Ref	剥離ホルダー		
		$\square$						And2 Ref		
61	PRNGF0107FCZ1	+	AC	DJ	L	С	Star ring	スターリンク゛		
L	(Unit)	$\mid$								
	CDOR-0002RS62		BF	GN		Е	Side door unit(Without No.33) (Except Japan)	サイト・ト・アユニット		
901	<u> </u>	┝──┤					Side deer unit/(Mitheut No 22)	(INO.33 际く) #/ いっっ…		
	CDŌR-0002RS63		BF	GN		Е	Side door unit(without No.33) (Japan)	ソ1 Γ Γ /ユーツト (No 33 陸 / )		
								(110.33 际人)		
<u> </u>		<u>├</u>								
<u> </u>		<u>†</u> −†								



# 13 マルチ手差しトレイユニット (Multi manual paper feed tray unit)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESC	CRIPTION	TR No.	Effective time
1	C PG i DM0 0 7 5 QST Z	-	AE	DJ		С	MB side guide F	[Missing parts code] MB サイドガイド F		1st lot
2	C PG i DM0 0 7 6 QST Z	-	AE	DJ		С	MB side guide R	[Missing parts code] MB サイドガイド R		1st lot
3	XEBS730P08000		AC	DD		С	Screw(3×8)	<u>۲</u> ۲		
4	LSOU-0024QSTE		AS	EQ		D	Manual paper feed tray 1 upper	手差しりレイ1上		
5			AD	DJ		C	Tray lock pawl	<u> </u>		
0	MSPRC0250QSZZ		AC AD	DJ			I ray lock spring			
8	XEPS730P06X00					0		(快大山フック)		
9	NGEBP1385ECZZ		AF	DS		C C	Width detect pipion	し ^		
10			AD	DJ		C C	Harness holder			
11			AP	EQ		D	Manual paper feed tray 2 upper	手差しりレイ2上		
12	QSW-B0017QSZZ		AF	DS		В	Trav detect switch			
13	DHAi-0359QSZZ		AP	EQ		С	Manual paper feed unit harness	手差しユニットハーネス		
14	MSPBP2830FC77		ΔΔ	Ы		C	Width detect plate spring	幅検知板		
14	M3111120301022		~~	5		U U		<b>スフ゜リンク゛</b>		
15	LPLTP0234QSZZ		AE	DS		С	Width detect plate	幅検知プレート		
16	MLEVP0035QSE2		AC	DJ		С	Original detect actuator	原稿検知		
47				50		-		77711-9-		
10			AP	EQ		E	Manual paper feed VR PVVB	手 走し VR 基板		1 of lot
10	VHPGP1S73P+-18	-	AS			B	Dete concer(CD1572D)	[Missing parts code] 手をしいれてい		151101
20	$\Box$ 1 SOU-00270STC	-	AP	FQ		D	Manual paper feed tray 2 lower			1st lot
22	XEBS730P06000		AA	DD		C	Screw(3×6)			
H	(Unit)					-				
004	CSOU-0024RS65		BF	GN		Е	Manual paper feed trav unit	(Except Japan) 手差しトレイユニット		
901	CSOU-0024RS66		BF	GN		Е	Manual paper feed tray unit	(Japan) 手差しトレイユニット		1
						-				
<u> </u>			1	1						
<u> </u>			1	1						
		İ —			İ —					1
L			L	L						
<u> </u>			<u> </u>	<u> </u>						
┣		<u> </u>	<u> </u>	<u> </u>	<u> </u>					
<u> </u>										
			<u> </u>	<u> </u>					-	
<u> </u>										
<u> </u>			<u> </u>	<u> </u>					-	-
			1	1						
<u> </u>		<u> </u>	<u> </u>	<u> </u>	<u> </u>					ļ
<u> </u>			I	I						
┣──		<u> </u>			<u> </u>					
┣						<u> </u>			L	
┣—										
┣─			<u> </u>	<u> </u>						
$\vdash$			<u> </u>	<u> </u>						
<u> </u>										

13 マルチ手差しトレイユニット (Multi manual paper feed tray unit)



# 14 マルチ手差し給紙ユニット (Multi manual paper feed unit)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective time
1	PCOVP0107QSTF		AL	EB		D	Multi frame cover N1	マルチフレームカハ゛ー N1		
2	XEBS730P10000		AC	DD		С	Screw(3×10)	ビス		
3	PSHEZ0099QSZZ		AC	DJ		С	Protect sheet S	防振シート S		
4	NROLR0922FCZ2		AR	ZZ		C	Manual paper feed roller	手差しローラー		
5	NGERH0223QSZZ		AC	DJ		C	Gear(20T)	<u>+ +</u>		
0	NGERH00610577			ום		C	Spring pin(\u00f62-7)	<u> </u>		
8	MABMP00090S71		AF	DS		C C	Bellor arm	<u>+ 1'</u> D-5-7-1		
9	MSPBT03510SZZ		AC	D.J		C	Roller arm spring			
10	NROLR1267FCZ1		AH	DX		C	Pick up roller	<u>「 , , , , , , , , , , , , , , , , , , ,</u>		
11	NSFTZ0096QSZ1		AF	DS		Č	Roller shaft F N	u-j-j+y+7 F N		
12	XRESP40-06000		AA	DD		С	E type ring(E4)	E リンク		
13	LBSHZ0303FCZZ		AC	DJ		С	M bushing C	M ブッシング C		
14	LBŌSZ0150QSZZ		AE	DS		С	Cam boss A2 N	<u> አ</u> ፈቱ እ A2 N		
15	MSPBC1315FCZ1		AD	DJ		С	Manual paper feed clutch spring A	手差しクラッチ		
				_		_		えつ リンク A		
16	PPiPP0109FCZ1		AC	DJ		С	Manual paper feed clutch sleeve A pipe	手左しりフッテ		
17		-	ΔF	PS		C	Com boos A1			
18	MABMP00410S77	-	AF	DS		C	Cam transmission arm			
19	MARMP0006QSZZ		AD	DJ		C	Fulcrum arm			
	MODD00470077					-	Stopper arm spring	<u>ストッハ゜ーアーム</u>		
20	MSPKD034/QSZZ		AD	DJ		C		<u> </u>		
21	MCAMP0003QSZZ		AD	DJ		С	Drive cam	駆動加		
22	MSPRC1316FC71		AF	DS		С	Manual paper feed clutch spring B	手差しクラッチ		
		L						<u> </u>		
23	PPIPP0014QSZZ		AC	DJ		C	Cam clutch sleeve	カムクラッチスリーフ		
25				DJ		C	Manual paper teed cum shaft	<u> </u>		
20	NGENHU9/2FCZZ		AD	DЭ		U	Bapar food connect plate TLPD	<u>キ 1′</u> 終純☆結≠⊏		
27	CPLTM0345QS01		AG	DX		С	Taper leeu vuillevi plate TLFD	<sup>亦由 孙氏1</sup> 女称21仪 TLPD		
29	XEBS730P08000		AC	DD		С	Screw(3×8)	+ <u> </u>		
30	PTME-0178FCZ1		AC	DJ		С	Manual paper feed pawl A	<u>こ</u> 手差しラッチA		
31	MSPRC2175FCZZ		AA	DJ		С	Pawl A spring	爪 A スプリング		
	BPI 11-00280877		ΔΜ	FG		в	Multi field solenoid	マルチフイールト゛		
32	111 20 00200322			20		Б		ソレノイト゛		
02	RPLU-0028QSPZ	1	AM	EG		в	Multi field solenoid	マルチフイールト゛		09/09
22			A A	DI		~		<u></u>		
33			AA	DJ		C	Manual paper feed spring B	<u>手差しスブリンク B</u>		
35	XBBS730P10000			סס		C	Scrow(2×10)	<u>于左しフット D</u> レ゙フ		
36	MABMP00270S71	-	AF	D.J		C	Manual paper feed tray arm	<u>し</u> へ 毛美し トレイアーム		
37	LFRM-0048QSTH		AS	EQ		D	Multi frame	7114711-1		
38	MARMP0008QSZZ		AH	DX		С	Stopper arm	ストッハ゜ーアーム		
39	LPLTP0056QSZ3		AD	DJ		С	Stopper plate	ストッハ゜ーフ゜レート		
40	XEPS730P06X00		AA	DD		С	Screw(3×6X)	ビス		
41	XEBS730P10000		AC	DD		С	Screw(3×10)	ビス		
42	PSHEZ0241QSZZ		AB	DJ		С	Manual paper feed protection sheet	手差し防振シート		
43	LBNDJ0013FCZ1		AE	DJ		C	Band	結束バンド		
44	NSF120090QS22		AG	DX		C	Roller shaft R N	<u> ローフー 朝 R N</u> チェーション いんざ		
45	MSPRD0302QSZZ		AC	DJ		С	manual paper teed coupling spring	于左しハッノ リンク スプリンガ		
				<b>.</b>		6	Revers ACT spring	反転 ACT		
46	MSPRD0329QSZZ		AC	DJ		С		えて <sup>°</sup> リンク <sup>°</sup>		
47	NCPL-0012QSZZ	L	AD	DJ		С	Manual paper feed coupling	<u>手差しカップ リング</u>		
48	CPWBF0083QSE5		AU	ΕZ		Е	Sensor PWB	センサー基板		
49	DHAi-0360QSPZ		AE	DJ		С	DUP 2 sensor harness	DUP2 センサーハーネス		
50	MLEVP0104QSZZ		AD	DJ		С	Revers lever	反転レパー		
51	LUSHZ0006QSZZ		AC	DJ		C	M bushing 2	M 7 y>>>1 2		
52			AC	DD		U C	Resin E type ring	樹脂ヒリング		
53			AB	עט		U U	Poly slider(5-12-0.5)	ホーリスフイダー		
<u> </u>	(Unit)						Multi manual paper food unit/Mithout No 26 40 44 42)	フルエモ羊! ゥー…!		
901	CFRM-00488555		BF	GN		Е	niun manuai paper leeu unin(viniout N0.30,40,41,43)	いい テ 左 しユーット (No 36 40 41 43		
								を除く)		
L		L								
<u> </u>										
┣───										
┣──		<u> </u>								
┣										
<u> </u>			-							
F		<u> </u>		<u> </u>						
t in the second		1								
L										
1		1	1		l I				1	



# [15] DV שבי (DV unit)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	LHLDZ0142QSZZ		AD	DJ		С	Filter holder 21/1/9-ħ/49* -		
2	PFiLD0313FCZZ		AG	DX		A	TN filter TN 71ルター		
3	XEBS/30P08000		AC			C	Screw(3×8) Contriduce suids to a literative state of the		
4	PSEL = 0.1620SZZ		AF	D.I		A			
6	LX-BZ1066FCZZ		AC	DD		C	Blue screw(3×6) 青ビス		
7	PGiDM0159QSZZ		AM	EG		С	Cartridge guide bottom カートリッジ か イト・下		
8	C PML T - 0 1 3 7 QSZZ	-	AD	DJ		С	Pipe cushion N [Missing parts code] / 17 EVIN		1st lot
9	PMLT-0142QSZZ		AC	DJ		С	Pipe cover cushion N אין אין דארי אין אין אין אין אין אין אין אין אין אי		
10	PSEL-0964FCZ1		AA	DJ		C	Cover upper seal カバー上シール		
11	PML T = 0 1 4 1 QSZZ		AC	DJ		C	DV guide cushion N DV fr Th Th N		
13			AD AC	DJ		C	DV side cushion R DV 71 t th R		
14	NROLP0150QSZZ		AS	EQ		C	MX roller I MX n-1- I		
15	NROLP0149QSZZ		AS	EQ		C	MX roller R MX II-7- R		
16	PMLT-0146QSZZ		AB	DJ		С	DV side cushion F DV サイト・モルト F		
17	XEBS730P06000		AA	DD		С	Screw(3×6) ביֹּג		
18	LHLDZ0132QSZ1		AC	DJ		С	Scraper holder スクレーパーホルダー		
19	PBOX-0025QSZZ		AM	EG		C	DV BOX DV # y/z		
20		-	AQ	EQ		C C	I oner sensor harness トナーセンサーハーネス		
21	NBBGY0769EC72		AA	FB		C C	E 1119(E4) E 177 MG bearing MG & 711/4*		
23	NPLYZ0041QSZZ		AC	DJ	<u> </u>	c	MX pullev MX 7°-II-		
24	LPLTM0194QSZZ	1	AC	DJ	1	Č	DV box fixing plate 現像槽固定板		
25	XBPS730P06KS0		AB	DD		С	Screw(3×6KS)		
26	NPLYZ0040QSZZ		AC	DJ		С	MG pulley MG 7° - IJ-		
27	NBLTH0494FCZZ		AD	DJ		В	DV belt DV ベルト		
28	PSHEZ0652QSZZ		AA	DJ		A	DV side sheet F DV サイドシート F		
29	XBB5/30P04000 PSHE706510977		AA AA	ים			SCREW(3×4) Ľ Ż		
31	XRESP50-06000	<u> </u>	AA	DD		C	E ring(E5) E II'''		
32	XEBS730P10000		AC	DD		C	Screw(3×10)		
33	NBRGC0020QSZZ		AH	DX		С	DMX bearing(F6/14) DMX ベアリング		
34	NGERH1653FCZZ		AC	DJ		С	DMX gear(24T) DMX גיין DMX לא		
35	LX-BZ1143FCPZ		AD	DJ		С	Screw Ľ λ		
36	LHLDZ0128QSZZ		AC	DJ		C	DV holder F DV אוא - F		
37	MSPRD0395QSZZ		AC	DJ		C	Bias spring パ イアススプ リング		
38			AC	DJ			MG holder MG #//9 -		
40	NBOL M01510S72		BT	NE		C	DV cover F DV /// - F		1st lot
41	PML T = 0.002 YSZ 1	-	AC	DJ		C	DV TH cushion DVTH FILE		131101
42	PSHEP0632QSZZ		AB	DJ		Č	Doctor cover seal		
43	LPLTM0002YSZ4		AR	EQ		С	Doctor reinforce plate ト* クター補強板		
44	LPLTM0477QSZZ		AK	EB		С	DV doctor DV ドクター		
45	XBPBZ30P03000		AB	DD		С	Screw(3×3) Ľ λ		
46	PCOVP0121QSZZ		AE	DJ		C	Doctor cover <u>h* ウターカバ</u> -		
47		1	AE	DJ					09/10 R/C
47	BDTCM00210S77		AC	FO		B			
49	XUBUZ30P08000		AA	DD		C	Screw(3×8)		
501	C CHLDZ0142RS51	-	AN	EG		E	Filter holder unit [Missing parts code] 7/1/9-#1/9 -1=y		1st lot
	(Unit)								
901	DUNT-0777RSZZ		BN	HZ		Е	DV unit DV ביין		
┣—									
┣──		<u> </u>							
		<u> </u>							
		1	1		1				
L		L							
┣		<u> </u>	<u> </u>		<u> </u>				
┣──		<u> </u>	<u> </u>		<u> </u>			1	
<u> </u>									
<b> </b>									
			1		1				
┣—		<b> </b>							
┣—		<u> </u>							
<u> </u>									
┣──								<u> </u>	
├──									
L									



# 16 7° דבגשם (Process unit)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	XEBS730P08000	Ū	AC	DD		С	Screw(3×8) Ľ λ		
2	PCAPH0022QSZZ		AC	DJ		D	Toner pipe cap ht-n° 17° +++7°		
3	NSRW-0002QSZZ		AE	DS		С	Transport pipe screw 搬送パイプスクリュー		
4	LPLTM0241QSZZ		AF	DS		С	Process reinforce plate 7° 叱ス補強板		
5	MLEVP0065QSZZ		AE	DS		C	Separator pawl lever 剥離爪い <sup>*</sup> -		
6	C CFRM-0049RS76	-	AZ	FQ		A	Process frame unit [Missing parts code] 7 ロセスフレームユニット		1st lot
10	NCPL-0003QS21		AC	DJ		C	Screw coupling 2/11-11/11/11/11/11/11/11/11/11/11/11/11/		
10	PSEL-0071QS22			05		A	Seal R try R		
12	PSEL 0070Q322					C A	Seal F $t77F$		
13	PPiPP00170S77		AF	DS		C	Toner pipe shutter $17.777$		
						0	Toner pipe $\frac{17}{100}$		
14	MSPRC0045QSZ1		AC	DJ		C			
15			10	ы		C	Pipe cap spacer n° 17° +++77°		
15	FSFA20090FC22		AC	DJ		C	ᠵ᠃᠃᠃ ᡘペ᠆ᡃᡃ᠆		
16	NGERH0036QSZZ		AC	DJ		С	Transport screw gear(30T) 搬送スクリューギヤ		
17	PCOVP0132QSZZ		AF	DS		D	Drum cover וֹי זעאַיי –		
18	NGERHOO39QSZZ		AE	DS		C	Transport pipe gear(14T) 搬送パイプキャ		
10	LFIX-0015QSZZ		AE	DJ		C	Drum fixing plate B (Inch series, AB Series agency) ト 74 固定板 B		
19	LFiX-0014QSZZ		AE	DJ		С	Drum lixing plate A (Except lach series AB Series agency) ビジ国字振 A		
20	NGEBH00370SZZ		AC	D.J		С	(LKCept Inch series,AD Series agency) ド /A回定版 A		
21	NGERH0038QSZZ	1	AC	DJ	<u> </u>	Č	Transport pipe gear(15T) 網沢パイプギャー		
22	NSFTZ0020QSZ1	1	AL	DS		С	Transport screw 搬送スクリュー		
23	NBRGP0299FCPZ		AD	DJ		С	DV bearing DV 軸受 DV 軸受		
24	PML T - 0 0 1 8 QS Z 1		AC	DJ		С	Transport screw cushion 搬送スクリューモルト		
25	PTME-0021QSZZ		AK	DX		С	Separator pawl 剥離爪		
26	LX-WZ0329FCPZ		AB	DD		С	Washer วิขว่ห		
27	LX-RZ0001QSZZ		AB	DD		C	Star ring スターリング*		
28	MSPHIU214QSZZ		AB	DJ	<u> </u>		Lever spring レバースプリング		
29			AA	עט			Screw(3×8) Concreter novel opting		
30	CHI DZ00358558			EG			Separator pawi spring 刺離パパノリソク	-	1st lot
- 51	CCL FZ00110S32	-	BD	GN		A	Cleaning brade $h^{1}$		131101
32	C) UCLEZ0011QSZ1	-	BR	MJ		A	Cleaning blade [Missing parts code] $\frac{1}{1-2}$		1st lot
33	XEBS730P10000		AC	DD		C	Screw(3×10)		
34	PSHEZ0329QSZZ		AC	DJ		С	Toner stir sheet トナー攪拌シート		
35	PTPE-0026QSZ1		AA	DJ		С	Screw tape $\lambda^{j}$		
36	LHLDZ0090QSZZ		AC	DJ		С	Star ring holder スターリング ホルダー		
37	LX-BZ0406FCPZ		AA	DD		С	Screw(3×4) Ľ <sup>*</sup> λ		
38	PRNGF0106FCZ2		AC	DJ		A	Star ring N2 スターリング・N2		
39	PRNGP0081FCZ1		AB	DJ		C	Resin E ring(E4) 樹脂 E リング		
44	PSHE20557QS22		AC	DJ		C	DR brake sheet DR 7 b-fy-h		
40 501	CPiPP0017851	_	AC	DD EG			Screw( $3 \times 6$ ) E $\lambda$ Topor pipe unit [Missing parts code] $1 \pm 10^{\circ} (7^{\circ})$		1st lot
502	CTME-00218S51	-	AN	FB			Toner pipe unit [Missing parts code] トノーハ イノ ユーット Separator pawl upit 副離血 コーット		151101
002	(Unit)		7.41	LD		~			
	(01)						Process unit(Without No.19.44) 7° העקביין		
901	CFRM-0049RS5N		BG	GT		Е	(No.19,44		
							を除く)		
┣—					<u> </u>	<u> </u>			
<u> </u>			$\vdash$						
<u> </u>									
┣──	1				<u> </u>	<u> </u>			
<u> </u>								-	-
		1		1					
L									
<b> </b>									
┣──									
┣					<u> </u>	<u> </u>			
<u> </u>									
<u> </u>									
	1	1							
L									
<u> </u>									
<u> </u>									
┣──									
<u> </u>								-	
<u> </u>									
<b>├</b>									
⊢		1			<u> </u>	<u> </u>			
<b> </b>		1		1	l	l			





# 17 定着ユニット 1(Fusing unit 1)

	NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESC	RIPTION	TR No.	Effective time
	1	C MARMP0048QSZ2	-	AF	DS		С	Pressure release fulcrum arm	[Missing parts code] 圧解支点7-4		1st lot
	2	MLEVP0100QSZZ		AE	DS		С	Pressure release lever F TL	圧解レバーF1	Ľ	
	3	MLEVP0101QSZZ		AE	DS		С	Pressure release lever R TL	圧解しい。一日	Ľ	
ŀ	8	RIHM-0050FCZZ		AN	EG		В	Thermostat TL	<u> </u>	-	
ŀ	10			AE	DJ DJ		C	DUP sensor namess	<u> </u>	×x	
ŀ	12	RH-HX0001QSLB		AT	EZ		В	Thermistor TI			
ŀ	13	LPLTM0338QSZ1		AC	DJ		C	Fusing earth plate UR		२	
ľ	14	VHPGP1SQ73P-18		AF	DS		В	Photo sensor(GP1SQ73P)	フォトセンサー		
ľ	15	XEBS730P06000		AA	DD		С	Screw(3×6)	۲ <sup>°</sup> ス		
Ļ	10	★ XEBS730P06000	-	AA	DD		С	Screw(3×6)	[To No,51] ב`ג (3×6)		09/07 mid
	18	LSTPF0172FCZZ		AA	DD		C	Roller stopper			
	10			BA			В	Heater lamp	(120V) E-9-527		
	19	BL MPUL0390SPZ		BA	FX		B	Heater lamp	(230V) = (-9-7)		
<u> </u>	22	LHLDZ0139QSZZ		AD	DJ		C	Lamp fixing plate			
ľ	23	LFRM-0098QSZZ		AV	FG		D	Fusing upper frame(TL)	定着上フレーム		
ſ	24	MSPBC03230S77		AC	D.J		С	Fusing unit earth spring	定着ユニット		
				1.0	50		0		アーススフ゜リンク゛	_	
ŀ	25			AC	DJ		C A	Fusing earth plate UF		=	
ŀ	27	NGEBH01710S77			FA FO		A	Heat roller(IL)	<u> 「 - ト</u>		
ŀ	20	NBBGP00250SZZ		AN	FQ		A	Lipper HR bearing(TL)	<u> 此间117</u> 上 HR 軸受		
ŀ	30	LPLTM0343QSZZ		AB	DJ		C	Gear key plate(TL)			
ľ	31	CPLTM0336QS02		AR	EQ		A	Fusing cleaner plate	定着夘ーナ板		İ
	32	MSPRT0257QSZ1		AC	DJ		С	Upper pawl spring	上爪スプリング		
ſ	33	MSPRD03220877		AC	D'I		С	Fusing ACT return spring	定着 ACT		
Ļ								<b></b>	復帰スプリング		-
	34	MLEVP0099QSZ1		AF	DS		С	⊢using rear paper detect lever	定着後用紙		
ŀ	35	PG i DM0 1 1 3 0 S 7 7		AT	F7		С	Fusing rear upper quide	(検知/ハ - 定善後 ト PG		
	36	PTME-0282FCZ2		AH	DX		Ā	Upper separate pawl	上刻離爪		
	37	LX-WZ0006QSZZ		AC	DD		С	Washer	剥離爪ワッシャ		
	38	PTME-0024QSZ2		AN	EQ		Α	Upper separate pawl	上剥離爪 LP	)	
	39	LX-BZ0086QSPZ		AD	DJ		С	Fusing unit fixing screw	定着ユニット 取付ビス		
Ī	40	C> CPL TM0 5 1 3 QS 0 1	-	AF	DS		А	Thermistor felt fixing plate	[Missing parts code] サーミスタフェルト		1st lot
	41	LX-BZ1195FCZZ		AC	DD		С	Screw(M3)	よいか 上、ス		
	42	LSTYM0004QSZZ		AK	DX		С	Fusing upper frame stay And3	定着上フレームス And3	τſ	
_	43	LPLTM0510QSZZ		AD	DJ		C	Earth joint plate	7-7連結板		
-	44			AB	עט		C	Screw(3×6)		10	
ŀ	45						C	Thermister screw	正有/~A版 Al #->フカレ゙フ	103	
ŀ	47	XHPS730P04000		AB	DD		C	Screw(3×4)			
ľ	48	XWHS730-05080		AA	DD		С	Washer	EjDist		
	49	LX-BZ0093QSZZ		AC	DD		С	Screw	ピス		
	50	PCOVP0148QSZZ		AK	DX		С	Thermostat cover	サーモスタットカハ゛ー		
	51	N XBBS/30P06000	-	AC	טט		C	Screw(3×4)	[From No,15] ב`ג (3×4)		1st lot
ŀ				BW	R.I		F	Fusing unit(Include Block 18)	(120V) 定着ユニット		
	004			D\//	<b>у</b> р і		_	Fusing unit(Include Block 18)	<u>( ブロック 18 含</u> (230V) 定着ユニット	む)	<u> </u>
	901	DUNIWU/82RS12		DVV	КJ		E	Eusing unit/Include Block 18)	<u>(ブロック18含</u> (100)/) 定差ュニット	む)	
		DUNTW0782RS11		BW	RJ		E		(1000) 足指ユニディ (フ゛ロック 18 含	む)	
ŀ											ļ
ŀ											
ŀ											
ŀ											1
ŀ											
ŀ											+
ŀ	_										
ŀ											+
ŀ											1
ľ											İ
ļ											<u> </u>
ŀ											
ŀ											-
ŀ											
ľ											

17 定着ユニット 1(Fusing unit 1)



# 18 定着ユニット 2(Fusing unit 2)

NO.	PARTS CODE	Inter- change	PRICE Fx	RANK	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective
1	NBRGY0022QSZZ		AL	EB		A	Fusing pressure bearing FU加圧軸受		
2	NROLR0156QSZZ		BF	GN		Α	Fusing roller  正着中-ラ-		
3	MSPBC03240SZZ		AC	D.I		С	Fusing pressure spring(TL) 定着加圧		
			///0	50		0	<u>۲٫° リンケ*</u>		
5	LPLIM0341QSZ1		AC	DJ		C	Fusing earth plate(DR) 定看7-2板		
7	C LPLTM0531QSZZ	-	AC	DJ		С	High resistor eatrh plate And3 [Missing parts code] ハルッパース板		1st lot
8	PGiDH0140QSZZ		AY	FQ		А	Fusing front guide 定差前がん		
9	LPLTM0340QSZZ		AC	DJ		C	Fusing earth plate(DF) 定着7-2板		
11	MSPRD0328QSZ1		AC	DJ		C	Lower pawl spring R(TL) 下爪スプリング R		
12	PTME-0041QSZZ		AG	DS		Α	Lower separate pawl 下剥離爪		
13	TCAUH0017QSZ1		AC	DJ		D	High temperature caution label (Except Japan) 高温注意ラベル		
	TLABH0381QSZZ		AE	DJ		D	High temperature caution label (Japan) 高温注意ラベル		
14	XBPSN30P08KS0		AA			C	Screw(3×8KS) L <sup>×</sup> λ		
15	MSPRD0327QSZ1		AC	DJ			Lower pawl spring F(TL) 下川スフリンク F		1 04 104
10		-	AI			D	Fusing lower mame [Missing parts code] 定有下ルム		151 101
17	MSPRD0326QSZZ		AC	DJ		С	r using real lower guide spring 定省 (アパイ) 復帰スプリング		
18	PGiDM0115QSZZ		AS	EQ		С	Fusing rear lower guide 定着後下が 仆		
19	TLABH0289QSZZ		AA	DJ		D	Fusing green label 定着グリーンラベル		
20	MLEVF0111QSZZ		AD	DJ		С	Pressure lever F(AND2) 加圧い-F		
21	MLEVF0112QSZZ		AD	DJ		С	Pressure lever R(AND2) 加圧い - R		
22	TLABH0685QSZZ	<u> </u>	AD	DJ		D	High temperature caution label (Except Japan) 高温注意ラベル		
22		<u> </u>	AE	DJ			High temperature caution label (Japan) 高温注意 デル		00/07:
23 24	XWHS740-08000			00			Kesistor(500IMΩ) [Missing parts code] 抵抗 (500MΩ)		09/07 mid
24	(Unit)		~~	00		0	₩asilei '/ツンヤー		
			DV	<b>.</b>		-	Fusing unit(Include Block 17) (120\/) 完善ו (120\/)		
	DUNTW0782RSZZ		BW	RJ		Е	(1200) 定指エア (ブック17 含む)		
Q() 1			B\//	RI		F	Fusing unit(Include Block 17) (230V) 定着エット		
301	00111070211312		DVV	113		L.	(ブロック 17 含む)		
	DUNTW0782RS11		BW	RJ		Е	Fusing unit(Include Block 17) (100V) 定着ユニット		
							(フロック1/含む)		
		<u> </u>							
<u> </u>									
L		<u> </u>							
<u> </u>		<u> </u>							
		<u> </u>							
		<u> </u>							
		1							
<u> </u>									
		L							
L									
L									
		<u> </u>							
├		<u> </u>							
			l	l	l				
<u> </u>		<u> </u>							
			1	1	1				





### 19 駆動ュニット (Drive unit)

NO		Inter- PRICE	RANK	NEW	PART	DESCRIPTION			Effective
NO.	PARTS CODE	change Ex.	Ja.	MARK	RANK	DESCRIPTION		TR NO.	time
1	XBPS740P08ES0	AB	DD		С	Screw(4×8ES)	Ľλ		
2	RMOTP0069QSP2	BA	FX		В	Main motor	メインモーター		
3		AU	FG		0	Main drive plate	メイン駆動板		
4	MSPRC0200QSZ1	AD	DJ	-	C	Ratchet spring	フナエットスノ リンク		
5	NGERH0234Q322		DS		C	Ratchet gear(491)	<u>ファエットキ ヤ</u> 空差取動ギメ		
7	NGEBH00840SZZ	AK	DX		C	$G_{ear}(0/21T)$	<u>に相感到す (</u> ギャ		
. 8	XRESP70-08000	AA	DD		č	E type ring(E7)	<u>1</u> Fリング		
9	NGERH0192QSZZ	AD	DJ		С	Gear(46/19T)	<u>ビック</u> ギヤ		
			<b>D</b> 1		<u> </u>	Gear(39/21T) [MX-M260/M260N/M260FP/M260FG,			
10	NGERHUU86QSZZ	AD	DJ		C	AR-5726]	ギヤ		
10	NGERH01900S77	AC	ы		C	Gear(39/19T) [MX-M310/M310N/M310FP/M310FG,			
	NGEIIII0190Q322	70	03		U	AR-5731]	ギヤ		
	NGEBH00870SZZ	AF	D.J		С	Gear(30/21T) [MX-M260/M260N/M260FP/M260FG,			
11					•	AR-5726]	ギヤ		
	NGERH0189QSZZ	AD	DJ		С	Gear(30/211) [MX-M310/M310N/M310FP/M310FG,	L* 1.		
10			БТ		<u> </u>	AR-5/31]	<u> </u>		
12	NGERHOOTOQSZZ	AD	DJ	-	C	Gear(281)	7 1 1 1		
14		AD	DJ		C	Gear(30/161)	+ 1		
14	XBPS730P06KS0				C		+ 7 ビ 7		
16	NGEBH00950SZZ	AF	D.I	1	C C	Sciew(3×0K3)	ビカ		
17	NGERH01910S77	AC	D.1	1	č	MG dear	ヽ i MG ギャ		
18	NGERH0186OSZ7	AH	DX		č	N gear(58/21T)	Nギヤ		
19	NGERH0096QSZZ	AE	DJ	1	C	Gear(37/25T)	<u>ギ</u> ャ		
20	CPLTM01610S02	AP	EQ	1	Č	Sub drive plate	サブ駆動板		
21	MSPRC02620S71	AC	D.I		č	MG spring	<u>, ア 同に当り17以</u> MG スプリング		
22	NCPL-00090877	AC	D.I		õ	MG coupling	MG カップリング		
23	NGEBH00910S77	AF	D.I		C C	Coupling gear(34T)	huつ゜llヽカ゛±゙ゎ		
24	CGEBH02048551		FO	1	C.		<u> パノフ ノノノ モ ド</u> ト デートカップ・キ ヤ		
<u> </u>					-	AN2R main motor harness	AN2R 1/17-8-		
25	DHA i -0602QSPZ	AE	DS		С		N-27		
26	LX-WZ0012QSZZ	AB	DD		С	Poly slider AND2	ホッリスライタ、一AND2		
27	XRESP50-06000	AA	DD		С	E type ring(E5)	F リング		
28	LX-WZ0476FCZZ	AC	DD		С	Poly slider	<u></u> ポリスライダー		
29	LX-WZ0407FCZZ	AB	DD		C	Poly slider	ポリスライタ゛ー		
	(Unit)		1		-		1 10/17		
					-	Drive unit [MX-M260/M260N/M260FP/M260FG.			
004	CPLIM0160RS59	вн	HC		E	AR-57261	駆動ユニット		
901		рц	ЦС		Е	Drive unit [MX-M310/M310N/M310FP/M310FG,			
	CFLIMOIOURS00	БП	пс		E	AR-5731]	駆動ユニット		
L		+ $+$ $-$	<u> </u>						
L		+ + + - + - + - + - + - + - + - + - +	<u> </u>	<u> </u>					
			<u> </u>						
		+							
L		+ $+$ $-$	<u> </u>						
		_	<u> </u>	ļ					
<b>├</b> ──		+ $+$			<u> </u>				
<u> </u>	l	$\left  \right $	+		<u> </u>				
<u> </u>		+ $+$							
<u> </u>	<u> </u>	┼─┼──							
<u> </u>	<u> </u>	┼─┼──							
<u> </u>	<u> </u>	┼─┼──							
	+	+ +	+						
		┼─┼──			<u> </u>				
		┼─┼──			<u> </u>				
	+	+ +	-		<u> </u>				
	+	+ +	-		<u> </u>				
<u> </u>		+ +	-	1	t				
		┼──┼──	+		<u> </u>				
		┼──┼──	+		<u> </u>				
		┼──┼──	+		<u> </u>				
		+ +	+		<u> </u>				
<u> </u>		+ +	1	1	t				
				1					
				1					
				1					
<u> </u>			1		<u> </u>				
<u> </u>			1	1					
			1		1				



# 20 第一排紙ユニット 1(1st delivery paper unit 1)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective time
1	NSFTZ0042QSZ1		AE	DS		С	Delivery sub roller shaft	非紙従動ローラー軸		
3	NRŌLP0049QSZZ		AC	DJ		С	Delivery sub roller	非紙従動ローラー		
4	NRŌLP0111QSZZ		AD	DJ		С	Delivery sub roller(Large)	非紙従動ローラー		
6	PBRSR0019QSZZ		AK	DX		В	Discharger brush I P	全雷ブラシート		
7	NROLR0114QSZZ		AR	EZ		C	Delivery roller C	<u>小電ノフノビロ</u> 非紙ローラー C		
8	NBRGY2122SCZZ		AB	DD		С	Transport roller bearing	般送口-う-軸受		
9	LPLTM0195QSZ2		AC	DJ		С	Delivery earth plate A	非紙アース板 A		
10	NBRGM0501FCZZ		AB	DJ		С	Bearing <b>‡</b>	<b>岫受</b>		
11	XRESP50-06000		AA	DD		C	E type ring(E5) E	£ リンク゛		
12			AQ	EQ		C	Delivery roller holder	非紙ローラーホルター		
13	LPLIP0185QSZ2		AL	EB		C	Delivery change gate	非紙切替ケート		
14	MSPRD0224QSZZ		AB	DJ		С	Delivery actuator spring	非私氏アクナユユーター リコ゜リンカ゛		
15	MLEVP0055QSZ1		AC	DJ		С	Delivery actuator	.ノ リノリ 非紙Fアクチュエーター		
						0	Delivery sub spring	非紙従動		
16	MSPRI0197QSZ1		AC	DJ		С	λ 2 σπτοτή σαυ σριπιά λ	、フ゜リンク゛		
17	XEBS730P08000		AC	DD		С	Screw(3×8) Ł	. <sup>*</sup> Х		
18	CPWBF0222QSE3		AK	EB		E	Sensor PWB t	ンサー基板		
21	CSFTZ0023QS04		AE	DS		С	Shifter shaft (North America) >	フタースラスト軸		
	CSFTZ0023QS01		AH	DX		C	Shifter shaft (Except North America) ジ	フタースラスト軸		
22		<u> </u>	AA		<u> </u>	C	E type ring(E4) E	: リンク まがつい /		
23			AZ AI				Delivery trame	<u>非社フレーム</u>		
24			AL AC				M bushing C	<u>ノリビ 排税世 7-</u>		
20		<u> </u>			<u> </u>		N Dustilling C N Delivery upper paper quide t	<u>n / ッン// し</u> 非紙 ト		
26	PGiDM0165QSZ1		AR	EQ		С	Solivery upper paper guide #	ም ጣይፈຼຼ ஃ −.パ −.ガ イド		
27	NROLP1122FCZZ		AF	DS		С	PS upper roller P	·S 上口-う-		
28	MSPRT0229GCAZ	1	AC	DJ	1	С	FU spring R F	U スプリング R		
29	XHBS740P10000		AA	DD		С	Screw(4×10) Ł	. ́ Х		
35	LX-BZ0780FCPZ		AC	DD		С	Screw t	. <sup>*</sup> Х		
36	PSHEZ0650QSZZ		AB	DJ		С	Delivery hole sheet B #	非紙孔マイラー B		
37	C PSHEZ0649QSZZ	-	AA	DJ		C	Delivery hole sheet A [Missing parts code]	非紙孔マイラ- A		1st lot
38	PSHEZ0655QSZZ		AD	DJ		C	Delivery fan connector sheet	非紙ファンコネクタシート		
39	PFILZUUI/QSZI		AP	EQ		A	Ozone filter 7	<u> ソ ンフィルター</u>		1 04 104
40		-	AB	עט		C C	Screw [Missing parts code] E	<u>λ</u>		1 St lot
41			AC AD	EO		B	CF fixing plate	テ 押え ノレート		
72	(Unit)		7.1	LQ			Tan motor ANR2	//t ) ANNZ		
	CFRM-0038RS74		BP	LP		E	1st delivery unit(Without No.29,35 Include Block 21) 1 (North America) (I ß	st 排紙ユニット No.29,35 を 余くブロック 21 全ま: )		
901	CFRM-0038RS75		BQ	LP		E	1st delivery unit(Without No.29,35 Include Block 21)  1 (Japan)(I 译	st 排紙ユニット No.29,35 を 余くブロック 21 含す: )		
	CFRM-0038RS76	-	BQ	LP		E	1st delivery unit(Without No.29,35 Include Block 21) 1 [Missing parts code](Except North America,Japan) (I [8]	st 排紙ユニット No.29,35 を 余くブロック 21 含む)		
L			L							
┣──		<u> </u>	<u> </u>		<u> </u>					
⊢		<u> </u>	<u> </u>		<u> </u>					
<u> </u>			<u> </u>							
<b> </b>										
<u> </u>			L							
┣		<u> </u>			<u> </u>					
<u> </u>								I		
<b>├</b> ──		<u> </u>	<u> </u>		<u> </u>					
┣──		<u> </u>	<u> </u>		<u> </u>					
<u> </u>			<u> </u>							
		1	1		1					
L										
⊢			<u> </u>							
┣—			<u> </u>							
<b>├</b> ──		<u> </u>	<u> </u>		<u> </u>					

20 第一排紙ユニット 1(1st delivery paper unit 1) ி D D *`*@` J-37 🖸 · v 15 1 **A** 39 - 17 40 C **©**37 **▲**39 (J ≫\_25 22 Q C 17 28 27

PRP03920

# 인 第一排紙그드가 2(1st delivery paper unit 2)

NO.	PARTS CODE	Inter-	PRICE	RANK	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective
1	XHBS730P08000	onango	AB	DD	1417 (1414	C	Screw(3×8) (Except North America) t <sup>*</sup> λ	_	unio
2	RMOTS0071QSPZ		BD	GJ		В	Shifter motor (Except North America) 579-E-9-	1	
3	CPLTM0184QS03		AH	DX		С	Shifter drive plate (Except North America) シフター駆動板		
4	XEBS730P08000		AC	DD		С	Screw(3×8) Ľ λ		
5	MSPRD0225QSZZ		AC	DJ		С	Stopper return spring (Except North America) ストッパー復帰		
6	LSTPP0003QSZ1		AC	DJ		С	Shifter stopper (Except North America) $\sqrt[3/7]{7/7}$	_	
7	NGERH0068QSZ1		AD	DJ		Č	Shifter gear(50T) (Except North America) $379-1^{\circ}1^{\circ}$		
8	NGERH0067QSZZ		AD	DJ		С	Shifter gear(24T) (Except North America) >79-+**		
9	VHPGP1A71L3-18		AG	DS		В	Photo sensor(GP1A71L3) (Except North America) フォトセンサー		
11	XRESP30-06000		AA	DD		C	E type ring(E3) (Except North America) E リング	_	
12	MSPBD02160577			עט			E type ring(E4) (Except North America) E UV7		
15			AD			0	Gate return spring ゲート復帰		
14	MSPRT0217QSZ1		AC	DJ		С			
15	LBRC-0002QSZ1		AC	DJ		С	Gate bracket ケ ートブ ラケット		
16	LBSHZ0303FCZZ		AC	DJ		C	M bushing C M 7 τηννή C		
17	NBRGY2122SCZZ		AB	עט		C	Transport roller bearing 搬送中方=軸受	_	
10	XPSSJ30-08000					C	Bearing(ゆ6) = 一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一一		
20	NBLTT0024QSZZ		AG	DS		В	Drive belt 240 駆動ベレト 240	-	
21	NGERH0080QSZZ		AE	DJ		С	Delivery drive gear(25/31T) 排紙駆動ギャ		
22	NGERH0082QSZZ		AD	DJ		С	DUP delivery gear(20/31T) DUP 排紙ギャ		
23	MSPRD0198QSZZ		AC	DJ		С	Delivery earth spring B 排紙7-入		
24	NGERH01120977				<u> </u>	6		_	
24	NGERH01140S77	<u> </u>	AC	D.1	<u> </u>	C	<u>ועופ year D(באו) אין אין אין אין אין אין אין אין אין אין</u>	-	
		<u> </u>		5.			Delivery earth spring A 排紙7-3		
26	MSPRD0196QSZZ		AC	DJ		С			
27	NGERH0155QSZZ		AD	DJ		С	Gear(31/39T) * *		
28	RPLU-0027QSZZ		AU	EZ		B	Change gate solenoid 切替ケートソレノイ		00/00
	S RPLU-0027QSPZ	1	AU	ΕZ		В	Change gate solenoid 切替ゲートソル/イ	.*	09/09
29	CBRC-0004QS03		AF	DS		С			
30	RMOTS0070QSPZ		BD	GJ		В	DUP motor DUP t-9-	-	
31	XHBS730P08000		AB	DD		С	Screw(3×8) Ľ <sup>*</sup> λ		
32	C XBBS726P03000	-	AA	DD		С	Screw(2.6×3) [Missing parts code] נ ג (2.6×3)		1st lot
33	XWHS730-05070		AA	DD		C	Washer ปรีวิภาวัง		
34	N LHLDW1334FCZZ	-		DJ		C	Wire holder オメカロック		1st lot
36	PRDAZ0002QSZZ		AD	DJ		C	Delivery motor radiation plate 非紙干小放熱	ŧÞ	
37	PSHEZ0341QSZZ		AA	DJ		Č	Shifter stop mylar (Except North America) $379-31y7^{\circ}$ 7(7)		
501	CPLTM0184RS54		AX	FG		Е	Shifter unit (Except North America) シフターユニット		
502	C CBRC-0004RS54	-	BA	FX		Е	DUP motor fixing bracket unit [Missing parts code] DUP t-9-		1st lot
	(1   mit)					_	取付ブラケットユニ	11	
	(Offic)						1st delivery unit(Include Block 20)   (North America) 1st 排紙1-wh	-	
001	CFRM-0038RS74		BP	LP		E	ر 20 py 20 date (100 kr 20) (	.)	
901	$C \in BM = 0.038BS76$		BO	IP		F	1st delivery unit(Include Block 20) [Missing parts code] 1st 排紙ュニット		1st lot
			DQ				(Except North America,Japan) (ブロック 20 含す	;)	130100
								-	
<u> </u>								+	
	<u> </u>								
┣—			<b> </b>		<b> </b>				
┣—								-	
<u> </u>			<u> </u>		<u> </u>				
<b>—</b>		1		1					
┣								_	
┣──								_	
<u> </u>			<u> </u>		<u> </u>			-	
<u> </u>		1		1	1			1	
┣──									
┣—		┣───	<u> </u>	┣───	<u> </u>			_	
┣──								+	
		1	1	1				-	
⊢			<u> </u>		<u> </u>			_	
┣──			<u> </u>					_	
F		<u> </u>		<u> </u>				-	



### 22 基板部 (PWB section)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
	CPWBX01360S31	<b>J</b> -	CB	тх		F	IMC PWB [MX-M260/M260N/M260FP/M260FG,		
1			00			-	AR-5726] IMC 基板		
	CPWBX0136QS3M		СВ	ТΧ		Е	INC PWB [MX-M310/M310N/M310FP/M310FG, AR-57311 IMC 其板		
2	XBBS730P08000		AA	DD		С	Screw(3×8) Ľ <sup>*</sup> λ		
3	PSPAB0039QSZZ		AG	DJ		С	Spacer 2 <sup>^°</sup> - <sup>#</sup> -		
4	CPWBF0235QSE1		BB	GD		E	Option interface PWB オプション中継基本	<u> </u>	
5	XBBS830P08000		AA	00			AN2R MCU-OP interface harness [Missing parts code] AN2R MCU-O	P	
6	C DHAI-0611QSPZ	-	AV	FG		С	中継//-ネス		1st lot
7	LHLDZ0062QSZ2		AT	ΕZ		С	MCU PWB fixing plate MCU 基板		
8	LX-BZ00900SPZ		ΔF	חח		C	取け板 Leveragen serew		
9	LHLDW0086QSZZ		AB	DJ		c	Hexagon sciew 0月し、 Harness ring I PD ハーネスリング・I PD		
	CPWBX0233QS31		CD	UD		Е	MCU PWB [MX-M260 North America] MCU 基板		
	CPWBX0233QS32		CD	UD		E	MCU PWB [MX-M310 North America] MCU 基板		
	CPWBX0233QS33		CD	UD		Е	MCU PWB [MX-M260/M260N/M260FP /M260EG Except North America] MCU其板		
10			CD			Б	MCU PWB [MX-M310/M310N/M310FP		
	CFWBX0233Q334		CD	00		<b>C</b>	/M310FG Except North America] MCU 基板		
	CPWBX0233QS35		CC	UB		E	MCU PWB [AR-5726] MCU 基板		
11	XBPS730P06KS0		AB			E C	MCU PWB [AR-5/31] MCU 基板 Screw(3×6KS) と は。1		
12	LHLDZ0071QSZZ		AG	DX		C	Mother board holder	-	
13	CPWBN0137QSE1		AZ	FX		Е	Mother board 70 70 This sector and the sector and t		
14	XHBS730P08000		AB	DD		С	Screw(3×8) Ľ <sup>*</sup> λ		
15	LX-BZ0082QSPZ		AA	DD		С	Screw(3×8) Ľ λ		
16	LHLDZ0070QSZ3		AW	FG		C	OP PWB holder OP 基板机约-		
17	XHBS730P08000		AB			C	Screw(3×8) E <sup>+</sup> X		
10	XEBS740P10000 XBPS730P08KS0		AA AB				Screw(4×10) $\xi \lambda$		
20	PSHEZ0269QSZZ		AC	DJ		c	CCD harness sheet		
22	DHA i - 0 3 4 5 QSZZ		AG	DX		C	CCD harness CCD //=ネス	-	
23	CPWBX0140QS3K		CM	UW		Е	FAX main PWB (Japan) FAX パン基板		
24	CPWBN0174QS31		BV	MW		E	LIU PWB (Japan) LIU 基板		
25	RSPA00001QSPZ		AH	DX		В	Speaker (Japan) גב° - לא-		
26	XEPS730P06X00		AA	DD		C	Screw(3×6) (Japan) Ľ λ		
27			AC	DJ			Spacer(WLS18-0) X^ -#-		1 ot lot
20		-	B7	TR		F	ILSW Interface namess 2 [Missing parts code] ILSW 中枢/一杯/	4	151 101
29	CPWBX0202RS54		CA	TR		E	PCL PWB [MX-M260EP/M310EP] PCL 基板 [MX-M260EP/M310EP] PCL 基板		
30	PCAPH0018QSZZ		AD	DJ		D	15P 保護キャップ		
31	PCAPH00190SZZ		AF	D.J		D	25P protect cap		
0.				D		5	(Except North America, Japan, Argentina) 25P 保護キャップ		
32	PCAPH0017QSZZ		AC	DJ		D	9P protect cap 9P 保護キャップ SPL C PWB [Missing parts code]		
33	C C P W B N 0 1 3 5 Q S 3 4	-	BS	MW		Е	[MX-M260/M310/M260FG/M310FG AR-5726/5731] SPLC 基板		1st lot
			DE	CN		0	1st delivery harness [Missing parts code]		1 ot lot
35	C DHAT 039TQ3FT	-	DL	GN		C	(North America) 1st 排紙ハーネス		151 101
	DHA i - 0 6 0 1 QSP 1		BE	GN		C	1st delivery harness (Except North America) 1st 排紙ハーネス		
37			AS	EZ		C	CL harness CL ハーネス		
38	DHA i -0.3460SPZ			FO		C C	Optical sensor harness (Inch Series) 光学セガーバーイム Optical sensor harness (AB Series) 光学セガーバーイム		
39	DHA i - 0 5 0 6 QSP Z		AQ	EQ		C	USU interface harness ISU 中継い-ネス		
40			DE	CN		C	Drive/Manual paper feed interface harness 駆動 / 手差し		1 ot lot
40	C DHAT 0393Q3FZ	-	ы	GN		U	[Missing parts code] 中継ハーネス		151 101
41	DHA i - 0 3 5 0 Q S P Z		AG	DX		С	Cassette sensor PWB harness カセットセンサー		
42	DHAI-06100SP1	<u> </u>	BF	GN		С	基板//-ネ/ Operation PWB FEC 品化甘生 ECC	'	
43	DHA i -03810SP7	<u> </u>	AH	DX		c	Cperation F work     床作奉板 FFC       Fusing interface harness     完善由継小-21		
44	C DHA i - 0 5 9 4 Q S P Z	-	BG	GT		C	AN2R power supply harness [Missing parts code] AN2R 雷源小之	2	1st lot
55	TLABH0533QSZZ		AB	DJ		D	USB label AND USB 7 <sup>*</sup> # ANE	)	
56	TLABH0534QSZZ		AB	DJ		D	NIC label AND [Except MX-M260FG/M310FG] NIC 7^ / AND		
70	RDTCH0161FCP1		AV	FG		В	Temperature humidity sensor         温度湿度センサー	_ <b>_</b> '	
72	DHA i - 0 5 9 5 QSP Z		AE	DS		С	Temperature humidity sensor harness 温度湿度センサー		
73	L SUPM0002QSZZ		AE	DJ		С	Support post [MX-M260N/M310N/M260EP/M310EP] #۵°-۱۰۴۵ ۲۸		
74	RCORF0046FCZZ	1	AH	DX		С	Core 17		
74	RCORF0046FCZZ	-	AH	DX		С	Core 17		1st lot
75	C DHA i - 0 5 9 7 Q S P 1	-	BF	GN		С	MCU-casette harness [Missing parts code] MCU- カセットハーネ	٢	1st lot
80	C) DHA I - 0 5 9 0 QSP Z	-	BT	NE		C	DV interface harness [Missing parts code] DV 中継ハーネス		1st lot
1			BD	GD		В	MCU ROM [MX-M260 North America] MCU ROM		
1	VHi291160700S		BA	FX		B	MCU ROM [MX-M260/M260N Except North America] MCU ROM	+	
82	VHi29L1607PQS		BA	FX		B	MCU ROM [MX-M310/M310N Except North America] MCU ROM	+	
1	VHi29L1607TQS	L	BA	FX		В	MCU ROM [MX-M260FG/M260FP] MCU ROM		
1	VHi29L1607UQS		BA	FX		В	MCU ROM [MX-M310FG/M310FP] MCU ROM		
L	VHi29L1608MQS		BA	FX		В	MCU ROM [AR-5726] MCU ROM	<u> </u>	
0.2	VH129L12856QS		BH	HC		В	PCL PRGDIMM [MX-M260N/M310N Philippines] PCL PRGDIM	<u>vi</u>	
03	VH129L1200000 VH129L1285409	<u> </u>	BH	HC		R			
L			5.1					<u>vi</u>	
							- 43 -		

#### 22 基板部 (PWB section)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
	VH i 29L 32077QS		AZ	FQ		В	PCL BOTDIMMJ [MX-M260N/M310N Philippines] PCL BOTDIMMJ		
84	VH i 29L 32079QS		AZ	FX		В	PCL BOTDIMMJ PCL [MX-M260N/M310N Except Philippines] BOTDIMMJ		
	VH i 29L 64012QS		BD	GN		В	PCL BOTDIMMJ [MX-M260FP/M310FP] PCL BOTDIMMJ		
85	LBNDJ0013FCZ1		AE	DJ		С	Band パンド		
86	PSPAN0025QSZZ		AE	DS		С	Spacer 2^°-#-		
87	L X - B Z 0 0 2 4 Q S Z Z		AA	DD		С	Screw Ľí		

#### 22 基板部 (PWB section)



# 23 後フレーム部 (Rear frame section)

ĺ	NO	PARTS CODE	Inter-	PRICE	RANK	NEW	PART	DESCRIPTION	TR No	Effective
	1		change	EX.	Ja.	MARK	RANK			· time
	1			AA	00		0	AN2R HL interface harness [Missing parts code] AN2R HL		
	2	C DHA i - 0 5 9 6 Q S P Z	-	BT	MW		С	中継ハーネス		1st lot
	3	TLABZ4868FCZ1		AB	DJ		D	Earth label (200V Series) 7-スラヘール		
	4	XHBS730P06000		AC	DD		C	Screw(3×6) Ľ X		
	5			AC	DJ		C	Drive earth plate 駆動アース板		
	0	LFLIMU252QSZZ		AD	DJ		U	Paper reed earth plate LP 約数/一次板 Drive/Manual paper feed interface barness 駆動 / 毛美		
	7	C DHA i - 0 5 9 3 Q S P Z	-	BF	GN		С	[Missing parts code] 中継ハーネス		1st lot
Ì	8	DHAi-0378QSPZ		AC	DJ		С	Cassette earth harness カセットアースハーギ	×۲	
	9	XHBS730P08000		AB	DD		С	Screw(3×8) ביא		
	10	XEBS740P30000		AC	DD		C	Screw(4×30)		
	11	PG1DM0184QS21		AH			C	Harness guide //-ネスカ イト		
	13	CDA i U0 0 2 4 B S 5 7		AC	FQ		F	Sciew(4×30)         L X           1st lift up upit         1st llフレアップ	1-wk	
	15	LPLTM0249QSZZ		AC	DJ		C	2nd earth plate 2nd 7-2板	/1	
$\triangle$		QACCD7713QCPZ		AT	ΕZ		В	AC cord (North America) AC u-h		
$\triangle$		QACCB7623QCPZ		BB	GD		В	AC cord (U.kingdom,UAE,Yemen,Oman,Qutar,		
								Kuwait,Bahrain) AC I-I		
<u> </u>		OACCVB6210CP7		AO	FO		в	AC cord (Germany, Switzerland, Europe, East Europe,		
								West Africa.Morocco.Jordan Lebanon) AC		
$\wedge$		QACCZR626QCPZ		BB	GD		В	AC cord (Philippines) AC $\neg$ - $\flat$		
$\triangle$		QACCZR941QCPZ		BB	FX		В	AC cord (Thailand,Indonesia) AC I-1		
Â	19	QACCB9521QCZZ		AW	FG	<u> </u>	В	AC cord (India,Special country,Malaysia,Singapore) AC I-h		
$\triangle$				AY DA	FQ		В	AC cord (Japan) AC h*		
<u>/\</u>			$\vdash$	ΒA Δ7	FÅ FO		B	AC cord (Australia, New Zealand) AC I-1		
<u> </u>		QPLGA4171CCP7		AR	FO		B	AC COLO (Argentina) AC I-1 Plug (India) 7° 5/*		
		QPLGA0001QCZZ		AN	EQ		B	Plug (Special country) 7° 5/°		
		QPLGA0009QCPZ		AR	EQ		В	Plug (Malaysia,Singapore) 7° 7/°		
		PHŌG-1023CCZZ		AB	DD		В	Plug protector (India,Malaysia,Singapore) 7 <sup>°</sup> ラ <sup>ヶ</sup> 用保	蒦	
		TCAUS0009QSZZ		AF	DS		D	LAG Plug caution label (Argentina) LAG 7° 51°		
	20			A 1			- D	注意ラベル 		
	20	0.5W - C9295QCFZ		AL AF			B	Power supply switch(AJSW200BF)  电源/1ッナ	( wI	-
	2.			50			0	Dehumidify heater switch harness (Japan) 除湿L-9-	//	
	22	DHAI-0589QSPZ		BS	IVIVV		C	ー		
	23	DHA i - 0 5 4 5 QSP Z		AH	DX		С	Dehumidify heater separate harness (Japan) 除湿L-9-		
	07						-			
^	21	RCTL20016QS22		BZ BZ	GN		F	Reactle (200V) リバクトル	• ar L	-
$\wedge$	28	BDENC00530SPZ		BZ BZ	TF		F	Low voltage power supply unit (120V) 低圧电源1-	-7 <b>r</b> 'wk	
$\overline{\mathbb{A}}$	20	RDENC0051QSPZ		BZ	TF		E	Low voltage power supply unit (100V) 低圧電源1	->1 ->1	
$\overline{\mathbb{A}}$	29	RDENU0058QSPZ		BN	LE		Е	High voltage power supply unit 高圧電源1	-yh	
	30	LHLDW1057FCZZ		AB	DD		С	Wire saddle(LWS-3S) ワイヤーサト・ル		
	31	C DHA i - 0 5 8 8 Q S P Z	-	BF	GN		C	AC switch harness [Missing parts code] AC X1/7F/1-	ねる	1st lot
	32	LFIX-0016FCZZ		AD	DJ		C	AC cord fixing (100V Series) AC コート 押	え	
	34	XEBS740P12000					C	Screw(4×30) $E \lambda$		-
	35	XWHS740-08100		AA	DD		C	Vasher ะรัวๆๆว่า		
	36	XWSS740-10000		AA	DD	1	С	Washer n° ネワッシャ		1
	37	L P L T M 0 3 4 9 Q S Z Z		AS	EQ		С	Power supply fixing plate 電源取付板		
	38	NFANP0020QSPZ		AP	EQ		В	P/S fan motor PS ファンモーター	-	
	39	XBPS/30P30KS0		AC	00		C	Screw(3×30KS) <u> <u> </u> <u> </u> <u> </u> <u> </u> <u> </u> <u> </u> <u> </u> <u> </u> <u> </u> </u>		+
ł	42		$\vdash$	AG	20		C C	Delivery support angle	,h°∥.	+
	46	XHBS740P10000		AA	DD		C	Screw(4×10) F <sup>*</sup> 7	· / IV	1
	47	LSUPP0133FCPZ		AC	DJ		С	PWB supporter 基板サポーター		1
Ì	49	RCORF0031QSPZ		AK	DX		С	Core <u>71</u> 57(1-37		
[	50	LBNDJ0013FCZ1		AE	DJ		С	Band 結束バンド		
ļ	53	LHLDW1154FCZZ		AC	DJ	L	C	Wire saddle(LWS5S2W) ワイヤーサト・ル		
	56		$\vdash$	AA	DJ		C	Band (200V Series) 結束パンド Tube(F5.20) (2001/ October 1) ズーブ		
	59	BCOBE00040877	$\left  - \right $	AC	DS		C C	LUDE(F0×20)         (200V Series) #1-7           Core         (200V/Series) #1-7		+
	60			AC	DJ		C	Edging(I = 32) (200V Series) $I_{2}V_{1}V_{1}$		
ľ	61	LPLTM0478QSZZ		AF	DS		Ċ	AC Inlet fixing plate (200V Series) AC 小り	2付板	
	62	XHSS730P06000		AB	DD		С	Screw(3×6) (200V Series) ב`ג		
	63	N XEBS730P12000	-	AC	DD		C	Screw(3×12)		1st lot
	64	XEBS/30P10000	$\left  - \right $	AC	טט		C	Screw(3×10) (200V Series) t <sup>*</sup> λ		
ł			$\vdash$							+
										1
										1
ĺ										
[										
			$\mid$							
			$\vdash$							
ŀ										
ŀ			1		h	-	-			1

23 後フレーム部 (Rear frame section)



### 27 2nd 搬送部 (2nd paper transfer section)

NO.	PARTS CODE	Inter- PRICE RANK NEW F		PART DESCRIPTION				Effective		
1	MSPBC03780S71	onange	AR	D.I	wir a a a	C	Lock spring	⊓⊎ກາລະຫາ		uno
2	MLOKZ0001QSZZ		AC	DJ		C	Paper guide lock	<u> ー/、 ー/、 // </u> ー/、 ー/、 ー/、 ー/、 ー/、 ー/、 ー/、 ー/、 ー/、 ー/、		
3	XEPS730P08X00		AA	DD		Č	Screw(3×8X)	ני <u>ג און און און און און און און און און און</u>		
			<b>A D</b>	50		0	Transport paper quide	<u>- //</u> 搬送		
4	PGIDM0068QSZI		AP	EG		C		^°−/ヽ°−ガイド		
5	MARMP0015QSZZ		AD	DJ		С	2nd door arm	2nd ドアアーム		
						_	Transport paper guide shaft	搬送		
6	NSFTZ0054QSZ1		AD	DJ		С		^° - / ° - ガ イ ド		
			۸ <b>г</b>	D0		6		<u> </u>		
/	NROLPTUBUFCZZ		AF	05		C	U-turn roller	U ターンローフー 140.1×4		
8	MSPBP03450S71		AD	וח		C	i ransport paper guide spring	版达 ^^		
0			10	00		Ŭ		ヽ_/ヽ_/」 1 r ス プ リ ン グ		
9	XEBS730P08000		AC	DD		С	Screw(3×8)	μ, , , , , , , , , , , , , , , , , , ,		
10	C GCOVA0026QSTC	-	AP	EQ		D	Right cover [Missing parts code]	<u>- ハ</u> 右か -		1st lot
11	XEBS730P10000		AC	DD		С	Screw(3×10)	<u>ר א</u> די גער גער גער גער גער גער גער גער גער גער		
12	PCOVP0089QSZZ		AD	DJ		D	Plate cover	_ プレートカバー		
13	LPLTP0409QSZZ		AC	DJ		С	Separator plate AND2	捌きプレートAND2		
14	PSHEZ0515QSZZ		AG	DX		A	Separator sheet	捌きシート		
15	NRÖLR0130QSZZ		AL	EB		С	Transport roller	搬送ローラー		
16	MSPRC0270QSZZ		AB	DJ		С	Separator plate spring	捌きプレート		
47			~			~		<u> えフ゜リンク゜</u>		
10		+	AC	DJ			Bearing	粗労 しょうちょう しょうしょう しょうしょう しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしん しょうしょう 見合う しょうしょう しょうしょう しょうしょう しょうしょう しょうしょう しょうしょう しょうしょう しょうしょう しょうしょう しょうしょう しょうしょう しょう		
10		<u> </u>	AC AD	EO		C	Concetto roll P	<u> 樹脂 ヒリンク</u>		
20	XBPS730P08KS0		ΔR			C		ルゼクトレール R ド フ		
20	NKOM-00050877	+ +	AC.	D.I		C C	Cassette quide collar	ር ^ ከታット ከ` ፈ ኑ` ㅋ⊓		
22	NSFTZ00480SP7	+	AF	DS		c	Cassette collar shaft	<u>カモノドル イド コロ</u> カヤットコロ車由		
23	PG i DM0 07 4 0SZ7	<u>} </u>	AK	DX		č	2nd U-turn quide	<u>ッこう ユーキー</u> 2ndl ターンカ・イト		
24	XEBS740P12000		AA	DD		C	Screw(4×12)	1100 7 77 11		
25	PSHEZ0301QSZZ		AC	DJ		С	Rail R side sheet F	<u>- ^</u> レール R サイドシート F		
26	PSHEZ0302QSZZ		AC	DJ		С	Rail R side sheet R	レール R サイト・シート R		
27	MSPPD02870577		۸C	וח		C	Paper feed sub roller spring	給紙補助ローラー		
21	M3F HD0287 Q322		AC	DJ		C		<b>スプリンク</b> ゙		
28	NRŌLP0087QSZZ		AD	DJ		С	Paper feed sub roller	給紙補助ローラー		
29	NSFTZ0101QSZZ		AC	DJ		С	Paper feed sub roller shaft	給紙補助ローラー軸		
30	PSHEZ0356QSZ1		AE	DS		C	Plate cover sheet	プレートカバーシート		
31	PSHEZ0347QSZ1		AC	DJ		C	2nd rail R sheet	2nd レール R シート		
33	LPLIM0396QSZ1		AD	DJ		C	Separator guide plate	<u>捌きガイトプレート</u>		
34	PSPAZ0055QSZZ		AA	DJ		С	Plate cover spacer	フレートカハー		
35		<u> </u>	ΔΔ	חח		C	Buch put(M2)	<u> スペーサー</u> フ゜ッシュナット		
501	CCOVP0089BS55	-	AP	FO		F	Plate cover unit [Missing parts code]	<u>ノ リノエノリド</u> フ゜レートカハ゛ーコニット		1st lot
			<i>,</i>	-~		_	Transport paper quide unit [Missing parts code]	<u>////////////////////////////////////</u>		101101
502	C CG i DM0 0 6 8 R S 5 5	-	AU	ΕZ		Е		^° – ^° – ガ イ ド		1st lot
								ユニット		
503	CPLTP0409RS51		AN	EG		С	Separation plate unit	分離プレートユニット		
		$ \rightarrow $								
<u> </u>		+								
		1 1								
L										
L	ļ	$ \downarrow \downarrow$								
L		+ + +								
<u> </u>		+								
	<u> </u>	+								
<u> </u>		+								
<u> </u>		┟──┼								
<u> </u>	1	+ +								
<u> </u>		<u>} </u>								
<u> </u>										
		1 1								
L										
L		$ \downarrow \downarrow$								
L		$ \downarrow \downarrow$								
<u> </u>		+								
	i de la companya de la company	1			1	1				

27 2nd 搬送部 (2nd paper transfer section)



# 25 2nd 550 カセットコニット (2nd 550 cassette unit)

NO.	PARTS CODE	Inter- change	PRICE	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	LPLTP0159QSZZ	g-	AD	DJ		С	Cassette rear edge plate  かい後端板		
2	LHLDW1226FCZZ		AB	DJ		С	Turn fastener $9-2772t-$		
3	LPLTM0179QSZ1		AR	EQ		С	Rotation plate 回転板		
4	PSHEZ0274QSZZ		AC	DJ		С	Rotation plate sheet 回転板シート		
5	GCASP0005QSZ4		BA	GD		D	550 cassette 550 カセット		
6	PGiDM0070QSZ1		AM	EG		С	Guide F が作 F		
7	C PTPE-0021QSZ1	-	AA	DJ		С	GID tape [Missing parts code] GID 両面テープ		1st lot
8	LPLTM0181QSZ1		AB	DJ		С	Side plate guide F 側板ガイド F		
9	PGiDM0071QSZZ		AL	EB		С	Guide R ทำให้ R		
10	LX-BZ1144FCPZ		AA	DD		С	Screw Ľ λ		
11	NGERH0193FCZZ		AB	DD		С	UC manual paper feed gear UC 手差しギャ	_	
12	MSPRC2631FCZZ		AC	DJ		С	Fusing pressure spring 定着加圧		
40						0			
13	MLEVP0755FC21		AE	DJ		C	Side plate F lever 側板 F b/1 -		
14			AC			C	Screw E X	_	
15	CSHEZ0244QS02		AE	DJ		C	2nd cassette sheet ASS'Y 2ndカセットシート組と	Å	
16	XRESP70-08000		AA	עט			E type ring(E7) E 1/27	_	
17	NGERH0108QSZZ		AD	DJ		C	Lift gear(22T)		
18	MSPRC0354QSZZ		AC				Lift gear spring 1714 427 1927	_	
19						C	Lift shaft UTPV#7F		
20				100		C	LIII piate 1717 U-1	-	
21				00			Dealing ====================================		
_ 22	ALD3/40710000		AA	00			Sciew(4×10) ĽX		
23	JHNDP0012QSZZ	1	AU	ΕZ		С	Zhu cassette panel ANZK 2nd 加切り小 ネル		
24	XBPS740P00KS0		ΔP	חח		<u> </u>			
4	-			00			Outew(4×0NO) ビム		
25	GCOV-0282FCZZ	1	AH	DX		D	Casselle nanule cover FZ 加水 P2 P2		
26	PSHE75948EC77	1	AD	וח		C	「Cassatta handla shoot D2」 ちょうしつ		
20	I PI TM0 2770977			10		C	Dasselle Inditute Sileet F2     加ット収手ットト2       Side plate quide R     個地方もののである。	-	
21	XFBS730P08000			חח		C	Dide plate guide N 1別校/11 K	1	
20	TCADZ05490SZZ	- I	AC	DS			Size display card [Missing parts code](lpch Series) $\#/7$ = $\pi$ -1		1st lot
29			ΔE	DS		C	Size display card [Missing parts code](Inch Series) 州 夜小 下		13(10)
23			ΔE	DS		C C	Size display label (AD Series except Japan) 91% 及小小		
	10/02/03/00/22		/\L	00		Ŭ	2nd 550 cassette unit [Missing parts code] 2nd 550 thm		
501	CCASP0005RS79	-	BF	GN		E			1st lot
-	(Unit)						<b>1</b> -71		
	(0111)						2nd 550 cassette unit(Without No 30) 2nd 550 ##vit		
901	CCASP0005RS59		BK	нс		Е			
				_			 (No 30 を除く)		
								·	
L		ļ			L				
L				L	L				
L			<u> </u>					-	
L									
L									
L			<u> </u>						
<u> </u>		ļ							
<u> </u>		ļ							
		ļ							
<u> </u>		ļ							
┣──									
┣				<u> </u>	<u> </u>				
<u> </u>				<u> </u>	<u> </u>				
<u> </u>	1								
<u> </u>	1		<u> </u>			<u> </u>		+	
<u> </u>		1	t					1	
	1		<u> </u>					1	
	1		<u> </u>			<u> </u>		+	
<u> </u>	1		<u> </u>					+	
<u> </u>	1		<u> </u>			1 1		+	
<b>—</b>	1	1						1	
<u> </u>			<u> </u>						
<u> </u>			<u> </u>						
<u> </u>			<u> </u>						
<u> </u>		1	1					1	
<u> </u>	1	1						1	
<u> </u>		1	1					1	
<u> </u>	1	1						1	

25 2nd 550 カセットユニット (2nd 550 cassette unit)



### 26 2nd 給紙部 (2nd paper feed section)

NO.	PARTS CODE	Inter-	PRICE	RANK	NEW	PART	DESCRIPTION	TR No.	Effective
2		change		Ja.	WARK			-	ume
	FCOVF0070Q322		AD	5		-	2nd cassette sensor PWB 2nd they by the		
4	CPWBF0095QSE3		AP	EQ		E	えんでは、またのですがし、これのかったが、 基板		
5			۸D	Ы		C	Upper limit detect actuator 上限検知		
5				5		0	70+11-9-		
6	MLEVP0064QSZZ		AD	DJ		С	Paper detect actuator 紙検知アクチュエータ	-	
7	MLEVP0062QSZZ		AC	DJ		С	P-IN detect actuator 入紙検知		
8	PCOVP00640SZZ		AD	D.J		D	Solepoid cover $\frac{1}{1}$		
	RPLU-0026QSZ1		AR	EQ		B	Paper feed solenoid 給紙ルルト		
9	RPLU-0026QSP1	1	AR	EQ		В	Paper feed solenoid 給紙ソレ/イド		09/09
10	MARMP0026QSZZ		AD	DJ		С	Solenoid arm yu/11°7-4		
11	MSPRC0209QSZ1		AC	DJ		С	Solenoid spring ソレノイト・スプ・リンク・		
13	NSFTZ0102QSZZ		AH	DX		С	2nd paper feed roller shaft 2nd 給紙ローラ-軸	1	
14	QSW-B0017QSZZ		AF	DS		В	Tray detect switch トレイ検知スイッチ		
17	DHA i - 0 3 9 7 Q S P Z		AD	DJ		С	Cassette detect interface harness  加小検知中継		
10			10	DI		<u> </u>			
10	NBRGC0100FCZ1		AC	DJ		C	Bearing 6 $\wedge 7927$ 6		
19	MSPRD0389QSZZ		AC	DJ		С	hreft in the second sec		
20	MARMP0021QSZZ		AD	DJ		С	Pick up arm R L° ックアップ アーム R		
21	NGERH0107QSZZ		AD	DJ		С	Paper feed gear(20T) 給紙ギヤ		
22	LPiN-0026MCZZ		AA	DD		С	Spring pin(φ2-8) 27° リンク・ヒッシ		
23	NRŌLR0132QSZ1		AR	EQ		С	Paper feed roller AND2 給紙ローラー AND2	2	
24	MARMP0019QSZZ		AD	DJ		С	Pick up arm F ピックアップ アーム F		
26	NGERH0990FCZZ		AB	DJ		C	Gear(16T) ギャ		
27	NRULR0133QSZZ		AM	ĔĠ		A	Pick up roller L° y/7y7° ローラー	1	
29	DHA i - 0 3 9 4 Q S P Z		AD	DJ		С	Door open/close detect harness ド 7開閉検知		
		$\vdash$					ハーネ人 Dener feed in detect actuator spring 3 紙比合作の		
30	MSPRD0204QSZZ		AC	DJ		С			
						-	, , , , , , , , , , , , , , , , , , ,		
31	DHA i -04730SP1		۵G	אח		C	Cassette sensor PWB harness カセットセンサー基板		
51	DIIXI 0473Q311		70	DA		U U	ハーネス		
								1	1
L								-	ļ
<u> </u>		$\vdash$							
		$\vdash$						+	
<u> </u>		$\vdash$						-	
├		$\vdash$						1	
		$\vdash$						1	
<b></b>								1	-
<u> </u>		$\vdash$							
<u> </u>									
		$\vdash$	-					-	
			-					1	
<b> </b>									
								1	
L	1	1	1	1	1			1	

26 2nd 給紙部 (2nd paper feed section)



### 27 2nd 搬送部 (2nd paper transfer section)

NO.	PARTS CODE	Inter- PRICE RANK NEW F		PART	TR No.	Effective				
1	MSPBC03780S71	onunge	AR	D.I	www.u.v.	C	Lock spring	ר» ווי <i>י</i> א		uno
2	MLOKZ0001QSZZ		AC	DJ		C	Paper quide lock	<u>、                                    </u>		
3	XEPS730P08X00		AA	DD		C	Screw(3×8X)	<u> </u>		
	DO: DM0000071		<b>A D</b>	F.0		0	Transport paper guide 搬送			
4	PGIDM0068QSZ1		AP	EG		C	^° -/\	°−ガイド		
5	MARMP0015QSZZ		AD	DJ		С	2nd door arm 2nd	F 77-6		
							Transport paper guide shaft 搬送			
6	NSFTZ0054QSZ1		AD	DJ		С	^° -/\	゚−ガイド		
				50		_	<u>کې کې کې کې کې کې کې کې کې کې کې کې کې ک</u>			
	NROLP1060FCZZ		A۲	DS		C	U-turn roller U 9-	シローラー		
0				וח		C	Transport paper guide spring 搬运	• <b>±</b> • /1•		
0	M3FRF0345Q321		AD	DJ		C	∧ -/\ ?⊐°⊔	- 70 1 ト እ		
9	XEBS730P08000		AC	חח		C	Screw(3×8) +* 7	<i>)</i> //		
10	C GCOVA00260STC	-	AP	FO		D	Pight covor [Missing parts codo] 左和	* _		1st lot
11	XEBS730P10000		AC	DD		C	Screw(3×10)			101101
12	PCOVP0089QSZZ		AD	DJ		D	Plate cover 7° l/-	トカハ* -		
13	LPLTP0409QSZZ		AC	DJ		С	Separator plate AND2 捌き	7° 1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-1-		
14	PSHEZ0515QSZZ		AG	DX		Α	Separator sheet 捌き	シート		
15	NRŌLR0130QSZZ		AL	EB		С	Transport roller 搬送	<u>0-5-</u>		
16	MSPBC02700S77		ΔB	וח		C	Separator plate spring 捌き	プレート		
10	M31 110027 0Q322		ΛD	DJ		U	גרייקע אין אין גער אין גער אין גער אין גער אין גער אין גער אין גער אין גער אין גער אין גער אין גער אין גער אין גער גער גער גער גער גער גער גער גער גער	ング		
17	NBRGZ0503FCZZ		AC	DJ		С	Bearing 軸受			
18	LSTPP0011QSZZ		AC	DJ		С	Resin E type ring 樹脂	EJング		
19	LRALP0009QSZ2		AP	EQ		C	Cassette rail R http:	l-∥R		
20	XBPS730P08KS0		AB	DD		C	Screw(3×8KS) Ľ X			
21	NKOM-0005QSZZ	↓	AC	DJ		C	Cassette guide collar htyl	<u>ה וֹרוֹ זר</u>		
22	NSFIZUU48QSPZ	$\vdash$	AF	DS		C	Cassette collar shatt カセット			
23		├	AK	DX		C C	2nd U-turn guide 2ndl	J 9-ンガイド		
24		──┼	AA AC	עט			Screw(4×12) L' λ			
20	PSHE703020977	┥		10		0	Rail R side sheet P	<u>ヽ ッ1ト ンート ト</u> D #/ドュ。 レ D		
20	1 3112203020322		A0	5		0	Rall R Side Sheet R V-NT	ベリイト ソート ベ 対击 田口 ニニー		
27	MSPRD0287QSZZ		AC	DJ		С	Paper reed sub roller spring 精報 77° li	1作用 9月11-7-		
28	NBOLP00870S77		AD	D.J		С	Paper feed sub roller 終紙	27 油助n_5_		
29	NSFTZ0101QSZZ		AC	DJ		Č	Paper feed sub roller shaft 給紙	補助[		
30	PSHEZ0356QSZ1		AE	DS		C	Plate cover sheet 7° k-	++++++++++++++++++++++++++++++++++++++		
31	PSHEZ0347QSZ1		AC	DJ		С	2nd rail R sheet 2nd	レール R シート		
33	LPLTM0396QSZ1		AD	DJ		С	Separator guide plate 捌き	ליים אין אין אין אין אין אין אין אין אין אין		
24			۸ A			C	Plate cover spacer 7° V-	トカハー		
34	F3FA20035Q322		AA	DJ		C	λ^° -	<del>"</del> -		
35	LX-WZ0064FCZZ		AA	DD		С	Push nut(M3) 7 ้ ๆง่	ュナット		
501	CCOVP0089RS55	-	AP	EQ		E	Plate cover unit [Missing parts code] 7° 1-	トカハ゛ーユニット		1st lot
500						_	Transport paper guide unit [Missing parts code] 搬送			
502	C CGIDM0068R555	-	AU	ΕZ		E	∧`-/\ 	- መግጉ		1st lot
503			ΔΝ	FG		F	L_ツト Concretion plate unit			
505	01 2 11 0 4 0 9113 5 1			20			Separation plate unit 为確	J V-LT-AL		
					-					
L		$ \square$								
L		↓								
L		$\vdash$								
<b>—</b>		┝──┼								
<u> </u>		├								
<u> </u>								i		
<u> </u>		──┤			<u> </u>					
		├								
<u> </u>		+ +								
<u> </u>		+ +			<u> </u>					
<u> </u>		+ +								
<u> </u>		<u>├</u>			<u> </u>					
<u> </u>										
		1 1			İ					
								_		
L										
L		$ \square$								
L		↓								
				1	1	1				
								1		
27 2nd 搬送部 (2nd paper transfer section)



# 28 2nd 駆動部 (2nd drive section)

NO.	PARTS CODE	Inter-	PRICE	RANK	NEW	PART	DESCRIPTION	TR No	Effective
		change	EX.	Ja.	MARK	RANK	BEGGINI HEIN		time
1	PCOVP0084QSZZ		AE	DJ		С	2nd bottom cover 2nd 底加 -		
2	CPWBF0228QSE1		AX	FG		Е	2nd cassette interface PWB 2nd カtット中継 基板		
3	XEBS730P08000		AC	DD		С	Screw(3×8) ະໍ້າ		
4	C DHA i - 0 5 9 7 Q S P 1	-	BF	GN		С	2nd multi step harness [Missing parts code] 2nd 多段ハーネス		1st lot
5	NBRGC0100FCZ1		AC	DJ		С	Bearing 6 ^* アリング 6		
6	MARMP0018QSZZ		AD	DJ		С	Body joint arm 本体連結7-ム		
7	C PCLC-0031QSZZ	-	AQ	EQ		В	2nd paper feed clutch(42T) [Missing parts code] 2nd 給紙ウラッチ (42T)		1st lot
8	XRESP40-06000		AA	DD		С	E type ring(E4) E リング		
9	XRESP50-06000		AA	DD		С	E type ring(E5) E リング		
10	MSPRT0203QSZZ		AC	DJ		С	Joint spring 連結スプリング		
11	NGERH0119QSZZ		AD	DJ		С	Gear(36T) ギャ		
12	NGERH1207FCZZ		AF	DS		С	Joint gear(40T) 連結ギヤ		
13	CDA i U 0 0 2 4 R S 5 8		AZ	FQ		Е	2nd lift up unit 2nd リフトアップュニット		
14	XEBS740P30000		AC	DD		С	Screw(4×30) ະັ λ		
15	XEBS740P12000		AA	DD		С	Screw(4×12) ະັນ		
17	C DHA i - 0 4 7 4 Q S P 1	-	BS	MW		С	LUM harness [Missing parts code] LUM ハーネス		1st lot
20	LPLTM0203QSZ1		AF	DS		С	Multi step drive plate 多段駆動プレート		
24	NGERH0121QSZZ		AE	DJ		С	Gear(20T/45T/26P) +* †		
25	NBLTT0029QSZZ		AG	DX		В	Vertical transport belt 縦搬送ベルト		
26	PCLC-0020QSZZ		AX	FG		В	Transport clutch 搬送クラッチ		
28	NPLYZ0027QSZZ		AD	DJ		С	Vertical transport pulley 縦搬送プーリー		
29	PSHEZ0250QSZZ		AB	DJ		С	Flange sheet 75ンジシート		
30	NRŌLP0008QSZZ		AD	DJ		С	Pulley 7° –IJ–		
31	PSHEZ0249QSZZ		AB	DJ		С	Flange sheet วรับบัญร์ ง-โ		
32	NBRGC0529FCZZ		AD	DJ		С	Bearing 軸受		
33	LPLTM0176QSZ1		AH	EB		C	Clutch earth plate クラッチアース板		
34	PSHEZ0556QSZZ		AC	DJ		С	Harness holder sheet ハー祝押えシート		

28 2nd 駆動部 (2nd drive section)



# <u>29</u> ידי (Lift up unit)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective time
1	CMŌTV0778FCE3		AU	ΕZ		Е	Lift up motor unit	リフトアップ゜モーター ユニット		
2	NGERH0158QSZ1		AE	DJ		С	Gear(29T/11T)	ギヤ		
3	LDAiU0024QSZ2		AF	DS		D	Lift up base	リフトアッフ゜ベース		
4	NGERH0102QSZZ		AD	DJ		С	Gear(53T/14T)	ギヤ		
5	NSFTZ0045QSZZ		AC	DJ		С	Shaft	シャフト		
6	NGERH0103QSZZ		AE	DJ		С	Gear(54T/13T)	ギヤ		
7	NSFTZ0044QSZZ		AC	DJ		С	Shaft	シャフト		
8	NSFTZ0060QSZZ		AC	DJ		С	Shaft	シャフト		
9	NGERH0104QSZZ		AE	DJ		С	Gear(13T/42T)	ギヤ		
10	NGERH0105QSZZ		AD	DJ		С	Gear(19T)	ギヤ		
11	PCOVP0061QSZ2		AH	DS		D	Lift up cover	リフトアッフ゜カハ゛ー		
12	MSPRD0208QSZZ		AC	DJ		С	1st cassette earth spring	1st カセットアース スフ゜リンク゛		
12	MSPRD0251QSZZ		AD	DJ		С	2nd cassette earth spring	2nd カセットアース スプリング		
13	MSPRC0263QSZZ		AC	DJ		С	Lift up spring	リフトアッフ゜スフ゜リンク゛		
	(Unit)									
001	CDA i U 0 0 2 4 R S 5 7		AZ	FQ		E	1st lift up unit	1st リフトアップ ユニット		
301	CDA i U 0 0 2 4 R S 5 8		ΑZ	FQ		E	2nd lift up unit	2ndリフトアッフ゜ュニット		

# 29 יד (Lift up unit)



# ③ MX-RP10 外装部 1(MX-RP10 Exteriors 1)

NO.	PARTS CODE	Inter- change	PRICE	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	GCAB-0075QST1		AR	EQ		D	Rear cabinet 後神ビ		
2	XEBS740P12000		AA	DD		С	Screw(4×12)  Ε΄ λ		
3	XHBS730P08000		AB	DD		С	Screw(3×8) Ľ λ		
4	LSTPP0016QSZZ		AC	DJ		C	Stopper Zhyn -		
5			AS	EQ		В	SPF paper feed clutch SPF 給紙/ラッヲ	_	
7	C CG i DM0 1 0 6 B S 5 3	-	BX	TF		F	Coupling pulley(39P)	- ) F	1st lot
. 8	XHBS730P10000		AD	DD		C	Screw(3×10)		101101
9	GCAB-0074QST1		AH	DX		D	Front cabinet 前ヤャビ		
10	MHNG-0021QSZZ		AX	FG		С	SPF hinge L SPF ビンジ L		
11	MHNG-0022QSZZ		AX	FG		C	SPF hinge R SPF ヒンジ R		
12	XWVS740-05000			עט		C	Washer キクワッシャ	_	
14			RD	GJ		C	Bearing ====================================		
15	PCUSS0022QSZ3		AW	EQ		C			
16	PSHEZ0413QSZZ		AD	DJ		С	OC mat sheet R OC マットシート R		
17	PSHEZ0077QSZ1		AE	DJ		С	OC mat sheet F OC סר אין אין אין אין אין אין אין אין אין אין		
18	XEBS730P08000		AC	DD		С	Screw(3×8) L <sup>*</sup> λ		
19	LPLTP0321QSZZ		AE	DS		С	Width detect sensor fixing plate		
							のriginal tray lower cabinet TLPD 原稿以/下地		
20	GCAB-0078QSI1		AV	FG		D			
21	L SOU - 0 0 3 9 Q S Z 1		AN	EQ		С	Original tray S 原稿IUIS		
22	MLEVP0098QSZZ		AC	DJ		С	Original detect actuator 原稿検知		
				<u> </u>		D	7/fil-9-		
23			AF AS	FO		F	PROTO SERSOF(GP1S73P) 7計センサー SPE VR PWR SPE VR 単振		
25	NGERP0168QSZZ		AD	DJ		Ċ	Pinion gear(36T) のアドマス 本位		
26	NGERR0169QSZZ		AE	DS		С	Width detect rack gear TLPD 幅検知ラックTLI	۶D	
27	MSPRC0250QSZZ		AC	DJ		С	Tray lock spring אין דער די דער דער די		
28	PTME-0271FCZZ		AD	DJ		C	Tray lock pawl ኑレብካንጠ		
29	XEPS730P08X00		AA	DD		C	Screw(3×8X) L' λ		
30			AD AW/	DJ		C	Regulation plate spring 現制板パフリンク		
32	LSOU 0038Q312		AV	FO		C C	Oliginal tray TLPD 原稿M11LPL の相比してLPD の目的になっていた。		
33	LPLTP0319QSN1		AG	DX		C	Regulation plate F TLPD 規制板 F TLP	D	
34	LPLTP0320QSN1		AG	DX		С	Regulation plate R TLPD	D	
35	DHA i - 0 4 6 8 Q S Z Z		AH	DX		С	Original tray harness 原稿トレイハーネス		
37	CCLEZ0020QS01		AK	EB		С	SPF glass cleaner SFP ガラスクリーナ	-	
501	CSOU-0037RS53		CD	UD		Е	Base tray unit(Include Block 31-501) パーストレイユニット ( ブ ロック 31-50	1	
502	CSOU-00388553		CE	ПН		F	合む)		
502				011			Onginal tray unit 原椅 F レイユニット		
┣			I						
┣──			<u> </u>						
<u> </u>									
<u> </u>		<u> </u>		<u> </u>	<u> </u>				
┣									
┣──			<u> </u>			$\vdash$			
<u> </u>									
<u> </u>		<u> </u>		<u> </u>	<u> </u>				
<u> </u>		L		L	L				
┣──			<u> </u>						
<u> </u>			<u> </u>						
<u> </u>		<u> </u>		<u> </u>	<u> </u>				
<b> </b>									
┣──									
<b>├</b>			<u> </u>						
		1	1	1	1				
				I					

③ MX-RP10 外装部 1(MX-RP10 Exteriors 1)



# ③ MX-RP10 外装部 2(MX-RP10 Exteriors 2)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective time
1	CPWBF0139QSE1	-	BA	FX		Е	SPF interface PWB	SPF 中継基板		
2	XHBS730P08000		AB	DD		С	Screw(3×8)	t <sup>*</sup> ス		
3	DHA i - 0 4 4 8 Q S Z Z		AV	FG		С	SPF interface harness	SPF 中継ハーネス		
4	LPLTM0111QSZZ		AC	DJ		С	Reinforce plate earth plate	補強板アース板		
5	<u>C</u> RPLU-0011QSZ2	-	BA	FX		В	Gate solenoid [Missing parts code]	<u> </u>		1st lot
6	PSP0-0023QSZZ		AB	DJ		C	Sound proof sponge	消音スポンジ		
7	PSPŌ-0004QSZZ		AB	DJ		С	Delivery gate sound proof sponge	排紙ゲート		
0			A1	ED		C	0(TD0 40040)	消音なシシ		
0	RCOHI 00201022	-	AL	LD	-	C	Core(TRC-16813)			
9	MSPRD0342QSZZ		AD	DJ		С	Delivery gale spillig	19F 市以り 一 ト フフ゜IIい/5゛		
10	MLEVP0036QSZZ		AD	DJ		С	Delivery gate lever	<u> 抹紙ゲートレバー</u>		
11	MLEVF0093QSZZ		AE	DJ		С	Pressure release lever	圧解レバー		
12	XBBS730P05000		AA	DD		С	Screw(3×5)	L' A		
13	DHA i - 0 3 8 8 QSP Z		AE	DS		С	Delivery sensor harness	排紙センサーハーネス		
14	MSPBD02110S77		AC	Ы		C	Delivery sensor ACT spring	排紙センサー		
17	10011100211Q022		7.0	00		Ŭ		ACT スプリング		
15	VHPSG2481++-1		AE	DS		В	Photo sensor(SG2481)	フォトセンサー		
16	MLEVP0092QSZZ		AC	DJ		С	Delivery sensor ACT lever TLPD	排紙センサー		
17	XRESR20-04000	-	A A		-	C		ACT UN - TLPD		
18	NROL P00110577			וח		C	E type ring(E2)	ヒリンク せい 紅 公子 香わっ ニ		
10		-	AD	00		0	Delivery anongo I PD	排航化到1-7- 時日日 - **いい		
19	PSPO-0020QSZZ		AB	DJ		С	Delivery shouge FLD			
		1	A.D.	<u> </u>		~	Delivery follower sound proof sheet	排紙従動		
20	PSHEZ0285QSZZ	1	AB	DJ		C		消音シート		
21	NSFTZ0013QSP1	1	AF	DJ	İ 👘	С	Delivery sub shaft	排紙従動軸		
_ 22	PSP0-0003QSZZ		AC	DJ		С	Sound proof sponge	消音スポンジ		
22	LHLDZ0101QSZZ		AE	DS		С	Pressure release holder	圧解ホルダー		
23	😋 LHLDZ0101QSZ1	1	AE	DJ		С	Pressure release holder	圧解ホルダー		09/12
24	MSPRD0305QSZZ		AC	DJ		С	Delivery sub spring	排紙従動		
						-		<u> えフ゜リンク゛</u>		
25			AC	DJ		C	SP pin(2×10)	SP L'>		4-11-1
20	C NSF120072QS22	-		EQ	-	C C	Pressure release shaft TLPD [Missing parts code]	<u> 上解軸 TLPD</u>		1st lot
21	NBRGM0501EC77		AA	וח		C	E type ring(E5)	E 1)2/1 計平		
20	NSETZ00090SP1		AF	DJ D.I		C C	Transport sub shaft	聉文 迦洋従動軸		
30	NBOL P1517FC77		AA	D.J		B	Transport sub roller	掀还1处到1轴 搬送従動□-5-		
						-	Read front sub spring	<u>减区促到1</u> 7		
31	MSPRP0306QSZZ		AC	DJ		С		えフ°リンク`		
32	LPLTM0316QSZZ		AH	DX		С	Base trav reinforce plate	ベーストレイ補強板		
33	XEBS730P08000		AC	DD		С	Screw(3×8)	Ľλ		
34	MSPBC03070S71		AC	Ы		C	Read front follower earth spring	読取前従動アース		
04	M81 118 8 8 8 7 8 8 2 1		7.0	00		Ŭ		<b>スプリング</b>		
35	MSPRP0123QSZZ		AD	DJ		С	Transport sub spring	搬送従動		
		-						スフ リンク		
36	MSPRT0308QSZZ		AC	DJ		С	Delivery sub earth spring	排紕従動/−λ フプリン.ガ		
37	PSHE704360S77			Ы		C	Pood front about	は の お い し		
38	PSHEZ00690SZZ	1	AF	D.J		C	Base trav sheet			
39	PSHEZ0439QSZ1		AD	DJ		C	Delivery gate sheet	非新ゲートシート		
40	LPLTP0117QSZZ	1	AM	EG		C	Delivery gate	排紙ゲート		
41	NBRGP0041GCZZ	1	AD	DJ	1	С	Bearing	軸受		
42	PRNGP0090FCZ1		AB	DJ		С	Resin E ring(E5)	樹脂Eリング		
43	LSOU-0037QST1		BD	GJ		С	Base tray TLPD	^ - ストレイ TLPD		
44	PSHEZ0459QSZZ		AC	DJ		С	Delivery gate sheet lower	排紙ゲートシート下		
<b>_</b>		1	05			_	Base tray unit(Include Block 30-501)	^`-ストレイユニット		
501	CSOU-0037RS53	1	CD	UD		E		( プロック 30-501 金まい)		
	1							呂心)		
	1									
<u> </u>	1									
	1	<u> </u>								
		1								
		1			1					
L		<u> </u>			L					
<u> </u>		<b> </b>								
<u> </u>										
<u> </u>		1								
	1	<u> </u>								
		1								
	1	1			1					

③ MX-RP10 外装部 2(MX-RP10 Exteriors 2)



## 22 MX-RP10 給紙部 (MX-RP10 Paper feeding section)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	٦	TR No.	Effective time
1	GCAB-0076QST1	Ū	AN	EG		D	Open/close cabinet 開閉キャ	۲Ľ		
2	NGERH0166QSZZ		AC	DJ		С	Paper feed shaft gear(20T) 給紙軸	1411		
3	PCLC-0316FCP1		AP	EQ		В	Torque limiter  hルクリミッ	ッター		
4	MLNKP0001QSZZ		AD	DJ		С	Pick up link TLPD 呼込み	トリンク TLPD		
5	MSPRD0309QSZZ		AC	DJ		С	Pick up arm spring 呼込み	ку−Д **		
6	NGEBH01670S77		AD	D.J		С	Paper feed drive dear(32T)  谷紙取	/ R		
7	NBRGM0096FCZ1		AC	DJ		Č	Haper reced drive gear(521) 相截連 相較	- 30/1 1		
9	XRESP50-06000		AA	DD		С	E type ring(E5) E שולה E נוסא ביו ביו ביו ביו ביו ביו ביו ביו ביו ביו			
10	NSFTB0075QSZ1	-	AF	EG		С	Paper feed roller shaft [Missing parts code] 給紙中	-ラ-軸		1st lot
11	XPSSP20-07000		AA	DD		С	Spring pin(φ2-7)	ゲピン		
12			AC	DJ		C	Paper feed earth plate 給紙7-	-ス板		
13	XEBS/30P08000		AC	טט		C	Screw(3×8) ビス	27 14		
14	MSPRD0314QSZZ		AD	DJ		С		<sup>件 IF IF</sup> IF IF IF IF IF IF IF IF IF IF IF IF IF		
15	C NSFTZ0074QSZ2	-	AM	EB		С	Paper feed shaft [Missing parts code] 給紙入	力軸		1st lot
17	NBRGC0018QSZZ		AD	DJ		С	Bearing(\oheta8) 軸受			
18	NPLYZ0033QSZZ		AD	DJ		С	Coupling pulley(39P) ກາງ ປະ	ック゛フ゜ーリー		
19	PCLC-0023QSZZ		AS	EQ		В	SPF paper feed clutch SPF 終	合紙クラッチ		
20	MARMMO0470877		ΔF	Ы		C	U-turn paper guide arm R U 9-2	+* / L*		
20				00		U	7-1, R	-// 1r		
21	LSTPP0016QSZZ		AC	DJ		С	Resin E ring(E5) 樹脂 E	リンク゛		
22	DHA i - 0 3 9 0 Q S Z Z		AC	DJ		С	U-turn earth harness U 9-27	アースハーネス		
							U-turn paper guide TLPD U ターン			
23	PGiDM0105QSZ1		AQ	EQ		С	^° −/\° −	-ガイド		
<u> </u>							IL turn nanor quido cobinet			
24	GCAB-0077OST1		AP	FQ		D	U-turn paper guide cabinet $U = 0$	-ガィド		
2.			/ 11			5	±++E*	N 11		
26	MSPBP03110S77		۸C	ы		C	PS sub tension spring PS 従到	動		
20	M311110311Q322		70	00		U	7ンションス	<b>スプリンク</b> ゙		
07			<u>۸</u> -			~	U-turn paper guide lock pawl TLPD U ターン			
27	PIME-0029QS11		AE	DJ		C		-ガイド TLDD		
							Liturn paper quide lock spring TLPD	ILPD		
20	MCDDD00100077			ы		~		-ታ 1ኑ		
20	MSPRD0310QSZZ		AC	DJ		C	םילאסים מיניים באיניים br>באיניים באיניים	リンク		
							TLPD			
29	NROLP1517FCZZ		AA	DJ		В	Transport sub roller 搬送従	生動ローラー		
30	NSFIZUUU9QSPI		AE	DJ		C	I ransport sub shaft 搬运征	E動軸		
31	MABMP00460SZZ		AD	D.J		С		-ガィド		
						-	7-4 F			
32	PCOVP0094QSZZ		AD	DJ		С	Maintenance cover メンテナンス	スカハ゛ー		
52	COVP0094QSZ1	1	AD	DJ		С	Maintenance cover メンテナンス	スカハ゛ー		09/12
34	CSFTB0073QS01		AF	DS		Е	Pick up roller shaft ASS'Y 呼び込	みローラー軸		
35	MARMP00440S71		ΔF	DS		C		217-1		
	LFRM-0069QSZ1		AQ	EQ		C	Paper feed frame TLPD 給紙70			
36	C LFRM−0069QSZ2	1	AQ	EQ		С	Paper feed frame TLPD 給紙70	V-4 TLPD		09/12
37	NCPL-0049FCBZ		AT	ΕZ		С	1way coupling 1way t	カッフ゜リンク゛		
38	NPLYZ0035QSZZ		AD	DJ		С	Paper feed roller pulley(16P) 給紙印	-ラ-プ-リ-		
39	C NROLR0166QSZZ	-	AX	FG		B	Paper feed roller [Missing parts code] 給紙中	-7-		1st lot
40	NHULH1542FCZZ	<u> </u>	AH	אט		В	Pick up roller 呼込み	×µ−7−		
41	NPLYZ0034QSZZ		AD	DJ		С	ーPick up roller pulley(16P) 呼込み っ°_=  -	×µ−7−		
42	NBLTT0033QSZZ		AF	DS		В	Drive belt 取動ベ	N F		
43	VHPGP1S73P+-18		AF	DS		В	Photo sensor(GP1S73P) 771427	<del>y</del>		
44	DHAi-0469QSZZ		AG	DX		С	Paper feed unit harness 給紙1二	ニットハーネス		
45	PSHEZ0444QSZZ		AE	DS		С	Pick up sheet 呼び込	みシート		
46	MLEVP0097QSZZ		AC	DJ		С	Original detect actuator 原稿検	知		
17				рі	<u> </u>	C	Stoppor	-4-		
47	MLEVP00960877		AC	D.1		C C	Stopper Zhyn - Z	- - 解除しバ-		
49	MARMP0045QSZZ		AC	DJ		Č	Stopper arm 2km/° -	-7-4		
50	MSPBD02120977		<u>م</u>	יח	l	C	JAM release spring F JAM 解	<b>解除</b>		
50	WIGE HUUSI 3Q8ZZ		AC	DJ		C	גדי "גד	۴F		
51	PSHEZ0407QSZZ		AB	DJ		C	PS guide sheet PS h 1	<u>1ドシート</u>		
52	VHPSG2481++-1		AE	DS		В	Photo sensor(SG2481) 77+25	# דיז זי		
53	LHLDZ0153QSZZ		AC	DJ		С	っつて pick up sub noider SPF 吗 がおいます	ナ14 <sup>、</sup> -		
54	PMLT-0095QSZZ		AB	DJ		С	ー 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一	,, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		
						_	U-turn paper guide unit U ターン			
501	CCAB-0077RS53		BP	LP		Е	∧° −/\° −	-ガイド		
<u> </u>		L			L		בבאל			
┣						$\left  \right $				
┣──										
<b> </b>										
L				l						

32 MX-RP10 給紙部 (MX-RP10 Paper feeding section)



PRP03932

# ③ MX-RP10 搬送部 1(MX-RP10 Transport section 1)

NO.	PARTS CODE	Inter-	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION		TR No.	Effective time
1	PGiDM0107QSZ1		AQ	EQ		С	Paper feed guide	給紙ガイド		
2	PSHEZ0452QSZZ		AF	DS		С	Front separator sheet	前捌きシート		
4	PSHEZ0423QSZZ		AP	EQ		С	Separator sheet	捌きシート		
5	LPLTP0328QSZZ		AC	DJ		C	SPF separator plate	<u>SPF 捌き板</u>		
6	MSPRC0321QSZ1		AB	DJ		C	Pressure spring	<u> </u>		
			AC			C	Sound proof sheet	<u> 前別さ泊音シート</u>		
9	2HBS730P08000		AD AB			C	Sound proof plate	月首板		
12			AR	FO		B	Sciew(3×8)	[ 人		
13			AP	FO		B	PS roller SPF			
14			AR	FQ		B	Read front roller			
15	PSHEP0647QSZZ		AD	DJ		C	White sheet AN2R	<u> 白マイラ-</u> AN2R		
16	LPLTM0325QSZZ		AH	DX		С	Transport plate	<u>出代力</u> ////////////////////////////////////		
47	MODDO000077					0	Delivery paper guide spring R	排紙が小		
17	MSPRC0360QSZZ		AC	DJ		C		えつ <sup>°</sup> リンク <sup>°</sup> R		
18	DHAi-0467QSZZ		AP	EQ		С	RSPF harness	RSPF ハーネス		
19	RDTCT0006QSPZ		AX	FG		В	Paper feed in detect sensor	入紙検知センサー		
20	PTME-0030QSZZ		AC	DJ		С	Open/close lock pawl TLPD	開閉ロック爪 TLPD		
21	MSPRC3356FCZZ		AA	DJ		С	Lock spring	ロックスフ゜リンク゛		
22	NBRGM0501FCZZ		AB	DJ		C	Bearing	軸受		
23	XRESP50-06000		AA	DD		C	E type ring(E5)	E リンク*		
24	XPSSP20-09000		AA	טט		C	Spring pin( $\phi$ 2-9)	<u> スブリングビン</u>		
25		+	AE	DJ			PS pulley	PS7-J-	ļ	
26		+	AA	עט			Fiange Sneet DUP2	<u> ノフンソート DUP2</u>		
21	XEBS730P08000	+	AC	70		C		<u>」フソヨノ小ルグ ニ ト</u> ド フ		
20	NKOM-00070977	+	AC	יח		C		<u>し 人</u> テンションフロ		
- 29		├		5		U	Rook sensor actuator TLPD	<u>」ノンヨノコロ</u> つ゛ックわい <del>ル</del> ー		
30	MLEVP0095QSZZ		AD	DJ		С	DUUR SEIISUI duludiui ILFD	70411-4- TI PD		
32	VHPSG2481++-1		AE	DS		В	Photo sensor(SG2481)	<u>,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,</u>		
33	XEBS740P14000		AB	DD		C	Screw(4×14)	L' A		
0.4	MODDO04500077					0	Book sensor spring	フ゛ックセンサー		
34	MSPRC0153QSZZ		AB	DJ		C		<b>スプリング</b>		
35	XWVS740-05000		AA	DD		С	Washer	キクワッシャー		
36			AC	D.I		C	Book sensor fixing plate B1A	フ゛ックセンサー		
00			///	00		Ŭ		取付板 B1A		
37	JKNBZ0009QSZZ		AE	DJ		D	JAM release knob(24P)	JAM 解除/ブ		
38	NBLTT0036QSZZ		AF	DS		В	Belt(B79MXL4.0)	<u> ^                                   </u>		
39	NBRGC0017QSZZ		AC	DJ		C	Bearing	軸受		
40			AC	DJ		C C	Tension spring F			
41			AR AR	EO		B	Revers gate plate	<u> </u>		
42	NITO EITO 0 97 QOZZ			LQ		Б	Delivery paper folier Paper feed paper guide reinferee plate	排术口-7- 给纸		
43	LPLTM0326QSZZ		AM	EG		С	Paper leeu paper guide territorce plate	<b>ホ</b> ロ πιζ ヘ゜ーハ゜ーカ゛イト゛		
						-		補強板		
44	PBRSS0008QSZ1		AH	DX		В	Discharge brush	除電ブラシ		
45			A11	E7		C	Transport R paper guide	搬送 R		
43	FGTDM0100Q321		AU	LZ		C		^゚-パ-ガイド		
						_	Paper feed paper guide cushion R	給紙		
46	PSHEZ0454QSZZ		AB	DJ		С		^゚-パ-ガイド		
								<u>779932 R</u>		
47	PSHE704550977			ים		C	Paper teed paper guide sound proof cushion	稻粃 ペーパーガ/レ゙		
4/	F3NE20405Q822		AD	DJ		C		ハ ーハ ール 1ト 当 立ちょう・		
		+ +					Delivery paper quide spring	<u>/日日フッフショノ</u> 排紙		
48	MSPBC00630SZZ		AB	D'I		С	Denvery paper guide spilling	」ファ //JLL ヘ゜ー/ヽ゜ーカ゛イ L゛		
				20		Ĩ		えフ <sup>°</sup> リンク`		
49	LX-WZ5002BCZZ	<u>†</u> †	AA	DD		С	Poly slider(6.2-12-0.5)	ポリスライタ゛ー		
							SPF Transport unit [Missing parts code]	搬送ユニット RSPF		
501	C) CG i DM0 1 06 BS 5 3		BX	TF		F	(Include Block 34-501,Without No.18)	( ブロック 34-501		1st lot
301			DA			-		含む。		i at lUt
L								No.18 除く)		
L										
L		$\vdash$								
		+								
┣───		+							-	
<u> </u>		+								
		+							-	
		+ +								
<u> </u>		+								
<u> </u>		+ +								
<u> </u>										
1					_					

# ③ MX-RP10 搬送部 1(MX-RP10 Transport section 1)



# 34 MX-RP10 搬送部 2(MX-RP10 Transport section 2)

NO.	PARTS CODE	Inter- PRICE	RANK	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	RMŌTS0043QSPZ	BG	GT		В	SPF motor TLPD SPF t-9- TLPD		
2	DHAi-0467QSZZ	AP	EQ		С	RSPF harness RSPF ハーネス		
3	PTPE-0018QSZZ	AC	DJ		С	Motor earth tape $\overline{t}-9-7-3\overline{7}-7^{\circ}$		
4	XEBS730P08000	AC	DD		C	Screw(3×8) Ľ X		
6 7	<u> </u>	AR	EQ		В	Pressure release solenoid 上解/レ/イト		
8	XBESP40-06000	AA			C C	Sound proof sponge 月日本小グ		
9	PSHEZ0414QSZZ	AB	DJ		C	Flange sheet 7522 -		
10	NBLTT0034QSZZ	AF	DS		В	Belt(48S2M244)		
11	NGERH0170QSZZ	AD	DJ		С	Gear(48T/43P) + * *		
12	NBRGM0501FCZZ	AB	DJ		С	Bearing 軸受		
13	NGERH0116QSZ1	AD	DJ		C	Gear(48T/25P) + * *		
14	XEPS/30P08X00	AA			C	Screw(3×8X) L <sup>*</sup> X		
15		AK				Gear(48T) F 1		
10	NPL YZ00190577		וס		C	Spring pin(\$2-9)		
18	NBLTT0035QSZZ	AE	DS		B	PS pulley PS 7 - 7-		
19	PSHEP3029FCZZ	AA	DD		C	Flange sheet(DUP2) 75.55		
20	XRESP50-06000	AA	DD		С	E type ring(E5) E リング		
21	MSPBP03120S77	AD	D.I		С	U-turn earth spring U ターン		
		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	50		Ļ	7-ススプリング		
22		AB	עט ן	<u> </u>		Screw(3×8) L' X		
23		AC	DJ			Bearing miley DS ters in the		
24	NPLYZ0018QSZZ	AE	DJ		С	ר איז די די די די די די די די די די די די די		
25	PCLC-0032QSZZ	AX	FG		В	PS clutch SPF PS h5w4 SPF		-
26	NKOM-0007QSZZ	AC	DJ		С	Tension roller דעניליל דעניגיע		
27	MSPRT0317QSZZ	AC	DJ		С	Tension spring R รับวัลบังวิ ไม่น้ำ R		
28	LHLDZ0103QSZZ	AC	DJ		С	Tension holder R รับบ่านได้ - R		
29	LPLTM0322QSZZ	AF	DS		С	Transport earth plate 搬送7-2板		
31	LPLTM0323QSZ1	AG	DX		C	Motor fixing plate モーター取付板		
32	XBBS/30P05000	AA	טט		C	Screw(3×5) E X		
34	MSPRC0418QSZZ	AC	DJ		С	PS Brake spring AN2R PS 7 U-F		
35	XWHS760-08115	AA	DD		С			
07			55		0	SPF motor cooling sheet SPF t-9-		
37	PIPE-0069QSZZ	AC	DJ		C	たいで、 放熱シート		
38	LX-WZ5002BCZZ	AA	DD		С	Poly slider(6.2-12-0.5) * "リスライダ-		
504		DY	-		_	SPF Transport unit(Include Block 33-501) 搬送ュニット RSPF		
501	C CGIDM0106RS53	- BX			E	[Missing parts code] ( 7 ロック 33-501		1st lot
<u> </u>			<u> </u>					
┣───			<u> </u>					
								<u> </u>
			<u> </u>	<u> </u>				
			1				l	
<u> </u>			<u> </u>					
			<u> </u>					
			<u> </u>					
			L					
L								
<u> </u>								
			<u> </u>					-
			1	1				

34 MX-RP10 搬送部 2(MX-RP10 Transport section 2)



### ③ MX-TR11 第二排紙ュニット (MX-TR11 2nd delivery paper unit)

NO		Inter-	PRICE	RANK	NEW	PART	DECO			Effective
NO.	PARTS CODE	change	Ex.	Ja.	MARK	RANK	DESC	RIPTION	TR NO.	time
1	XHBS740P10000		AA	DD		С	Screw(4×10)	Ľ٦		
	CPL TM0 2160501		АН	лх		C	DID rail sub plate	DID V-N		
2	01 2 1 1 1 0 0 0 0 1		/ 11	DA		Ŭ		補助プレート		
-	CPL TM0 2160502	1	АН	лх		С	DID rail sub plate	DID V-IV		09/08 Mid
			/ 11	BA		Ŭ		補助プレート		00,00 1114
3	PBRSR0021QSZ1		AG	DS		В	Discharger brush S	除電ブラシS		
4	PBRSR0020QSZ1		AH	DX		В	Discharger brush L	除電ブラシ L		
5	LFRM-0047QSZZ		AG	DX		D	Delivery frame	排紙フレーム		
6	LFRM-0058QSZ1		AG	DX		D	Delivery frame R	排紙フレーム R		
7	MSPRT0229GCAZ		AC	DJ		С	FU spring R	FU スプリング R		
8	NROLP1122FCZZ		AF	DS		С	PS upper roller	PS 上ローラー		
9	NRÖLR0056QSZ1		AN	EQ		С	Delivery roller	排紙ローラー		
10	DHA i - 0 5 9 2 Q S P Z		AH	DX		С	2nd delivery harness	2nd 排紙ハーネス		
11	MSPRD0218QSZ1		AE	DS		С	Delivery earth spring	排紙アーススプリング		
12	VHPGP1SQ44S-18		AK	EB		В	Photo sensor(GP1SQ44S)	フォトセンサー		
13	VHPGP1SQ73P-18		AF	DS		В	Photo sensor(GP1SQ73P)	フォトセンサー		
15	QSW-B0017QSZZ		AF	DS		В	Tray detect switch	トレイ検知スイッチ		
16	NBRGM0501FCZZ		AB	DJ		С	Bearing	軸受		
17	NGERH0111QSZZ		AC	DJ		С	Drive gear A(25T)	駆動ギヤA		
18	NGERH0110QSZZ		AE	DJ		С	Idle gear A(29T)	711 N+ + A		
19	NGERH0112QSZZ		AC	DJ		С	Drive gear B(25T)	駆動ギヤB		
20	NBRGY2122SCZZ		AB	DD		С	Transport roller bearing	搬送ローラー軸受		
21	PG i DM0 1640977		A0	FO		C	Delivery lower paper guide	排紙下		
21	FGTDM0104Q322		AQ	LQ		C		へ <sup>。</sup> ーパ <sup>。</sup> 一力 <sup>*</sup> イト <sup>*</sup>		
22	NROLR0051QSZ1		AL	EB		С	DUP delivery roller	DUP 排紙ローラー		
23	LBSHZ0303FCZZ		AC	DJ		С	M bushing C	Μ ブッシンク゛ Ϲ		
24	XRESP40-06000		AA	DD		С	E type ring(E4)	Ε リンク		
25	MLEVP0067QSZ2		AD	DJ		С	Delivery actuator	排紙アクチュエーター		
26	XRESP50-06000		AA	DD		С	E type ring(E5)	Ε リンク		
27	XHBS730P08000		AB	DD		С	Screw(3×8)	۲ <sup>°</sup> ス		
28	XHBS740P10000		AA	DD		С	Screw(4×10)	۲ <sup>°</sup> ス		
29	NSFTZ0117QSZZ		AE	DS		С	Joint idle shaft	連結アイドル軸		
30	PCLR-0015QSZZ		AC	DJ		С	21 collar	21 カラー		
31	NGERH0230QSZZ		AC	DJ		С	Gear(21T)	ギャ		
32	XBPS740P08KS0		AB	DD		С	Screw(4×8KS)	۲̈́λ		
33	C PSHEP0660QSZZ	-	AB	DJ		С	Harness protect sheet	[Missing parts code] ハー衣保護マイラー		1st lot
	(Unit)						· F			
004			PC	0		Е	2nd delivery unit(Without No.28)	[Missing parts code] 2nd 排紙ュニット		1 at lat
901		-	БС	GJ		E		(No.28 除く)		TST IOT

③ MX-TR11 第二排紙ュニット (MX-TR11 2nd delivery paper unit)



36 MX-TR11 ジョブセパレーターユニット (MX-TR11 Job-separater unit)

NO		Inter-	PRICE	RANK	NEW	PART				Effective
NO.	PARTS CODE	change	Ex.	Ja.	MARK	RANK		DESCRIPTION	TR NO.	time
1	C LSOU-0034QST3	-	AY	FQ		D	2nd delivery tray	[Missing parts code] 2nd 排紙N/		1st lot
2	GCŌV-0042QST1		AK	DX		D	Rail dummy cover	レールタ゛ミーカハ゛ー		
3	MLEVP0066QSZZ		AD	DJ		С	Actuator	アクチュエーター		
4	XEBS730P08000		AC	DD		С	Screw(3×8)	ב <sup>*</sup> א		

36 MX-TR11 ジョブセパレーターユニット (MX-TR11 Job-separater unit)



# ③ 梱包及び付属品 (Packing material & accessories)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
	T i NSE 2 0 2 6 QSZZ		AY	FQ		D	Operation manual [MX_M260/M210 English(North America)] 即把詳明書		
	T i NSE 2 0 7 8 QSZZ		BD	GN		D	Operation manual		
		_	BG	GX		D	[English(Except North America,U.Kingdom)] 取扱說明書 Operation manual [Missing parts code]		1 et lot
		-	60	0,		D	[MX-M Series English(U.kingdom)] 取扱説明書 Operation manual [Missing parts code]		151101
	C T i NSG2088QSZZ	-	BD	GN		D	[German(Germany,Switzerland)] 取扱説明書		1st lot
	T i NSE2027QSZZ		AY AK	FQ DX		D	Operation manual [Japanese] 取扱説明書 Operation manual(Copy/SPI C install guide) [English] 取扱説明書		
	T i NSE 2 0 8 3 QSZ Z		AY	FQ		D	Operation manual(Copy/PCL install guide)		
							[English MA-M260N/M310N] 取扱説明書 Operation manual(Copy/SPLC install guide)		
	C T i NSG2089QSZZ	-	AR	EQ		D	[Missing parts code] [German/Germany Switzerland)] 取扱説明書		1st lot
	T i NSJ2032QSZZ		AK	EB		D	Operation manual(Copy/SPLC install guide)		
	T : NO 100000077			50			[Japanese MX-M260FG/M310FG] 収扱說明書 Operation manual(Copy/SPDL install guide)		
2	TINSJ2033QSZZ			EQ		D	[Japanese MX-M260FP/M310FP] 取扱説明書		
			AVV	DX		D	Operation manual(FAX) [Japanese] 取扱説明書 CD-ROM [MX-M260 North America] CD-ROM		
			Δι	FR		n	CD-ROM [Missing parts code]	1	1et lot
		-					[MX-M Series(Except North America)] CD-ROM		131101
1			AL AI	EB			CD-RUM(PDL DISK1) [MX-M260N/M310N] CD-ROM	1	
1	CDSKA02670S31			FR			CD-ROM [MX-M260N/M310N] CD-ROM	+	
1	CDSKA0268QS31		AL	EB		D	CD-ROM IMX-M260F9/M310F91 CD-ROM	1	
1		1				-	Installation report card	1	
	TCAD20049QS22		AH	DX		D	(Germany,Switzerland,Europe,East Europe) 設置報告書		
	TCADS1693FCZZ		AA	DS		D	Installation report card (Japan) 設置報告書		
	TCADZ0098QSZZ		AF	DS		D	Warranty card SUK (U.kingdom) 保証カードSUK		
	CCADZ1518FC01		AB	DJ		D	Maintenance card EX [MX-M260/M260N/M310/M310N.AR-5726/5731] メンテナンスカート EX		
	CCADZ1561FC01		AK	DX		D	Maintenance card J		
	TGANE1001QCZB		AC	DJ		D	SCA warranty (Australia, New Zealand) SCA 保証書		
	QCNWG0013QSZZ		AF	DS		С	Line cable (Japan) ラインケーフ <sup>*</sup> ル		
	TKE i A0001QSZZ		AE	DJ		D	Counter contract card (Japan) かッター契約書		
7	SPAKA0484QSZZ		BE	GN		D	Bottom packing case (Japan) 底ケース		
8	LX-BZ0015QSPZ		AF	DS		C	2/3 fixing screw 2/3 固定ビス		
9	TCADZ0010QSZZ		AC	DJ		D	Fixing screw caution card 固定 A 注意から		
10	LHLDW1226FCZZ		AB	DJ		С	Turn fastener ターンファスナー		
11	TCADZ1275FCZZ		AB	DJ		D	Cassette rotation tag 加小回転タグ		
12	SSAKA3001CCZZ		AA	DD		D	Vinyl bag(140×360) (North America, Japan, Argentina) ポリ袋		
13	SSAKA5003CCZZ						Vinyl bag(140×260) (Except North America, Japan) 市 1没		
14	SPAKA0134BSZZ		AL	EB		D	VIIIyi bag(200×360) 小 小衣		
<u> </u>			A.D.			0	AC cord band (Except North America, Japan, India,		
15	LBNDC0075FCZZ		AB	DJ		C	Special country, Philippines, Malaysia, Singapore) AC コート・ハ・ント・		
	UBNDA0001FCZZ		AA	DD		С	AC cord band (India,Special country,,Malaysia, Singapore,Argentina) AC コート・パント・		
17	SPAKA3914FCZZ		AC	DJ		D	DV sleeve (Japan) DV און-ד`		
19	TLABZ0106RSZZ		AF	DS		D	LAG 4 label (Argentina) LAG4 7 <sup>^*</sup> l		
<b> </b>									
┣──			<u> </u>		<u> </u>			+	
<u> </u>								1	
F								1	
<u> </u>								<u> </u>	
┣—									
<b> </b>									
<u> </u>		1							<u> </u>
<u> </u>	1	1	<u> </u>					1	
L									
<u> </u>			<u> </u>						
┣								+	
┣──			<u> </u>		<u> </u>			-	
<u> </u>			<u> </u>		1			1	
<u> </u>		1						1	
								<u> </u>	
┣								+	
┣──								+	

③ 梱包及び付属品 (Packing material & accessories)



## 38 MX-VR10 梱包及び付属品 (MX-VR10 Packing material & accessories)

NO.	PARTS CODE	Inter-		RANK	NEW		DESCRIPTION	TR No.	Effective
		change	EX.	Ja.	WARK	RAINK			ume
1	GCŌV-0075QSZ1		BB	GD		D	OC cover OC h/ -		
2	GCŌV-0247FCZZ		AS	EQ		D	OC stocker OC ストッカー		
3	PCUSS0032QSZZ		AW	FG		С	OC mat OC २७२		
4	MHNG-0025QSTZ		BC	GD		С	OC hinge R OC ヒンジ R		
5	XWVS740-05000		AA	DD		С	Washer ワッシャ		
6	XEBS740P12000		AA	DD		С	Screw(4×12)		
7	MHNG-0026QSTZ		BC	GD		С	OC hinge L OC センジ・L		
14	SSAKH3012KCZZ		AD	DJ		D	Vinyl bag ポリ袋		
	(Unit)								
901	C C C O V - 0 0 7 5 R S 5 3	-	BK	HC		E	OC cover unit OC h/ -1=yk		

38 MX-VR10 梱包及び付属品 (MX-VR10 Packing material & accessories)



#### 39 MX-RP10 梱包及び付属品 (MX-RP10 Packing material & accessories)

NO.	PARTS CODE	Inter-	PRICE	RANK	NEW	PART	DESCRIPTION		TR No.	Effective
		change	EX.	Ja.	WARK	RAINK	BEGGIN HOI		-	ume
1	SPAKA0088QSZZ		AE	DS		D	Protect packing sheet 保調	護シート		
2	CF i X - 0 0 1 2 R S 5 4		AU	ΕZ		E	SPF glass fixing plate unit SP	PF ガラスユニット		
3	SSAKZ0004QSZZ		AA	DD		D	Vinyl bag(80×450) * * ا	袋		
6	SSAKH3012KCZZ		AD	DJ		D	Vinyl bag 👘 🕯 ا	袋		
7	SPAKA0488QSZZ		BK	HG		D	Add R 71	Γ R		
9	SPAKA0487QSZZ		BF	GN		D	Add L 71	Ĺ		
10	LSOU-0041QST1		AP	EQ		С	Middle tray 中	間トレイ		
11	SSAKA1341QCZZ		AA	DD		D	Vinyl bag(180×380) * * ا	袋		
12	SPAK-545ECCZZ		AA	DD		D	Vinyl bag 静能	電ポリ袋		
14	SPAKA0622QSZZ		AG	DX		D	OC mat fixing add OC	こマット固定材		
15	CCLEZ0020QS01		AK	EB		D	SPF glass cleaner SP	PF ガラスクリーナー		
16	TLABS3760FCZZ		AC	DJ		D	CE label CE	57°N		

39 MX-RP10 梱包及び付属品 (MX-RP10 Packing material & accessories)



## 個 MX-TR11 梱包及び付属品 (MX-TR11 Packing material & accessories)

NO.	PARTS CODE	Inter- change	PRICE Ex.	RANK Ja.	NEW MARK	PART RANK	DESCRIPTION	TR No.	Effective time
1	XEBS740P10000		AA	DD		С	Screw(4×10) Ľ <sup>*</sup> λ		
2	XHBS740P10000		AA	DD		С	Screw(4×10)		
3	SSAKA0006UCZZ		AA	DD		D	Vinyl bag(50×60) ポリ袋		
4	LHLDZ0149QSZZ		AH	DX		С	2nd delivery holder 第 2 排紙制約 -		
7	SSAK-4271CCZZ		AD	DJ		D	Vinyl bag(420×690) ポリ袋		
9	SSAKA2540QCZZ		AB	DD		D	Vinyl bag(260×560) ポリ袋		
10	N PSHEZ0665QSZZ	-	AC	DJ		C	Optical frame sheet 光学フレームマイラー		09/08 Mid

40 MX-TR11 梱包及び付属品 (MX-TR11 Packing material & accessories)



# SHARP