

website http://www.lgservice.com e-mail http://www.lgeservice.com/techsup.html

LG Multi Air Conditioner **OWNER'S MANUAL**



Dear Owner Thank you for installing LG air conditioner. Your best choice guarantees you a great performance and service to make your life comfortable & pleasant.

IMPORTANT

- · Please read this owner's manual carefully and thoroughly before installing and operating your room air conditioner.
- · Please retain this owner's manual for future reference after reading it thoroughly.

Multi Air Conditioner Owner's Manual

TABLE OF CONTENTS

Electrical Safety	6
Temporary Use of an Adapter	
Temporary Use of an Extension Cord	16
Symbols used in this Manual	6

Operating Instructions	
How to insert the Batteries	.7
Wireless Remote Controller	
Maintenance	.7
Operating Method	.7
Operation Indication Lamps	.8
Wireless Remote Controller	.9
Operation Mode1	0
Healthy Dehumidification Operation1	1
Air Circulation Operation1	1
Auto Operation1	1
Jet Cool/Heat Operation1	2
Auto Clean Operation1	2
NEO PLASMA Purification	
Operation (Optional)1	2
Energy-Saving Cooling Mode	
(Optional)1	
Display Luminosity (Optional)1	3
Forced operation1	3
Setting the Current Time1	4
Timer Setting1	
To cancel the timer setting1	4
Sleep Mode1	4
Vertical / Horizontal Airflow Direction	
Control (Optional)1	
Auto Restart Function1	5

/lai	intenance and Service	.16
1	Artcool Mirror Type	.16
ł	Artcool Type	.17
H	How to replace picture & photograph	
((Art Cool Type2)	.18
1	When the air conditioner is not going	
t	to be used for a long time	.19
(Operation Tips	.19
-	Troubleshooting	.20

FOR YOUR RECORDS

Write the model and serial numbers here:

Model # Serial

You can find them on a label on the side of each unit.

Dealer's Name

Date Purchased

Staple your receipt to this page in the event you need it to prove date of purchase or for warranty issues.

OREAD THIS MANUAL

Inside you will find many helpful hints on how to use and maintain your air conditioner properly. Just a little preventive care on your part can save you a great deal of time and money over the life of your air conditioner.

You'll find many answers to common problems in the chart of troubleshooting tips. If you review our chart of

Troubleshooting Tips first, you may not need to call for service at all.

PRECAUTION

- Contact the authorized service technician for repair or maintenance of this unit.
- Contact the installer for installation of this unit.
- The air conditioner is not intended for use by young children or invalids without supervision.
- Young children should be supervised to ensure that they do not play with the air conditioner.
- When the power cord is to be replaced, replacement work shall be performed by authorized personnel only using only genuine replacement parts.



Safety Precautions

To prevent injury to the user or other people and property damage, the following instructions must be followed.

Incorrect operation due to ignoring instruction will cause harm or damage. The seriousness is classified by the following indications.

AWARNING This symbol indicates the possibility of death or serious injury.

This symbol indicates the possibility of injury or damage.

Meanings of symbols used in this manual are as shown below.



Be sure not to do.

Be sure to follow the instruction.

Always use a power plug and socket with a ground terminal.	Do not use a defective or underrated circuit breaker. Use the correctly rated breaker and fuse.	Do not use a multi consent. Always use this appliance on a dedicated cicuit and breaker.
There is a risk of electric shock.	• There is risk of fire or electric shock .	Otherwise it can cause electric shock or fire.
For electrical work, contact the dealer, seller, a qualified electrician, or an Authorized Service Center. Do not disassemble or repair the product by yourself.	Always ground the product as per the wiring diagram. Do not connect the ground wire to gas or water pipes lightening rod or telephone ground wire.	Install the panel and the cover of control box securely.
There is risk of fire or electric shock.	• There is risk of fire or electric shock.	There is risk of fire or electric shock due to dust , water etc.
Use the correctly rated breaker or fuse.	Do not modify or extend the power cable. If the power cable or cord has scrathes or skin peeled off or deteriorated then it must be replaced.	For installation, removal or reinstall , always contact the dealer or an Authorized Service Center.
There is risk of fire or electric shock.	• There is risk of fire or electric shock.	 There is risk of fire, electric shock, explosion, or injury.
Do not install the product on a defective installation stand. Be sure that the installation area does not deteriorate with age.	Never install the outdoor unit on a moving base or a place from where it can fall down.	When the product is soaked (flooded or submerged) in water, contact an Authorized Service Center for repair before using it again.
It may cause product to fall.	 The falling outdoor unit can cause damage or injury or even death of a person. 	• There is risk of fire or eletric shock.
In outdoor unit the step-up capacitor supplies high voltage electricity to the electrical components. Be sure to discharge the capacitor completely before conducting the repair work.	When installing the unit, use the installation kit provided with the product.	Be sure to use only those parts which are listed in the svc parts list. Never attempt to modify the equipment.
An charged capacitor can cause electrical shock.	Otherwise the unit may fall and cause severe injury.	 The use of inappropriate parts can cause an electrical shock, excessive heat generation or fire.

Safety Precautions

Indoor/outdoor wiring connections must be secured tightly and the cable should be routed properly so that there is no force pulling the cable from the connection terminals.	Safely dispose off the packing materials. Like screws, nails, batteries, broken things etc after installation or svc and then tear away and thraw away the plastic packaging bags.	Make sure to check that the power cable plug is not dirty, loose or broken and then only insert the plug completely.
 Improper or loose connections can cause heat generation or fire. 	 Children may play with them and cause injury. 	 Dirty, loose or broken power plug can cause electric shock or fire.
Be sure to check the refrigerant to the used. Please read the label on the product.	Don't use a power cord, a plug or a loose socket which is damaged.	Do not touch , operate, or repair the product with wet hands. Hold the plug by hand when taking out
Incorrect refrigerant used can prevent the normal operation of the unit.	Otherwise it may cause a fire or electrical shock.	• There is risk of electric shock or fire.
Do not place a heater or other heating appliances near the power cable.	Do not allow water to run into electric parts. Install the unit away from water sources.	Do not store or use or even allow flammable gas or combustibles near the product.
There is risk of fire and electric shock.	• There is risk of fire, failure of the product, or electric shock.	• There is risk of fire.
Do not use the product in a tightly closed space for a long time. Perform ventilation regularly.	Do not open the front grille of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)	If strange sounds, smell or smoke comes from product.Immediately turn the breaker off or disconnect the power supply cable.
Oxygen deficiency could occur and hence harm your health.	 There is risk of physical injury, electric shock, or product failure. 	• There is risk of electric shock or fire.
Ventilate the product room from time to time when operating it together with a stove, or heating element etc.	Turn the main power off and unplug the unit when cleaning or repairing the product.	When the product is not to be used for a long time, disconnect the power supply plug or turn off the breaker.
Oxygen deficiency can occur and hence harm your health.	• There is risk of electric shock.	 There is risk of product damage or failure, or unintended operation.
Take care to ensure that nobody especially kids could step on or fall onto the outdoor unit.	Take care to ensure that power cable could not be pulled out or damaged during operation.	Do not place ANYTHING on the power cable.
This could result in personal injury and product damage.	• There is risk of fire or electric shock.	• There is risk of fire or electric shock.

Do not plug or unplug the power supply plug to turn the unit ON/OFF .

When flammable gas leaks, turn off the gas and open a window for ventilation before turn the product on.

• There is risk of fire or electric shock.

Two or more people must lift and transport the product.

· Avoid personal injury.

Keep level even when installing the product.

• To avoid vibration or noise.

 Do not use the telephone or turn switches on or off. There is risk of explosion or fire.

ACAUTION

Do not install the product where it will be exposed to sea wind (salt spray) directly.

• It may cause corrosion on the product.

Do not install the product where the noise or hot air from the outdoor unit could damage or disturb the neighborhoods.

• It may cause a problem for your neighbors and hence dispute.

Install the drain hose to ensure that the condensed water is drained away properly.

· A bad connection may cause water leakage.

Always check for gas (refrigerant) leakage after installation or repair of product.

 Low refrigerant levels may cause failure of product.

ENGLISH

		Salety Precautions
Do not use the product for special purposes, such as preserving foods, works of art, etc. It is a consumer air conditioner, not a precision refrigeration system.	Do not block the inlet or outlet of air flow.	Use a soft cloth to clean. Do not use harsh detergents, solvents or splashing water etc .
 There is risk of damage or loss of property. 	• It may cause product failure.	 There is risk of fire, electric shock, or damage to the plastic parts of the product.
Do not touch the metal parts of the product when removing the air filter.	Do not step on or put anyting on the product. (outdoor units)	Always insert the filter securely after cleaning. Clean the filter every two weeks or more often if necessary.
 There is risk of personal injury. 	 There is risk of personal injury and failure of product. 	• A dirty filter reduces the efficiency.
Do not insert hands or other objects through the air inlet or outlet while the product is operating.	Be cautious when unpacking and installing the product.	If the refrigerant gas leaks during the repair, do not touch the leakaing refrigerant gas.
 There are sharp and moving parts that could cause personal injury. 	Sharp edges could cause injury.	• The refrigernat gas can cause frostbite (cold burn)
Do not tilt the unit when removing or uninstalling it.	Do not mix air or gas other than the specified refrigerant used in the system .	If the refrigerant gas leaks during the installation, ventilate the area immediately.
 The condensed water inside can spill. 	 If air enters the refrigerant system, an excessively high pressure results, causing equipment damage or injury. 	Otherwise it can be harmfull for your health.
Dismantling the unit, treatment of the refrigerant oil and eventual parts should be done in accordance with local and national standards.	Replace the all batteries in the remote control with new ones of the same type. Do not mix old and new batteries or different types of batteries.	Do not recharge or disassemble the batteries. Do not dispose off batteries in a fire.
	• There is risk of fire or product failure.	 They may burn or explode.
If the liquid from the batteries gets onto your skin or clothes, wash it well with clean water. Do not use the remote if the batteries have leaked.	If you eat the liquid from the batteries, brush your teeth and see doctor. Do not use the remote if the batteries have leaked.	Do not let the air conditioner run for a long time when the humidity is very high and a door or a window is left open.
 The chemicals in batteries could cause burns or other health hazards. 	• The chemicals in batteries could cause burns or other health hazards.	Moisture may condense and wet or damage furniture.
Do not expose your skin or kids or plants to the cool or hot air draft.	Do not drink the water drained from the product.	Use a firm stool or ladder when cleaning, maintaining or repairing the product at an height.
plants to the cool or not air draft.	product.	maintaining or repairing the product at an heigh

• This could harm to your health.

- It is not sanitary and could cause serious health issues.
- Be careful and avoid personal injury.

Electrical Safety

A WARNING

- This appliance must be properly grounded.
- To minimize the risk of electric shock, you must alway plug into a grounded oulet.
- Do not cut or remove the grounding prong from the power plug.
- Attaching the adapter ground terminal to the wall receptacle cover screw does not ground the appliance unless the cover screw is metal and not insulated, and the wall receptacle is grounded through the house wiring.
- If you have any doubt whether the air conditioner is properly grounded, have the wall receptacle and circuit checked by a qualified electrician.

Temporary Use of an Adapter

We strongly discourage the use of an adapter due to potential safety hazards. For temporary connections, use only a genuine adapter, available from most local hardware stores. Ensure that the large slot in the adapter is aligned with the large slot in the receptacle for a proper polarity connection.

To disconnect the power cord from the adapter, use one hand on each to avoid damaging the ground terminal. Avoid frequently unplugging the power cord as this can lead to eventual ground terminal damage.

A WARNING

• Never use the appliance with a broken adapter.

Temporary Use of an Extension Cord

We strongly discourage the use of an extension cord due to potential safety hazards. For temporary situations, use only CSA certified and UL listed 3-wire grounded extension cords, rated 15 A, 125 V.

A WARNING

This appliance should be installed in accordance with national wiring regulations. This guide acts as a guide to help to explain product features.

Symbols used in this Manual



This symbol alerts you to the risk of electric shock.



This symbol alerts you to hazards that may cause harm to the air conditioner.



This symbol indicates special notes.

Operating Instructions

How to insert the Batteries

- 1. Remove the battery cover by pulling it according to the arrow direction.
- 2. Insert new batteries making sure that the (+) and (-) of battery are installed correctly.
- 3. Reattach the cover by sliding it back into position.

NOTE

- 1. Always use/replace both batteries of same type.
- 2. If the system is not to be used for a long time, remove the batteries to save their working life.
- 3. If the display screen of remote controller starts, fading replace both of the batteries.

Wireless Remote Controller Maintenance

- 1. Choose a suitable place where its safe & easy to reach.
- 2. Fix the holder to wall etc with the supplied screws firmly.
- 3. Slide the remote controller inside the holder.



NOTE

- 1. Remote controller should never be exposed to direct sunlight.
- 2. Signal transmitter & receiver should always be clean for proper communication. Use a soft cloth to clean them.
- 3. In case some other appliances also get operated with remote control, change their position or consult your serviceman.

Operating Method

- 1. The signal receiver is inside the unit.
- 2. Aim the remote controller towards the unit to operate it. There should not be any blockage in between.

Artcool Mirror Type



Artcool Type



Operation Indication Lamps

Artcool Mirror Type

Display panel LCD indicators



\bigcirc	On/Off	: Lights up during the system operation, error code and auto restart setting.
☆	Sleep mode	: Lights up during sleep mode auto operation.
Ü	Energy-Saving Cooling Mode	: Lights up during Energy-Saving Cooling Mode Operation.
£≆	Plasma	: The function illustrates its dynamic mode by using a multiple lighting system.
G	Timer	: Lights up during timer operation or sleep mode auto operation.
8	Defrost mode	: Lights up during defrost mode or *hot start operation (Heat pump model only)
out / 🚫	Outdoor unit operation	: Lights up during outdoor unit operation. (Cooling model only)
88	Power Display	Indicates the setting temperature and operation mode.

Artcool Type

Display panel LED indicators



On/Off : Lights up during the system operation, error code and auto restart setting.

* Hot start operation: Stops the indoor fan in heating operation for minutes to prevent cold air from blowing out from unit.

* In defrost mode unit stops heating operation for few minutes to remove formation of ice on the heat exchanger coils to maintain the efficiency.

Wireless Remote Controller

The controls will look like the following.





- 1. ON/OFF BUTTON Used to turn off/on the unit.
- 2. OPERATION MODE SELECTION BUTTON Used to select the operation mode.
- 3. ROOM TEMPERATURE SETTING BUTTONS Used to select the room temperature.
- 4. INDOOR FAN SPEED SELECTOR BUTTON Used to select fan speed in four steps low, medium, high and CHAOS.
- 5. JET COOL BUTTON Used to start or stop the speed cooling. (It operates fan in super high speed in cooling mode)
- 6. CHAOS SWING BUTTON Used to stop or start louver movement and set the desired up/down airflow direction.
- 7. TIMER AND TIME SETTING BUTTON Used to set the time of starting and stopping operation.
- 8. TIME SETTING BUTTONS Used to adjust the time.
- 9. TIMER SET / CLEAR BUTTON Used to set and to cancel the timer operation.
- 10. SLEEP MODE AUTO BUTTON Used to set sleep mode auto operation.
- 11. ROOM TEMPERATURE CHECKING BUTTON Used to check the room temperature.
- 12. RESET BUTTON Used prior to resetting time.
- 13. AUTO CLEAN BUTTON Used to set auto clean mode.
- 14. PLASMA BUTTON Used to start or stop the plasma-purification function.
- 15. CLEAR ALL BUTTON Used to cancel all timer setting.
- 16. ENERGY SAVING COOLING BUTTON(OPTIONAL) Used to save Energy.
- 17. LCD LUMINOSITY BUTTON(OPTIONAL) Used to adjust LCD luminosity.
- 18. HORIZONTAL AIRFLOW DIRECTION CONTROL BUTTON (OPTIONAL) Used to set the desired horizontal airflow direction.

Operation Mode





Set the fan speed with the remote controller. You can select the fan speed in four steps-low, medium, high and CHAOS by pressing the INDOOR FAN SPEED SELECTOR BUTTON. Each time the button is pressed, the fan speed mode is shifted.



Natural wind by the CHAOS logic

4

For fresher feeling, press the INDOOR FAN SPEED SELECTOR BUTTON selector and set to CHAOS mode. In this mode, the wind blows like a natural breeze by automatically changing fan speed according to the CHAOS logic.

Healthy Dehumidification Operation





During Healthy Dehumidification Operation

If you select the dehumidification mode on the OPERATION MODE SELECTION

BUTTON, the product starts to run the dehumidification function. It automatically sets the room temperature and airflow volume to the best condition for dehumidification, based on the sensed current room temperature.

In this case, however, the setting temperature is not displayed on the remote controller and you are not able to control the room temperature either.

During the healthy dehumidification function, the airflow volume is automatically set according to the optimization algorithm responding to the current room temperature status, so that the room condition is kept healthy and comfortable even in the very humid season.

Air Circulation Operation



This operation circulates the air without cooling or heating. It can be activated by pressing the OPERATION MODE SELECTION BUTTON. Once the air circulation is activated you can select the air speed by pressing the INDOOR FAN SPEED SELECTOR BUTTON.

NOTE

CHAOS Air economizes power consumption and prevents overcooling. The fan speed is automatically changed from high to low or vice versa, depending on the ambient temperature.

Auto Operation



In this operation mode the actual setting temperature and the fan speed are automatically set by the electronic control logic based on the current room temperature. If you feel hot or cold press the temperature setting buttons respectively for more cooling or heating effect.

NOTE : You cannot set the actual setting temperature and the indoor fan speed in this operation mode. But you can use the Chaos swing in this operation.

If the system is not operating as desired, switch manually to another mode.

Jet Cool Operation



Jet cool function can be used to cool the room quickly in hot summer. When this function is turned on, the air conditioner runs in cooling operation mode with super high fan speed and 18°C setting temperature for 30 minutes for fast and effective cooling.

You can activate this operation by pressing the JET COOL BUTTON. To change from jet cool mode to high fan speed cooling mode, press the JET COOL BUTTON or INIDOOR FAN SPEED SELECTOR BUTTON or the ROOM TERPERATURE SETTING BUTTON again.



• Jet cool function cannot be activated during heating mode.

• Art Cool and Art Cool Wide models close the side discharges during jet cool operation, for strong cooling.

Auto Clean Operation

During auto clean function, moistures left in indoor units after cooling operation or healthy dehumidification operation can be removed.



- Press the AUTO CLEAN BUTTON to activate this function.
- Now whenever the unit is turned off, the indoor fan is still running for about 30 minutes internally without cooling or dehumidification operation. Also the louver is closed.
- This dries up any remains of moisture & cleans the unit internally.
- If you press AUTO CLEAN BUTTON again during operation, this function is cancelled.

During auto clean function, only ON/OFF BUTTON, PLASMA BUTTON and AUTO CLEAN BUTTON can be used.

NEO PLASMA Purification Operation (Optional)

Ŷ		
*		
¢≠		
b	18	\Box
FANS		_

Plasma filter is a technology developed by LG to get rid of microscopic contaminants in the intake air by generating a plasma of high charge electrons. This plasma kills and destroys the contaminants completely to provide clean and hygienic air.

Plasma purification can be started by pressing the PLASMA BUTTON on the remote controller. Repressing it will deactivate the operation.



This feature can be used in any operation mode and any fan speed can be used while plasma filter is functioning.

Energy-Saving Cooling Mode (Optional)

Energy-saving cooling mode can save energy in cooling and healthy dehumidification operation, because it can operate efficiently by setting body-adaptation time according to the change of time and temperature and adjusting automatically desired temperature.



- 1. Press the ON/OFF BUTTON to start the unit.
- Open the door of the remote controller. Select cooling operation or healthy dehumidification operation.
- 3. Press the ENERGY-SAVING COOLING MODE BUTTON.
- To cancel the energy-saving cooling mode, press the ENERGY-SAVING COOLING MODE BUTTON again and unit will operate in previous mode(Cooling or healty dehumidification mode).

ACAUTION

Because Energy-Saving Cooling Mode is optional function, some product will not operate.

Display Luminosity (Optional)

The Display Luminosity can be adjusted by using the remote control. Open the door of the remote controller, and press the LCD LUMINOSITY button. Display will be dark. Press the button again to set bright display.

ACAUTION

Because Display Luminosity is optional function, some product will not operate.

Forced operation

Operation procedures when the remote control can't be used. The operation will be started if the ON/OFF button is pressed. If you want to stop operation, re-press the button.





	Cooling Model	Heat pump Model		
		Room Temp. \geq 24°C	$21^{\circ}C \le Room Temp. < 24^{\circ}C$	Room Temp. < 21°C
Operating mode	Cooling	Cooling	Healthy Dehumidification	Heating
Indoor FAN Speed	High	High	High	High
Setting Temperature	22°C	22°C	23°C	24°C

Test operation

During the TEST OPERATION, the unit operates in cooling mode at high speed fan, regardless of room temperature and resets in 18 minutes.

During test operation, if remote controller signal is received, the unit operates as remote controller sets.

If you want to use this operation, Press and hold the ON/OFF button for 3~5 seconds, then the buzzer sound 1 "beep". If you want to stop the operation, re-press the button.



 If you wish to cancel each timer setting, press the TIMER BUTTON to turn timer sleep on or off as you want. And then press the SET/CLEAR BUTTON aiming the remote controller at the signal receptor.
 (The timer lamp on the air conditioner and the display will go off.)

Sleep Mode

Press the SLEEP MODE AUTO BUTTON to set the time when you want the unit to stop automatically. The timer is programmed in one-hour increments by pressing the SLEEP MODE AUTO BUTTON 1 to 7 times. The sleep mode is available for 1 to 7 times.

NOTE

- The sleep mode will operate indoor fan at slow speed in cooling mode and at medium speed in heating mode for pleasant sleep.
- Art Cool and Art Cool Wide (non-Deluxe) close the lower discharge partially in sleep mode for pleasant sleep. In cooling mode or healthy dehumidification mode:

The setting temperature will rise automatically two times by 1°C over next consecutive 30 minutes (2°C in 1 hour) for a comfortable sleep. Now this will be the final setting temperature as long as sleep mode is functioning.

Vertical / Horizontal Airflow Direction Control (Optional)



NOTE

- By pressing the CHAOS SWING BUTTON the horizontal air flow direction is changed automatically based on the chaos
 algorithm to distribute the air in the room evenly and at the same time to make the human body feel most comfortable as if
 enjoying natural breeze.
- Manually moving the vertical air flow direction louver by hand could damage the mechanism. When the unit is shut off, the up/down airflow direction louver will close the air outlet vent of the system.
- The Chaos Swing may not run correctly during sleep mode.

Because Horizontal Airflow Direction Control is optional function, some product will not operate.

Auto Restart Function

This function is useful in the situation of power failure.

When power regains after a failure this feature restore the previous operating condition and the air conditioner will run in the same settings.

NOTE

This feature is enabled by factory default setting, but you can disable it by pressing the ON/OFF button for 6 seconds. The unit will beep twice and the indicator lamp(2) will blink 4 times.

To enable it, press the button again for 6 seconds. The unit will beep twice and the indicator lamp(1) will blink 4 times.



Maintenance and Service

ACAUTION

Before performing any maintenance, turn off the main power to the system, disconnect the circuit breaker and unplug the power cord.

Artcool Mirror Type

Grille, Case, and Remote Control

Turn the system off before cleaning.

To clean, wipe with a soft, dry cloth. Do not use bleach or abrasives.

NOTE Supply power must be disconnected before cleaning the indoor unit.

AIR FILTERS

The air filters behind the front grille should be checked and cleaned once in every 2 weeks or more often if neccessary.

- 1. Open the front panel as shown.
- 2. Then pull the filter tab slightly forward to remove the air filter.
- 3. Clean the filter with a vacuum cleaner or warm, soapy water.
 - If dirt is conspicuous, wash with a solution of detergent in lukewarm water.
 - If hot water (40°C or more) is used, it may be deformed.
- 4. After washing with water, dry well in the shade.
- 5. Re-install the air filter.

NANO PLASMA FILTER

The NANO PLASMA filter behind the air filters should be checked and cleaned once in every 3 months or more often if necessary.

- 1. After removing the air filters, pull slightly forward to remove the NANO PLASMA filter.
- Remove dust with vacuum cleaner or air. (You should not try to wash with water).
- 3. Note the cuts of electric discharge lines.
- 4. Re-install the NANO PLASMA filter to the original position.
- Never use any of the followings:
 - Water hotter than 40°C Could cause deformation and/or discoloration.
 - Volatile substances Could damage the surfaces of the air conditioner.





Don't touch this PLASMA Filter within 10 seconds after opening the inlet grille, it may cause an electric shock.



Artcool Type

Clean the unit with a soft dry cloth. Do not use bleach or abrasives.

ACAUTION

Never use any of these

- \bullet Water hotter than 40°C. It may cause deformation and discoloration.
- Volatile substances. They may damage the surface of the air conditioner.

Air Filters

The air filters behind the front panel / grill should be checked and cleaned once in every 2 weeks or more often if necessary. To remove the filters see the self explanatory diagrams for each model type. Clean the filters with a vacuum cleaner or warm soapy water. If dirt is not easily removed, wash with a solution of detergent in luke warm water. Dry well in shade after washing and reinstall the filters back in place.

Plasma Filters

The plasma filters behind the air filter should be checked and cleaned once in every 3 months or more often if necessary. To remove the filters see the self explanatory diagrams for each model type. Clean the filters with a vacuum cleaner. If it is dirty wash it with water and dry well in shade an install back in place.

Deodorizer Filters

Remove the deodorizer filters behind the air filter and expose them in direct sunlight for 2 hours.

And then insert these filters into original position.

Removal of Filters

1. Art Cool Type :

Pull out the upper section of front panel and lift it up. Take out a filter with front panel held.

With PUSH button pressed, pull out grip to take out a plasma filter. Dry it completely in the shade after cleaning. Then set a plasma filter and a filter orderly. Put the hook of front panel onto the hanger, in order to close the front panel.



ACAUTION

Don't touch this plasma filter within 10 seconds after opening the inlet grille, it may cause an electric shock.









How to replace picture & photograph (Art Cool Type2)

1. Turn off power and then open the upper part of front panel.



4. Take out picture.



7. Cover mat and press down with hand(s) until contacting closely. 2. Pull out the both links of lower part of front panel, as described in the below picture.



5. Turn upside-down of the picture and turn over mat, then take off a protective tape attached at the mat.



8. Slide the photo graph/drawing requested under both hanger parts as following, and fix them. Press the front panel lightly to close. Push and close the top part of the front panel and then pull the bottom part of the panel forward until it is secured.



 Place the picture/photograph between the exited picture and mat. (Recommended size of a photo/picture: 450mm x 450mm)



9. Push both links of lower part of panel inside and fix it. Then turn on.







In case a mat is not used, recommended size of a photo/picture: 522mm x 522mm

When powering on after replacing filter and picture, the front panel doesn't intervene.



When the air conditioner is not going to be used for a long tim



Remove the batteries from the Remote Controller.

When the air conditioner is to be used again.

 Clean the air filter and install it in the indoor unit. (Refer to page 14~15 for cleaning filters.)

2 Check that the air inlet and outlet of the indoor/outdoor unit are not blocked.

Operation Tips

3

Do not overcool the room.	Keep blinds or curtains closed.	Keep the room temperature uniform.
This is not good for the health and wastes electricity.	Do not let direct sunshine enter the room when the air conditioner is in operation.	Adjust the vertical and horizontal airflow direction to ensure a uniform temperature in the room.
Make sure that the doors and windows are shut tight.	Clean the air filter regularly.	Ventilate the room occasionally.
Avoid opening doors and windows if possible to keep the cool air in the room.	Blockages in the air filter reduce the airflow and lower cooling and dehumidifying effects. Clean at least once every two weeks.	Since windows are kept closed, it is a good idea to open them and ventilate the room now and then.

Troubleshooting

Check the following points before requesting repairs or service.... If the fault persists, please contact your dealer or service center.

Case	Explanation	See page
The air conditioner does not	Check room temperature setting?	10
operate.	Check if circuit breaker is on?	-
The room has a peculiar odor.	 Check that this is not a damp smell exuded by the walls, carpet, furniture, or cloth items in the room. 	-
It seems that condensation is leaking from the air conditioner.	 Check the drain hose is connected tight or if indoor unit is installed even. 	-
Air conditioner does not operate for about 3 minutes after turning on.	 This is the protector of the mechanism. Wait about 3 minutes and operation will begin. About 3 minutes delay is applied to protect compressor from frequenty on/off. 	-
Does not cool or heat effectively.	 Is the air filter dirty? See air filter cleaning instructions. 	14~15
	Has the temperature been set correctly?	10
	Are the indoor unit's air inlet or outlet vents obstructed?	-
The air conditioner operation is noisy.	 For a noise that sounds like water flowing. -This is the sound of refrigerant flowing inside the air conditioner unit. For a noise that sounds like the compressed air releasing into atmosphere. This is the sound of the dehumidifying water being processed inside the air conditioning unit. 	-
Remote Controller display is faint, or no display at all.	 Are the batteries depleted? Are the batteries inserted in the opposite (+) and (-) directions? 	7
Crack sound is heard.	• This sound is generated by the expansion/constriction of the front panel, etc. due to changes of temperature.	-