


USER GUIDE

Model: HF740T

www.oricore.com

Be familiar with your HF740T

- ①、Previous track/Next track
- 2 Play/Pause
- ③、TF card
- 4 Multifunction Button
- ⑤、Volume +/Volume -
- 6 Power switch
- 7 Charge socket



Specification

Bluetooth Version: V4.0 (Headset/Handsfree/A2DP/AVRCP)

Battery: 3.7V/200mAh, Polymer Lithium Battery

Talk Time: >10 hrs
Music Time: >8 hrs
MP3 Time: >6 hrs
Charge Time: <2 hrs
Work Temp: -10 C~60 C

DIM/Weight: 135.6mm(W)*167.3mm(L)*16.9mm(H)*34g

Frequency: 2402MHz~2480MHz

How to use

Bluetooth On/Off

- —-Turn it On: In off status, press and hold the MFB for 3 seconds with "Power On"voice prompt.
- ---Pairing: In off status, press and hold the MFB for 5 seconds with "Pairing" voice prompt.
- —-Turn it Off: In standby, press and hold the MFB for 3 seconds with "Power Off"voice prompt.

Volume Adjustment

- --Adjust the volume by the volume keys "+"&"-".
- —In order to avoid damaging to your hearing, there will be twice long voice when it reaches to the toppest 3 tons.

Charging

--The indicator is red while charging.

Battery Status

—-Press and hold the volume key "-" for 3 seconds to get battery status as belows:

0 0010110.			
Battery condition	High(3.9-4.1V)	Medium(3.7-3.9V)	Low(under 3.6V)
Voice prompt	Battery High	Battery Medium	Battery Low

^{*}When connecting to Iphone, the headset power will appear in the upper right of Iphone.

Low Power Level

---Voice prompt of low power every 2 minutes with red indicator

blinking. (green indicator blinking in MP3 mode)

-- It will shut down if not be charged in time.

Answer/End Call

- --Click to answer call, or double click to end the call.
- Only the left engine will shake when HF740T comes a call.

Redial the Call

-- Double click the MFB to redial the last call you dialed.

Voice Dialing

--Press and hold the MFB for 1 second after you hear "Du"tone, speak the voice tag that you store in your phone. (Check whether

your mobile phones support voice dialing or not) Transfer the Call

- ---Press and hold the volume key "+" to transfer the call between headset and phone.
- Some mobile phones will transfer to HF740T automatically while some need to press and hold volume key "+" for 3 seconds.

Reject the Call

-- Press and hold the MFB for 1 second to reject the calls.

Mute the Microphone

--During the call, click the volume keys "-"& "+" together once to mute the microphone. (Repeat to return)

Music Operation

---Play/Pause the Music: Click "Play/Pause" key to play or pause the

music.

—Previous track/Next track: Click the "Previous Track" & "Next Track" keys to select songs.

MP3 Operations

Turn MP3 On/Off

- —Slip the power switch to "On/Off" position to turn it on/off.
- —In Bluetooth standby mode, if no audio output, it will transfer to MP3 mode in 10 seconds.

Play/Pause

-Under MP3 status, click "Play/Pause" to play or pause the music.

Previous Track/Next Track

—Under MP3 Status, press "Previous Track" and "Next Track" to choose the song you like.

Volume Adjustment

-Click the volume keys "+" & "-" to adjust the volume.

Warm Prompt

- 1, Under TF card mode, enter MP3 play/pause status, click
- "Play/pause" to start. (Connect the Bluetooth devices automatically if there is paired record.)
- 2, Turn MP3 on and insert the TF card, it enters MP3 music playing

mode.(Connect the Bluetooth devices automatically if there is paired record.)

3, In Bluetooth standby status, playing music from MP3, if call comes it will transfer to Bluetooth talk automatically and return to MP3 playing mode after call ends.

4,In Blutooth standby mode,it will shut down automatically if no operation.Bluetooth is prior to MP3.

5,MP3 can not automatically shut down. Please shut down if no using

 $5,\!MP3$ can not automatically shut down. Please shut down if no using to avoid affecting use next time.

Troubleshooting

If you are unable to connect your headset and mobile phone, please try the followings:

--Ensure your headset is turned on and properly charged.

—Ensure the headset is paired with your mobile phone.

—Ensure your mobile phone's Bluetooth feature is activated.

Pleaserefer to your mobile phone used guide for specific instruction.

—Ensure the headset is within a 10 meters range of your mobile headset and there are no obstructions, such as walls or other electronic devices in between.

• If the above steps do not solve your problem, please recharge the headset and restart your mobile phone.

Care and Maintenance Headset

- --Consider turning your headset off before placing it in your pocket or bag. If the MBF is accidentally activated, your mobile phone may place an unintended call.
- --Do not expose the headset to liquid, moisture or humidity as it is not waterproof.
- -- Do not use abrasive cleaning solvents to clean the headset.
- ---Do not expose the headset to extreme temperature conditions. The best store temperature range is from -10 to +60, otherwise the life of the headset will be influenced.
- ---Do not dispose of the headset is a fire as it this may result in an explosion.
- --Do not bring your headset into contact with sharp objects as this will cause scratched and damage.
- --Do not insert any objects to the headset as this will damage the components inside.
- —Do not attempt to disassemble the headset as it dose not contain serviceable components.
- If you will not use the headset for long periods, be sure to store it in
 a dry place, free from extreme temperature conditions and dust. If the
 headset is placed for more than 1 month, please charge it on time to
 make sure the battery and the headset's working performance.

Product Information Card

Product Name:		
Product Model:		
S/N NO.:		
Purchase Date:		
Customer Name:		
Tel/Mobil:		
Distributer:		