




- 1:Microphone Input
- 2:Microphone Input
- 3:Aux-in(3.5mm)
- 4:TF Card input
- 5:USB Playing back
- 6:DC 9V input(charging slot)
- 7:Charging indicator
- 8:Power on/off
- 9:Play/pause under USB/TF/BT,Long press to get Microphone priority
- 10:MENU(control BASS/Treble/MIC Volume)
- 11:Next sound(under USB/TF/BT mode)
- 12:Light mode switching and on/off,short switch to get different mode,long press to on/off the light