
In idle screen: Inserting or removing the SIM card I.I Keys 100 Alarm clock Your mobile Press to access shortcuts Getting started Insert SIM2 Navigation key I d SIMI(2) level of network reception. En + P access to Profiles Confirm an option (press the middle of the key) Fn + Q: access to Clock SIMI(2) voicemail message arrived Access to menu (short keypress) Fn + S: access to Notes 2.1 Set-up Show/hide shortlist menu(long keypress) Ĉх. Missed calls In edit mode: Pick up Press once to input top-half character Removing or installing the back cover Radio is or Éæ Send a call Press twice to lock top-half inputting mode, then press once to unlock top-half inputting mode. Access call memory (short keypress) \odot Stopwatch is active Navigation key⁽¹⁾ Access to Fake call (long keypress) Long keypress: access to Dictionary. Main menu.confirm 20 WAP alerts option Switch on/Switch off the telephone (long keypress) In edit mode: rofiles 🔺 £28 Roaming End call Short press: popup symbol page to select special character by /Calendar 🔫 Side key Return to the idle screen navigation key 82 Line switching (2); indicates the selected line New Messages Long press & Fn+SYM: popup smileys page to select spe Left softkey FM Radio SIMI(2) GPRS connection status (Gray - Activated) smileys by navigation key Right softkey Ch Ch Right softkey SIMI(2) GPRS attached. Left softkey Delete one by one (short keypress) Delete one by one quickly (long keypress) Access your voicemail (long keypress) Message receipt in progres Switch the uppercase and minuscule (in edit screen) Pick up/Send call Û ŵ Sending a message ver on/off Vibration alert nd call Input the "#" in Idle Return a cursor to the next line Silence mode: your phone neither rings, beeps nor vibrates Voicemail except for the alarms. Del kev Installing or removing the battery Sym key-Message unread Side key in idle screen Message list is full: your terminal cannot accept any new) 🔍 🦳 🌔 Short Push : Show/hide shortlist menu messages. You must access the message list and delete at least Main screen icons (1) 1.2 one message on your SIM card. Battery charge level IX IX Flight mode. In idle screer Vibrate alert: Your phone vibrates, but does not ring or beep Place the SIM card with the chip facing downwards and slide it into its Space key Long/short keypress: Lock/Unlock the keypad with the exception of the alarm housing. Make sure that it is correctly inserted. To remove the card, press the bottom and slide it out. Please power off your phone before you In edit mode: \cap Headset connected remove the SIM card. Short keypress: input space Keypad locked Long keypress: switch language () Depending on your network operator. SIMI(2) call forwarding activated: your SIMI(2) calls are En key + Space: switch input mode ीत के OT-255D ALCATEL The icons and illustrations in this guide are provided for informational purposes ⁽¹⁾ Depending on your network operator Contact your network operator to check service availability 2 16.1 Dual SIM settings Menu arrange...... Directory Profiles..... Internet..... You can switch easily between either SIM card using the following options: You can create a note in text or voice format by accessing "Notes" from Dual SIM open: you may receive calls in either SIM card but can only take one call from one SIM card at a time. Both SIM cards can send and receive main menu With this menu, you may personalise ringtones for different events and 15.4 Tasks. Main Menu is designed to vary according to your preference. **9Ι WΔP** 6.1 Consulting your directory Only SIMI open: SIM2 card is deactivated; SIM2 calls, messages and Change the order To access the Directory from the main screen, press the key and Access WAP options: Homepage, Bookmarks, Go to URL, Recent Enables you to easily manage and track the progress of an task with voicemail are not accessible. From main menu, press left softkey and select "Move" or long keypress select the 🔝 icon. Only SIM2 open: SIMI card is deactivated; SIMI calls, messages and pages, Offline pages. priorities. All the tasks will be sorted by due date. key till tick "\" is shown, then move the cursor to your favorite You can check contact details on either SIMI/SIM2 and also Copy between 9.2 Weather oicemail are not accessible 15.5 Clock Flight mode: no calls/messages are accessible in this mode. Media album..... destination and confirm with key. SIM1/SIM2 and the Phone directory. From "Directory Management" select the "Default Storage" option and choose your preferred SIM card Your phone is equipped with a weather function for consulting up to 3-day 5.5.1 Alarm Standby time will be less if using dual SIM function. Show/Hide on which to save informati forecast of favorite cities. Your mobile phone has a built-in alarm clock with a snooze feature. Access "Menu arrange", press key till tick (" $\sqrt{}$ ") show or off, it will 6.2 Adding a contact You will have an access to all audio and visual files stored in phone or in Medium Album. You can access a number of items with this option: My 15.5.2 Clock 16.2 Keys show/hide some main audios. My images. Unknown files and Memory status. Select the contacts list in which you wish to add a contact to, press the Allows you to have settings of date and time, including 12/24h format. You may set the keypad to which you prefer to. "Options" softkey, select "Add contact" then Save. ICE 📉 Fn + Keys: you may define the combined Fn key function and to get 15.5.3 World clock shortcuts with below options: Edit/Add/Delete. The World clock shows current local time and the time zone in different Messages 🖂 16.3 Security ICE (in case of emergency) are 3 numbers emergency services can call if Fake Call...... you have an accident, you can also add useful information such as blood Set SIM1 and SIM2 security using the following options: SIM1(2) security 15.5.4 Stopwatch type, allergy. Access to "ICE" menu from main menu and below options setup, Phone code. 5.1 Messages: Text/Multimedia message are available: View, Add/Edit, Delete The stopwatch is a simple application for measuring time with the possibility You may check the operator service on either two SIM cards. to register several results and suspend/resume measurement. 16.4 Networks Contact your network operator to check service availability Protect yourself from annoying situations with the "Fake Call". In this 5.1.1 Create message meun, you can set "Caller name/nb", "Call time" and "Ringtone". You may choose the network of either SIM card and set it as your preferred 15.6 Converter From the main menu select "Messages" to create text/multimedia When the timer reaches, the phone will ring and display like receiving a network Unit converter and Currency converter real phone call. Press 🚫 key, pretend answering a call, the screen will You can type a message and select to send it to a recipient in either the 16.5 Call settings Others..... display just like have an ongoing call. Press 🧭 key, pretend to reject the SIM1 or SIM2 directory. You can configure individual options for both SIM1 and SIM2, such as Caller You can also modify a predefined message in **Templates** or customise your call, the call will terminate automatically. Your phones includes some games, Select "Game settings", it allows you ID, Call waiting, Call forwarding, Call barring and Line switching. message by adding pictures, photos, sounds, titles, etc (only available while to manage settings, in which you may set background audio and vibration editing a MMS). While writing a message, select "Options" to access all the 15.1 Calendar My numbers alert. ing options. You can save your messages that you send often to Type in or modify your telephone number and confirm by pressing _____. Once you enter this menu from main menu, there is a monthly-view Drafts or Templates (MMS only). Radio Your telephone number is usually written on your SIM card. calendar for you to keep track of important meetings, appointments, etc. From the main menu, select the menu icon 🕺 and select the function of 5.1.2 Inbox/Outbox Days with events entered will be marked in color. Billings (You can check the details of messages contained on either SIM card from Your phone is equipped with a Radio⁽¹⁾ with RDS functionality. You can use your choice in order to customise your telephone: Dual SIM settings, Display, Languages, Headset, Input mode, Vocabulary, Keys, Security, You can access different items with this option: Amount, Duration 15.2 Calculator.... Inbox/Outbox. the application as a traditional Radio with saved channels or with parallel Networks, Call settings, Connectivity, Restore default set. GPRS counter, Beep duration. Access this feature by selecting "Calculator" from the main menu. visual information related to the radio program on the display, if you tune 5.2 Email to stations that offer Visual Radio service. You can listen to it while running Enter a number, select the type of operation to be performed using the Your phone has an email client with the settings predefined for a few other applications. navigation keys, and enter the second number, then press () key or left popular email services like - GoogleMail, Windows live, Yahoo, AOL, etc softkey to display the result. Depending on your network operator. May cause additional network charge ^(I) The quality of the radio depends on the coverage of the radio station in that data flow to provide this service. Extra fees might also be charged (i) HTML email and image in email not supported. particular area. roaming states. () Depending on your network operator 10 11 12 13

۲



2.2 Power on your phone

Hold down the \swarrow key until the telephone powers on.

2.3 Power off your phone

Hold down the \swarrow key from the main screen.



3.1 Making a call

Input the phone number and choose SIM1 or SIM2 to call number. If you make a mistake, you can delete the incorrect digits by pressing the right softkey or 🙆 key

To hang up the call, press the \checkmark key.

Making an emergency call

If your phone has network coverage, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Call memory

You can access your call memory by pressing the 🚫 key from the idle screen, including the following options for either SIM card: "Outgoing calls", "Missed calls", "Answered calls",



Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only eadphones recommended by TCT Mobile Limited and its affiliates.



All rights reserved © Copyright 2010 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

Safety and use Latin input mode......

To write messages, there are two writing methods: - Normal: this mode allows you to type a text by choosing a letter or sequence of characters associated with a key.

Predictive with the Zi mode: This mode speeds up the writing of your text.

Fn key Fn :	Press once: input top-half character, Press twice: lock top-half character inputting mode, then press once to unlock top-half character inputting mode.
	Long press: access to Dictionary
Sym key 🔐	Short keypress: access the Symbols table Long keypress & Fn + Sym: popup smileys page
Space key	Short press: input space

Long press: press to switch language Fn+Space: switch input mode In abc (Multitapabc) input mode (no Abc mode):

Shift key Short press once: only switch one character from minuscule to uppercase Short press twice: lock uppercase input mode Short press once: unlock the uppercase In eZiabc (Smartabc) input mode: Short press once: to eZi ABC Short press twice: to eZi Abc

Short keypress: delete one by one Del key 🔤 Long keypress: delete one by one quickly

We recommend that you read this chapter carefully before using your phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

• TRAFFIC SAFETY: Given that studies show that using a mobile phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...). drivers are requested to refrain from using their mobile when the vehicle is not

- When driving, do not use your phone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas. When switched on, your phone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To
- ensure that there is no problem: do not place your phone on top of the dashboard or within an airbag deployment
- check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from mobile phone RF energy.
- CONDITIONS OF USE You are advised to switch off the telephone from time to time to optimise its

performance Switch the phone off before boarding an aircraft.

- Switch the phone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, mobile telephones can interfere with other electrical or electronic devices, or equipment using radio frequency.
- Switch the phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive atmosphere.
- When the phone is switched on it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any,
- To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the "hands-free" mode because the amplified volume might cause hearing damage.
- Do not let children use the phone and/or play with the telephone and accessorie without supervision
- When replacing the cover please note that your phone may contain substances. that could create an allergic reaction.

16

Do not allow your phone to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The manufacturer's recommended operating temperature range is -10°C to +55°C. At over 55°C the legibility of the phone's display may be impaired, though this is temporary and not serious.

Emergency call numbers may not be reachable on all cellular networks. You should er rely only on your phone for emergency calls.

Do not open, dismantle or attempt to repair your mobile phone yourself Do not drop, throw or bend your mobile phone. Do not paint it.

Use only batteries, battery chargers, and accessories which are recommended by the improper use of the mobile phone. TCT Mobile Limited and its affiliates and are compatible with your phone model. • BATTERY: TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the Before removing the battery from your phone, please make sure that the phone is use of other chargers or batteries.

Remember to make back-up copies or keep a written record of all important information stored in your phone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please. Batteries must be disposed of in accordance with locally applicable environmental

flashing-lights feature on your phone. Parents should monitor their children's use of video games or other features that its affiliates. corporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

Do not play or use a flashing-lights feature if you are tired or need sleep. Take a minimum of a 15-minute break hourly.

Play in a room in which all lights are on.

- Play at the farthest distance possible from the scree If your hands, wrists, or arms become tired or sore while playing, stop and rest
- for several hours before playing again If you continue to have sore hands, wrists, or arms during or after playing, stop
- the game and see a doctor.

When you play games on your phone, you may experience occasional discomfort. Items of equipment with this symbol are not to be thrown into ordinary bins if in your hands, arms, shoulders, neck, or other parts of your body. Follow the your jurisdiction or your region has suitable recycling and collection facilities: instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other instead they are to be taken to collection points for them to be recycled. culoskeletal disorders.

Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only INSTRUCTIONS headphones recommended by TCT Mobile Limited and its affiliates.

Always handle your phone with care and keep it in a clean and dust-free place · PRIVACY

diction or other jurisdiction(s) where you will use your mobile phone regarding 40 °C. such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and cate or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorisation be obtained, if necessary, in order to record private or confidential conversations or take a Proof of compliance with international standards (ICNIRP) or with European or their children's RF exposure by limiting the length of calls, or using "hands-free"

۲

CHARGERS

BADIO WAVES

frequency bands.

switched off

Observe the following precautions for battery us

Do not attempt to open the battery (due to the risk of toxic fumes and burns Do not puncture, disassemble or cause a short-circuit in a battery

Do not burn or dispose of a used battery in household rubbish or store it at temperatures above 60 °C.

use damaged batteries or those not recommended by TCT Mobile Limited and/or age or state of health.

This symbol on your telephone, the battery and the accessories known as the Specific Absorption Rate or "SAR". The SAR limit is set by OT-255D operate in DSDS mode (Dual SIM Dual Stand-by) means that these products must be taken to collection points at international requirements or by the Council of the European Union at 2 watts/ • LICENCES the end of their life - Municipal waste disposal centres with specific bins for these

items of equipment Collection bins at points of sale

They will then be recycled, preventing substances being disposed of in the Although the SAR was established at the highest certified level, the actual SAR level vironment, so that their components can be reused

In European Union countries

17

24

These collection points are accessible free of charge All products with this sign must be brought to these collection points In non European Union jurisdictions:

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE

The ICNIRP requirements are applicable in the following regions; Central America (except Mexico), South America, North and South Africa, Pacific Asia (except Korea), Australia.

levels, they only use the minimum level of power required to provide a con

not work in another jurisdiction. They should be used for this purpose only.

REQUIREMENTS REGARDING EXPOSURE TO RADIO WAVES.

European Union (Recommendation 1999/519/EC) (2)

the power level required by the mobile phone.

Unable to receive incoming calls

The European recommendation (1999/519/EC) is applicable in the following regions: Europe, Israel. 18

network (check for overloaded or unavailable network)

The caller's name does not appear when a call is received

• You can adjust the volume during a call by means of the 2 key

I am unable to use the features described in the manual

Make sure this feature does not require an Alcatel accessory

When I select a number from my directory, the number

Make sure you have not forwarded incoming calls

Make sure that you have not barred certain calls

The sound quality of the calls is not optimal

Your caller has concealed his/her number

Check the network strength

includes this service

not dialled

Telephone warranty

Your phone is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months ⁽ⁱ⁾ from the date of purchase as shown on your 2) Connection to any equipment not supplied or not recommended original invoice.

15

22

Batteries⁽²⁾ and accessories sold with your phone are also warranted 3) Modification or repair performed by individuals not authorised by against any defect which may occur during the first six (6) months⁽¹⁾ from the date of purchase as shown on your original invoice. In case of any defect of your phone which prevents you from normal use thereof, you must immediately inform your vendor and present your phone with your proof of purchase.

replaced or repaired as appropriate. Repaired Phone and accessories (IMEI) have been removed or altered. are entitled to a one (1) month warranty for the same defect. Repair offering equivalent functionality

This warranty covers the cost of parts and labor but excludes any provided by your country or jurisdiction. other costs

- accessory due to (without any limitation): 1) Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical Before contacting the aftersales department, you are advised to follow the area where your phone is used.
- by TCT Mobile Limited, TCT Mobile Limited or its affiliates or your vendor.

4) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage, corrosion, oxidation.

If the defect is confirmed, your phone or part thereof will be either Your phone will not be repaired in case labels or serial numbers

or replacement may be carried out using reconditioned components There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty

> In no event shall TCT Mobile Limited or any of its affiliates be liable for indirect, incidental or consequential damages of any nature whatsoever, including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed by law.Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

This warranty shall not apply to defects to your phone and/or Troubleshooting.....

- structions below
- You are advised to switch off the telephone from time to time to optimise its performance.
- You are advised to fully charge (IIII) the battery for optimal
- Avoid storing large amounts of data in your telephone as this may affect the performance of your telephone.

and carry out the following checks:

My mobile phone will not switch on

- Press vuntil the screen comes on Check the battery charge level Check the battery contacts, remove and reinstall your battery, then
- turn your telephone back on

My phone has not responded for several minutes

Press the 📿 key

Remove the battery and re-insert it, then switch the phone back

My screen is difficult to read

- Clean your screen Use your mobile phone in accordance with the recommended conditions of use
- My mobile phone turns off by itself
- · Check that your keypad is locked when you are not using your mobile phone
- Check the battery charge leve

23

My mobile phone will not charge properly Make sure that your battery is not completely discharged; the

- battery charge indicator can take several minutes and may be accompanied by a quiet whistling sound Make sure charging is carried out under normal conditions (0°C - valid, etc.)
- +40°C) Make sure your battery is inserted. It must be inserted before

plugging in the charger Make sure you are using an Alcatel battery and charger in the box When abroad, check that the electrical current is compatible

My mobile phone will not connect to a network

- Try connecting in another location
- Verify the network coverage with your operator
- Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually Try connecting at a later time if the network is overloaded

SIM card error

- Make sure the SIM card has been correctly inserted Verify with your operator that your SIM card is 3V or 1.8V
- compatible: the old 5V SIM cards cannot be used Make sure the chip on your SIM card is not damaged or scratched

Unable to make outgoing calls

Make sure you have dialled a valid number and press the 🚫 key For international calls, check the country and area codes

۲

- Make sure your mobile phone is connected to a network, and that the network is not overloaded or unavailable
- Check your subscription status with your operator (credit, SIM card valid, etc.)
- Make sure you have not barred outgoing calls

foreign country I am unable to create a file in my directory

25

- Make sure that your SIM card directory is not full; delete some files or save the files in the product directory (i.e. your professional or personal directories)
- My callers are unable to leave messages on my voicemail Contact your network operator to check service availability

The warranty period may vary depending on your country. The life of a rechargeable mobile phone battery in terms of conversation tim standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your phone

IP3219_255D_QG_Eng_GB_12_101015.indd 2

during the first six months after purchase and for approximately 200 more

Please note that you must respect the laws and regulations in force in your Mains powered chargers will operate within the temperature range of: 0 °C to compliance against the standard is 1.02 W/kg. While there may be differences between the SAR levels on various phones and at various positions, they all meet taking photographs and recording sounds with your mobile telephone. Pursuant to The chargers designed for your mobile phone meet with the standard for safety of the relevant International guidelines and EU requirements for RF (radio-waves) information technology equipment and office equipment use. Due to different exposure.

- applicable electrical specifications, a charger you purchased in one jurisdiction may The World Health Organisation (WHO) considers that present scientific . information does not indicate the need for any special precautions for use of mobile phones. If individuals are concerned, they might choose to limit their own
- photograph of another person; the manufacturer, the seller or vendor of your Directive 1999/5/EC (R&TTE) is required of all mobile phone models before they devices to keep mobile phones away from the head and body (fact sheet n° 193). mobile phone (including the operator) disclaim any liability which may result from can be put on the market. The protection of the health and safety for the user and Additional information about electromagnetic fields and public health are available any other person is an essential requirement of these standards or this directive on the following site: http://www.who.inf/peh-emf.
 - Health Organisation advises as a precautionary measure to use your telephone
 - manufactured to comply with the radiofrequency (RF) exposure thresholds 5 bars). It is also advised to keep the telephone, during communications, away from and 1800 MHz bands.
 - recommended by international requirements (ICNIRP) (1) and by the Council of the the belly of pregnant women and from the lower abdomen for teenagers. Your telephone is equipped with a built-in antenna. For optimal operation, you These limits are part of a set of requirements and establish authorised should avoid touching it or degrading it.

zicorporation Affiliates

groups of experts on the basis of regular and detailed scientific assessments. They than against your ear. In such circumstances the device will be compliant with the relevant provisions of Directive 1999/5/EC. The entire copy of the consult your doctor before playing video games on your phone or enabling a regulations. Only use the battery for the purpose for which it was designed. Never include a significant safety margin intended to ensure the safety of all, regardless of guidelines when used with headset or usb data cable. If you are using another Declaration of Conformity for your telephone can be obtained through our accessory ensure that whatever product is used is free of any metal and that it website: www.alcatel-mobilephones.com The exposure standard for mobile phones is determined by a measurement unit positions the phone at least 2cm away from the body

is a registered trademark of Obigo AB.

kilogram (W/kg) averaged over 10 grams of body tissue. The tests used to Obigo®

determine SAR levels were carried out on the basis of standard usage modes with

- for the mobile phone during use is generally much lower than the maximum values. In fact, since mobile phones are designed to operate at many different power
- to the network. In theory, the closer you are to a base station antenna, the lower

19

The highest tested SAR value for this mobile phone for use at the ear and General information

- Internet address: www.alcatel-mobilephones.com
- Hot Line Number: see "TCT Mobile Services" leaflet or go to our Internet site

On our Internet site, you will find our FAO (Frequently Asked Ouestions) section. You can also contact us by e-mail to ask any questions you may

An electronic version of this user guide is available in English and other THIS MOBILE PHONE COMPLIES WITH INTERNATIONAL AND EUROPEAN Although no danger relating to the use of telephone was ever proved, the World languages according to availability on our server: www.alcatel mohilephones.com

Your mobile phone is a radio transmitter/receiver. It was designed and with a good level of network reception as indicated on the telephone display (4 to Your telephone is a transceiver that operates on GSM networks with 900

€ 588

radiofrequency levels for the public. These limits were established by independent As mobile devices offer a range of functions, they can be used in positions other This equipment is in compliance with the essential requirements and other

Protection against theft ()

Your telephone is identified by an IMEI (phone serial number) shown on the phones transmitting at their maximum power level over the entire range of 🗓 eZiText[™] and Zi[™] are trademarks of Zi Corporation and/or its the packaging label and in the product's memory. We recommend that you note the number the first time you use your telephone by entering * # 0.6# and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card.

Disclaimer

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator services.

() Contact your network operator for service availability.

21

I cannot access my voicemail

- Make sure your mobile phone is switched on and connected to a Make sure your operator's voicemail number is correctly entered in Make sure your battery is not completely used up or damaged "My numbers'
- Check your subscription status with your operator (credit, SIM card Try later if the network is busy
 - I am unable to send and receive messages MMS, Vox MMS
 - Check your phone memory available as it might be full
 - Contact your network operator to check service availability and check MMS parameters
- Check that you have subscribed to this service with your operator Verify the server centre number or your MMS profile with your **How to make your battery last longer** operator
 - The server centre may be saturated; try again later

The 🚾 icon is displayed on my standby screen

You have saved too many short messages on your SIM card; delete some of them or archive them in the product memory

Check with your operator to make sure that your subscription "No service" is displayed

You are outside of the network coverage area

I have already entered 3 incorrect PIN codes

 Contact your network operator to obtain the PUK code (Persona Unblocking Key)

Make sure that you have correctly recorded the number in your I am unable to download new files

- Check for free space
- Make sure that you have selected the country prefix when calling a Delete some files
 - Check your subscription status with your operator

My mobile phone is frozen, can't power on

- Remove your battery, remove your SIM card then reinstall them to power on again, if still does not work
- Hold down # key and press Power on/off key for a while to reset the phone



- Make sure you follow the complete charge time (minimum 3 hours)
- After a partial charge, the battery level indicator may not be exact Wait for at least 20 minutes after removing the charger to obtain

- interval longer

an exact indication Switch on the backlight upon request.

- Extend email auto-check interval to as long as possible.
- Update weather info, upon demand manually or set its auto-check