Your mobile	I.I Keys Send Key ( ) - Access call log from idle - Accept an incoming call	<ul> <li>Keypad locked.</li> <li>Call forwarding activated: your calls are forwarded .</li> </ul>	2 Getting started	3 Calling
	- To dial the number focused on the screen End Key ( سرف) - Power on (long press) - Return back to idle from any other state	<ul> <li>Alarm clock or appointment(s).</li> <li>Level of network reception.</li> <li>Voicemail message or PUSH message arrived.</li> </ul>	2.1 Let's go Removing and installing the back cover	Dial the desired number then press the $\$ key to place the ca you make a mistake, you can delete the incorrect digits by pressing C.
Middle key/Play and Pause key	<ul> <li>Turn off the backlight and lock the screen (short press in idle screen)</li> <li>Long press in idle to access 'quick profile + power off' Navigation keys (in idle screen):</li> </ul>	<ul> <li>✓ Unanswered calls.</li> <li>✓ Radio is on.</li> <li>✓ Web alerts <sup>(1)</sup>.</li> <li>™ Roaming.</li> </ul>		To hang up the call, press the vec. Making an emergency call If your phone is covered by the network, dial emergency number press the vec key to make an emergency call. This works e
ALCATEL	<ul> <li>Up to message</li> <li>Down to Camera</li> <li>Left to alarm</li> <li>Right to Bluetooth menu</li> <li>Central key (()))</li> </ul>	환지 Memory card scanning in progress. 환전 Memory card scanning completed. L1L2 Line switching @: indicates the selected line.	Inserting and installing the battery, SIM card	<ul> <li>without a SIM card and without typing the PIN code <sup>(1)</sup>.</li> <li>Calling your voicemail <sup>(2)</sup></li> <li>Your voicemail is provided by your network to avoid missing call</li> </ul>
End key Navigation and OK key	<ul> <li>Open Main Menu in idle</li> <li>Confirm/ok/select in other state</li> <li>Play/pause key (side middle key)</li> <li>Play/pause music</li> </ul>	G       GPRS attached.         G       GPRS connecting.         ♪       Music player active.         ▶       Message receipt in progress.	Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card,	works like an answering machine that you can consult at any time access your voicemail, hold down <b>3.3</b> Receiving a call When you receive an incoming call, press the key to talk
Send key	Volume keys (side keys) - Adjust general volume (short press) - Go or return to previous/next song (long press) 1.2 Main screen icons <sup>(1)</sup>	Sending a message.       Silence mode: your phone does not ring, beep or vibrate.       Message unread.       Message list is full: your phone cannot accept any new	press it and slide it out. 2.2 Power on your phone Hold down the عن key until the phone powers on.	<ul> <li>3.4 Available functions during the call</li> <li>During a call, you can use your directory, short messages, etc. with</li> </ul>
Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates.	<ul> <li>Battery charge level.</li> <li>Vibrate alert: your phone vibrates, but does not ring or beep with the exception of the alarm.</li> <li>Bluetooth status (Blue - Activated).</li> <li>Bluetooth status (Connected to an audio device).</li> </ul>	messages. You must access the message list and delete at least one message on your SIM card.         ズ       Flight mode.         ⑧       Bluetooth headset connected.	2.3 Power off your phone Hold down the من key until the pop-up "Profile tab" appears, then select "Power off" and confirm.	losing your correspondent.
OT-706 ALCATEL mobile phones	<ul> <li>Headset connected.</li> <li>The icons and illustrations in this guide are provided for informational purposes only.</li> </ul>	<ul> <li><sup>(1)</sup> Depending on your network operator.</li> <li><sup>(2)</sup> Contact your network operator to check service availability.</li> <li>3</li> </ul>	4	<ul> <li><sup>(1)</sup> Depends on local regulations.</li> <li><sup>(2)</sup> Contact your network operator to check service availability.</li> </ul>
5 Directory	7 Camera	<ul> <li>8.2 Radio</li> <li>Your phone is equipped with FM radio <sup>(1)</sup> with RDS functionality. You</li> </ul>	O Tools	File manager
5.1 Consulting your directory list In Idle interface, click i icon to access the contacts.	Your mobile phone is fitted with a camera for taking photos that you can use in different ways: - store them in your " <b>File manager</b> ": - send them in a multimedia message (MMS) to a mobile phone or an	can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.		<b>II.I My music</b> Choose an audio for the Power on/off screen, for an incoming ca message alert, power on/off ringtone or an alarm and scheduler.
5.2 Create contact Select the contacts list in which you wish to add a contact to, press the "Options" softkey, select "Create contact" then O.	email address; - customise your main screen; - select them as incoming call image to a contact in your directory; - transfer them by data cable or microSD card to your computer;	8.3 Image viewer A library links to the pictures in "My creations" and "My images" in phone to be shown in list, slide, or thumbnail, set as Wallpaper, Screen saver, Power on/off display, and Contact ID, or sent by	<ul><li>10.2 Alarm</li><li>Your mobile phone has a built-in alarm clock with a snooze feature.</li><li>10.3 Bluetooth</li></ul>	<b>II.2 My images</b> You can select an image or a photo as wallpaper, ON/OFF screen assign it to a contact in the directory.
	7.1 Camera Select of to access the function from main menu.	MMS, Bluetooth.	To use your phone with a Bluetooth device, you need to proceed in two steps: - Pair and register the device to your phone, - Select it to use hands-free communication. Only one Bluetooth	II.3 My videos The "My videos" album contains all video clips downloaded to phone or memory card.
You can create, edit and receive SMS and MMS <sup>10</sup> with this mobile phone. MMS enables you to send images, photos, animations and sounds to other compatible mobiles.		<b>9</b> Web	audio device (your Bluetooth headset or your Bluetooth car kit) can be connected during the communication.	<ul> <li>11.4 My photos</li> <li>This feature stores all the photos captured by your mobile phone.</li> <li>11.5 Other files</li> </ul>
<b>6.1 Create text/multimedia message</b> <sup>(1)</sup> You can click in idle interface to create a message. Or select " <b>Messages</b> " from the Main Menu to create text/multimedia messages.	8.1 Music player	information such as weather conditions, news, sport and download new ringtones, wallpapers, music. Homepage • Launch the Web browser with the homepage of the default profile.	Once you enter this menu from " <b>Tools</b> ", there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.	Store files of unsupported format.
You can type a message, but you can also modify a predefined message in " <b>Templates</b> " or customise your message by adding pictures, photos, sounds, titles, etc. (only available while editing an MMS). While writing a message, select " <b>Options</b> " to access all the messaging options.	will have full flexibility of managing music both on your mobile and	Bookmarks       • Access your favorite sites.         Recent pages       • Pages which you recently browsed.         Offline pages       • Pages available for offline viewing.         Go to URL       • Enter the URL of Web site.         Profiles       • Customise your Web access.	<b>10.5 Calculator</b> Enter a number, select the type of operation to be performed, and enter the second number, then press <b>a</b> key to display the result. To return to the main screen, click <b>b</b> area.	You can access all files stored in memory card here. II.7 Memory status Indicates how much space is used and how much is currently free your phone and memory card (if any).
You can save standard messages to <b>Drafts</b> or <b>Templates</b> (MMS only).			10.6 Memo You can create a Text note or Voice memo by accessing "Memo".	

<sup>(1)</sup> Depending on your network operator. English - CJB2220ALAAA

7

may view up to 3 cities at one time (Options\Set as my city). Also, you can <sup>(1)</sup> The quality of the radio depends on the coverage of the radio add a maximum of 10 new cities to the list (**Options\Add**). station in that particular area. 9

8

10.7 World clock

The World clock shows current local time and the time in different cities. You

10



## 4.1 Call log

call. If You can access your call memory by pressing 🔪 from the idle the screen. Choose the option of the desired list: Outgoing call(s), Missed call(s), Answered call(s).

## 4.2 My numbers

and Type in or modify your telephone number or the number to access and your vocemail and confirm by clicking. Your telephone number is usually written on your SIM card.

## 4.3 Billings

Ils. It You can access different items with this option: Amount, Duration, B. IT GPRS counter, Beep duration.

## 4.4 Call settings (1)

You can access a number of items with this option: Call waiting, Call forwarding, Call barring, Caller ID, Auto redial.

nout

ility. 5	(i) Contact your network operator to check service availability.
<b>FERNA</b>	2 Settings Ø
ing call, a ler.	From the main menu, select the menu icon function of your choice in order to customise your telephone: Profiles,Touch settings, Display, Time and date, Languages, Headset mode, Screen lock, Numeric keys, Input mode, Vocabulary, Security, Network, Connectivity, Call settings.
creen, or	
d to the	<b>3</b> Latin input mode/character table <sup>(1)</sup>
hone.	To write messages, there are two writing methods: - Normal: This mode allows you to type text by choosing a letter or a sequence of characters. - Predictive with the Zi mode: This mode speeds up the writing of your text. Press the key once and the word will be modified each time you press a key. As you go on, the word will keep changing.
y free on	ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited. All rights reserved © Copyright 2010 TCT Mobile Limited. TCT Mobile Limited reserves the right to alter
	material or technical specification without prior notice.

(1) For specific languages as Chinese, please see specific input leaflets. 12

manufacturer disclaims any liability for damage, which may result as a consequence, temporary and not serious of improper use or use contrary to the instructions contained herein.

## TRAFFIC SAFETY:

Given that studies show that using a mobile phone while driving a vehicle cons a real risk, even when the hands-free kit is used (car kit, headset...), drivers are Do not drop, throw or bend your mobile phone. quested to refrain from using their mobile when the vehicle is not parked.

radio. Using a headphone can be dangerous and forbidden in some areas.

When switched on, your phone emits electromagnetic waves that can interfere with TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the • BATTERY: the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure use of other chargers or batteries.

- that there is no problem:
- do not place your phone on top of the dashboard or within an airbag deployment information stored in your phone.

check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from mobile phone RF energy.

### CONDITIONS OF LISE

performance.

Switch the phone off before boarding an aircraft.

- Switch the phone off when you are near gas or flammable liquids. Strictly obey all Do not play or use a flashing-lights feature if you are tired or need sleep. signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in - Take a minimum of a 15-minute break hourly.
- any potentially explosive atmosphere When the phone is switched on, it should be kept at least 15 cm from any medical - Play at the farthest distance possible from the screen.
- device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when If your hands, wrists, or arms become tired or sore while playing, stop and rest using the phone, you should hold it against the ear on the opposite side to the device, if any
- To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the "hands-free" mode because the amplified volume might cause hearing damage.

Do not let children use the phone and/or play with the telephone and accessories without supervision

When replacing the cover please note that your phone may contain substances that

could create an allergic reaction. Always handle your phone with care and keep it in a clean and dust-free place. Do not allow your phone to be exposed to adverse weather or environmental • PRIVACY:

manufacturer's recommended operating temperature range is -10°C to +55°C. We recommend that you read this chapter carefully before using your phone. The Over 55°C the legibility of the phone's display may be impaired, though this is

never rely only on your phone for emergency calls.

Do not open, dismantle or attempt to repair your mobile phone yoursel

- Do not paint it. When driving do not use your phone and headphone to listen to music or to the Use only batteries, battery chargers, and accessories which are recommended by TCT Mobile Limited and its affiliates and are compatible with your phone model. of the mobile phone
  - Remember to make back-up copies or keep a written record of all important switched off. Observe the following precautions for battery use:
  - Some people may suffer epileptic seizures or blackouts when exposed to flashing Do not attempt to open the battery (due to the risk of toxic fumes and burns). (Recommendation 1999/51)/PIC) (PI lights, or when playing video games. These seizures or blackouts may occur even if a - Do not puncture, disassemble or cause a short-circuit in a battery,
  - person never had a previous seizure or blackout. If you have experienced seizures or Do not burn or dispose of a used battery in household rubbish or store it at blackouts, or if you have a family history of such occurrences, please consult your
- on your phone. Switch the phone off when you are in health care facilities, except in designated incorporate flashing lights on the phones. All persons should discontinue use and affiliates.
- areas.As with many other types of equipment now in regular use, mobile telephones consult a doctor if any of the following symptoms occur: convulsion, eye or muscle can interfere with other electrical or electronic devices, or equipment using radio twitching, loss of awareness, involuntary movements, or disorientation. To limit the kelihood of such symptoms, please take the following safety precautions:

  - Play in a room in which all lights are on

  - for several hours before playing again. If you continue to have sore hands, wrists, or arms during or after playing, stop
  - the game and see a doctor. When you play games on your phone, you may experience occasional discomfort in
  - your hands, arms, shoulders, neck, or other parts of your body. Follow the terms of equipment with this symbol are not to be thrown into ordinary bins if your
  - instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders. Prolonged exposure to music at full volume on the music player may damage CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT

Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones ended by TCT Mobile Limited and its affiliates

13

19

# Telephone warranty .....

Your phone is warranted against any defect or malfunctioning which 2) Connection to any equipment not supplied or not recommended may occur in conditions of normal use during the warranty period of twelve (12) months (1) from the date of purchase as shown on your 3) Modification or repair performed by individuals not authorised by • You are advised to switch off the telephone from time to time to original invoice

against any defect which may occur during the first six (6) months (1) from the date of purchase as shown on your original invoice.

In case of any defect of your phone which prevents you from normal use thereof, you must immediately inform your vendor and present Your phone will not be repaired in case labels or serial numbers (IMEI) and carry out the following checks: your phone with your proof of purchase.

If the defect is confirmed, your phone or part thereof will be either replaced or repaired, as appropriate. Repaired Phone and accessories There are no express warranties, whether written, oral or implied, are entitled to a one (I) month warranty for the same defect. Repair other than this printed limited warranty or the mandatory warranty or replacement may be carried out using reconditioned components provided by your country or jurisdiction. offering equivalent functionality.

This warranty covers the cost of parts and labor but excludes any In no event shall TCT Mobile Limited or any of its affiliates be liable for My phone has not responded for several minutes other costs.

This warranty shall not apply to defects to your phone and/or accessory due to (without any limitation):

(1) The warranty period may vary depending on your country.

recharges.

(2) The life of a rechargeable mobile phone battery in terms of

conversation time standby time, and total service life, will depend

on the conditions of use and network configuration. Batteries

being considered expendable supplies, the specifications state that

you should obtain optimal performance for your phone during the

first six months after purchase and for approximately 200 more

by TCT Mobile Limited. TCT Mobile Limited or its affiliates or your vendor. Batteries (2) and accessories sold with your phone are also warranted (1) Inclement weather, lightning, fire, humidity, infiltration of liquids or • You are advised to fully charge (1111) the battery for optimal

area where your phone is used

foods, chemical products, download of files, crash, high voltage, corrosion, oxidation...

have been removed or altered. My mobile phone will not switch on

with technical and safety standards applicable in the geographical

indirect, incidental or consequential damages of any nature whatsoever, • Press the very key including but not limited commercial or financial loss or damage, loss of • Remove the battery and re-insert it, then switch the phone back on data or loss of image to the full extent those damages can be disclaimed My screen is difficult to read by law.

Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or My mobile phone turns off by itself exclusions may not apply to you.

mobile phone · Check the battery charge level

20

Clean your screen

conditions of use

temperatures above 60°C.

their life:

equipment

In non European Union jurisdictions:

In European Union countries:

the instructions below

operation

optimise its performance

affect the performance of your telephone.

• Press of until the screen comes on

Check the battery charge level

turn your telephone back on

Collection bins at points of sale.

are to be taken to collection points for them to be recycled.

All products with this sign must be brought to these collection points

environment, so that their components can be reused.

These collection points are accessible free of charge.

X.a

14

This symbol on your telephone, the battery and the accessories means that these products must be taken to collection points at the and of

They will then be recycled, preventing substances being disposed of in the

jurisdiction or your region has suitable recycling and collection facilities; instead they

TYPE DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

· Avoid storing large amounts of data in your telephone as this may

· Check the battery contacts, remove and reinstall your battery, then

· Use your mobile phone in accordance with the recommended

- Municipal waste disposal centres with specific bins for these items of

- taking photographs and recording sounds with your mobile telephone. Pursuant to information technology equipment and office equipment use. Due to different International guidelines and EU requirements for RF (radio-waves) exposure. Emergency call numbers may not be reachable on all cellular networks. You should record the voices of other people or any of their personal attributes and duplicate not work in another jurisdiction. They should be used for this purpose only. or distribute them, as this may be considered to be an invasion of privacy. It is the • RADIO WAVES:

user's sole responsibility to ensure that prior automation be obtained, in necessary, into an enternational automation of all mobile phone models before they can to keep mobile phones away from the head and body (fact sheet n° 193). Additional An electronic version of this user guide is available in English and other another person; the manufacturer, the seller or vendor of your mobile phone be put on the market. The protection of the health and safety for the user and any information about electromagnetic fields and public health are available on the (including the operator) disclaim any liability which may result from the improper use other person is an essential requirement of these standards or this directive.

- REOLUREMENTS REGARDING EXPOSURE TO RADIO WAVES
- to comply with the radiofrequency (RF) exposure thresholds recommended by It is also advised to keep the telephone, during communications, away from the belly international requirements (ICNIRP) (1) and by the Council of the European Union of pregnant women and from the lower abdomen for teenagers.

These limits are part of a set of requirements and establish authorised avoid touching it or degrading it. radiofrequency levels for the public. These limits were established by independent As mobile devices offer a range of functions, they can be used in positions other than groups of experts on the basis of regular and detailed scientific assessments. They against your ear. In such circumstances the device will be compliant with the other relevant provisions of Directive 1999/5/EC. The entire copy of You are advised to switch off the telephone from time to to potimise its doctor before playing video games on your phone or enabling a flashing-lights feature Batteries must be disposed of in accordance with locally applicable environmental include a significant safety margin intended to ensure the safety of all, regardless of guidelines when used with headset or USB data cable. If you are using another the Declaration of Conformity for your telephone can be obtained regulations. Only use the battery for the purpose for which it was designed. Never age or state of health.

- Parents should monitor their children's use of video games or other features that use damaged batteries or those not recommended by TCT Mobile Limited and/or its The exposure standard for mobile phones is determined by a measurement unit positions the phone at least 2cm away from the body. known as the Specific Absorption Rate or "SAR". The SAR limit is set by international • LICENCES
  - requirements or by the Council of the European Union at 2 watts/kilogram (W/kg) that these products must be taken to collection points at the end of Obigo® carried out on the basis of standard usage modes with the phones transmitting at

their maximum power level over the entire range of frequency bands. Although the SAR was established at the highest certified level, the actual SAR level for the mobile phone during use is generally much lower than the maximum values. In fact, since mobile phones are designed to operate at many different power levels. they only use the minimum level of power required to provide a connection to the

- network. In theory, the closer you are to a base station antenna, the lower the power level required by the mobile phone.
- The ICNIRP requirements are applicable in the following regions: Central America (except Mexico), South America, North and South Africa, Pacific Asia (except Korea), Australia, The European recommendation (1999/519/EC) is applicable in the
- following regions: Europe, Israel. 16

## I) Non-compliance with the instructions for use or installation, or **Troubleshooting......** My mobile phone has a low level of autonomy

15

- Make sure you respected the complete charge timing (minimum 3 · Make sure your mobile phone is switched on and connected hours)
- Before contacting the aftersales department, you are advised to follow After a partial charge, the battery level indicator may not be exact. Check your subscription status with your operator (credit, SI Wait for at least 20 minutes after removing the charger to obtain an valid, etc.) Make sure you have not forwarded incoming calls exact indication

## My mobile phone will not charge properly

- Make sure that your battery is not completely discharged; the The caller's name does not appear when a call is received battery charge indicator can take several minutes and may be • Check that you have subscribed to this service with your operation of the several minutes and may be • Check that you have subscribed to this service with your operation.
- accompanied by a quiet whistling sound Make sure charging is carried out under normal conditions (0°C-+40°C)
- Make sure your battery is inserted. It must be inserted before Check the network strength full plugging in the charger I am unable to use the features described in the manua
- Make sure you are using an Alcatel battery and charger in the box When abroad, check that the electrical current is compatible

## My mobile phone will not connect to a network

- Try connecting in another location
- Verify the network coverage with your operator
- Check with your operator that your SIM card is valid Try selecting the available network(s) manually
- · Try connecting at a later time if the network is overloaded

## SIM card error

21

- Make sure the SIM card has been correctly inserted • Verify with your operator that your SIM card is 3V or 1.8V compatible; the old 5V SIM cards cannot be used
- · Check that your keypad is locked when you are not using your Make sure the chip on your SIM card is not damaged or scratched

# Unable to make outgoing calls

- Make sure you have dialled a valid number and press the 
   key · For international calls, check the country and area codes
- Make sure your mobile phone is connected to a network and that
- the network is not overloaded or unavailable
- Check your subscription status with your operator (credit, SIM card
- valid etc.)
- Make sure you have not barred outgoing calls

The highest tested SAR value for this mobile phone for use at the ear and General information ..... jurisdiction or other jurisdiction(s) where you will use your mobile phone regarding The chargers designed for your mobile phone meet with the standard for safety of the SAR levels on various phones and at various positions, they all meet the relevant Internet address: www.alcatel-mobilephones.com such laws and regulations, it may be strictly forbidden to take photographs and/or to applicable electrical specifications, a charger you purchased in one jurisdiction may. The World Health Organisation (WHO) considers that present scientific information does not indicate the need for any special precautions for use of mobile phones. If individuals are concerned, they might choose to limit their own or their

user's sole responsibility to ensure that prior authorisation be obtained, if necessary, Proof of compliance with international standards (ICNIRP) or with European children's RF exposure by limiting the length of calls, or using "hands-free" devices questions you may have. following site: http://www.who.int/peh-emf.

THIS MOBILE PHONE COMPLIES WITH INTERNATIONAL AND EUROPEAN Although no danger relating to the use of telephone was ever proved, the World Health Organisation advises as a precautionary measure to use your telephone with Your telephone is a transceiver that operates on GSM networks with Before removing the battery from your phone, please make sure that the phone is Your mobile phone is a radio transmitter/receiver. It was designed and manufactured a good level of network reception as indicated on the telephone display (4 to 5 bars). 900 and 1800 MHz bands. Your telephone is equipped with a built-in antenna. For optimal operation, you should

accessory ensure that whatever product is used is free of any metal and that it through our website: www.alcatel-mobilephones.com

\*

is a registered trademark of Obigo AB Micro

microSD Logo is a trademark.

The Bluetooth word mark and logos are owned by the and trade names are those of their respective owners

## OT-706 Bluetooth QD ID B016328

eZiText" eZiText<sup>™</sup> and Zi<sup>™</sup> are trademarks of Zi Corporation and/or 71 CORDORATION its Affiliates

22

On our Internet site, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any

# Protection against theft ()

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the product's memory We recommend that you note the number the first time you use your telephone by entering \* # 0.6 # and keep it in a safe place. It may be requested by Bluetooth SIG, Inc. and any use of such marks by TCT Mobile the police or your operator if your telephone is stolen. This number Limited and its affiliates is under license. Other trademarks allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card.

languages according to availability on our server: www.alcatel-

This equipment is in compliance with the essential requirements and

## Disclaimer

mobilephones com

CE1588

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator services.

17	<sup>(1)</sup> Contact your network operator for service availability. 18
<ul> <li>Unable to receive incoming calls</li> <li>Make sure your mobile phone is switched on and connected to a network (check for overloaded or unavailable network)</li> <li>Check your subscription status with your operator (credit, SIM card valid, etc.)</li> <li>Make sure you have not forwarded incoming calls</li> <li>Make sure that you have not barred certain calls</li> </ul>	<ul> <li>"My numbers"</li> <li>Try later if the network is busy</li> <li>The <i>M</i> icon is displayed on my standby screen</li> <li>You have saved too many short messages on your SIM card; delete</li> </ul>
Thate sure that you have not barred certain cans     The caller's name does not appear when a call is received     Check that you have subscribed to this service with your operator     Your caller has concealed his/her number	some of them or archive them in the product memory "No service"is displayed * You are outside of the network coverage area
<ul> <li>Your caller has concealed his/her humber</li> <li>The sound quality of the calls is not optimal</li> <li>You can adjust the volume during a call by means of the key</li> <li>Check the network strength full</li> </ul>	I have already entered 3 incorrect PIN codes Contact your network operator to obtain the PUK code (Personal Unblocking Key)
I am unable to use the features described in the manual     Check with your operator to make sure that your subscription     includes this service     Make sure this feature does not require an Alcatel accessory	<ul> <li>My mobile phone is frozen, can't power on</li> <li>Make sure your battery is not completely used up or damaged</li> <li>Remove your battery, remove your SIM card then reinstall them to power on again, if still does not work</li> <li>Hold down ∧ key + ay key at same time, then press ∨ key</li> </ul>
<ul> <li>When I select a number from my directory, the number is not dialled</li> <li>Make sure that you have correctly recorded the number in your file</li> <li>Make sure that you have selected the country prefix when calling a foreign country</li> </ul>	to reset it <sup>(I)</sup>
<ul> <li>I am unable to create a file in my directory</li> <li>Make sure that your SIM card directory is not full; delete some files or save the files in the product directory (i.e. your professional or personal directories)</li> </ul>	
My callers are unable to leave messages on my voicemail • Contact your network operator to check service availability	

(1) ALL User phone data: contacts, photos, messages, files and downloaded applications will be lost permanently. Please do not remove battery during resetting.