



1. Push connector out



2. Insert the USB card directly into the USB port (USB 2.0 or 1.1).



3. Install the driver from the CD (Windows 98 SE only)

WINDOWS

• To access USB card



4. Select "My Computer" icon
5. Click on "Removable Disk" icon

• To remove USB card



6. Double click on "unplug or eject hardware" icon in the system tray of the Windows Taskbar



7. Remove USB card from USB port (USB 2.0 or 1.1)

Macintosh

• To access USB card



4. Select "Untitled" drive icon

• To remove USB card



5. Drag the USB card icon into the trash can icon



6. Remove USB card from USB port (USB 2.0 or 1.1)