Your mobile OT-106 OT-203e OT-206 30

- Left softkey Pick up/Send call
- Voicemail
- Right softkey 6 Switch on/
- A Lock/Unlock Switch off End call



Prolonged exposure to music at full volume on the music player may damage Prolonged exposure to music at the robustic state of the listener's hearing. Set your phone volume safely. Use only headph

Vibration alert

(1) Navigation key

Messages A

Directory ▼

FM radio (3)

Alarm

My shortcuts (2)

Menu/Confirm an option

OT-203e OT-206 ALCATEL

- (I) Depending on your network operator
- (2) OT-106/OT-203e only. (3) OT-206 only.

I.I Keys



Confirm an option (press the middle of the key) Access "Templates" in "Messages" (3) (long keypress () in main screen)

Access favorite contact(s)(4) (long keypress O in main screen)

Pick up Send a call

> Access call memory (Redial) (short keypress) Switch on/Switch off the telephone (long keypress)

Fnd call Return to the main screen

Left softkey

Right softkey

Access your voicemail (long keypress)

In edit mode

- Short keypress: access the language list
- Long keypress; enter zero

In Edit mode:

- Short keypress: change input methods
- Long keypress: access the Symbols table

 \cap

- Short keypress: # - Long keypress: activate/deactivate the vibrator In edit mode
- Short keypress: (space)
- Long keypress: add a word
- (I) OT-106/OT-206 only.
- (2) OT-203e only.
- (3) OT-106 only.
- (4) OT-203e/OT-206 only.

Main screen icons

- Battery charge level.
- Vibration alert: your phone vibrates but neither rings not heens except for the alarms
- Headset connected
- Call forwarding activated: your calls are forwarded.
- Alarm clock programmed
- Voicemail message arrived
- FM radio is on
- Unanswered calls
- Line switching (3): indicates the selected line
- Shown only in no ciphering mode while calling, sendir receiving SMS.
- Level of network reception

Silence mode: your phone neither rings, beeps nor vibrates except for the alarms

- Keypad locked
- Stopwatch is active
- Ringtone alert
- Vibration and ringtone alert
- (I) OT-106 only.
- (2) OT-203e/OT-206 only.
- (3) Depending on your network operator

2.I Set-up

Removing and installing the back cover







Inserting and removing the SIM Card



press it and slide it out







2.2 Power on your phone

Hold down the \Rightarrow / \geqslant key until the phone powers on.

2.3 Power off your phone

Hold down the \rightarrow / key from the main screen.

Calls 4

3.1 Making a call

Dial the desired number then press the — / 📞 key to place the call. You can access your call memory by pressing the — / 📞 key from If you make a mistake, you can delete the incorrect digits by pressing the the main screen. right softkey

To hang up the call, press the \rightarrow / \geqslant kev.

Making an emergency call

press the — / 📞 key to make an emergency call. This works even usually written on your SIM card. without a SIM card and without typing the PIN code or unlocking the

3.2 Calling your voicemail (1)

To access your voicemail, hold down the key.

3.3 Receiving a call

When you receive an incoming call, press the - / key to talk and then hang up using the - / 🦠 key.

3.4 Available functions during the call

During a call, you can use your directory, short messages, etc. without losing your correspondent.

Call register

4.1 Call memory

4.2 My numbers

Type in or modify your telephone number or the number to access If your phone is covered by the network, dial emergency number and your voicemail and confirm by pressing O. Your telephone number is

4.3 Billing (1)

You can access different items with this option: Amount, Duration.

44 Call settings

You can access a number of items with this option: Call waiting, Call forwarding, Call barring, Answer mode, Auto redial...

4.5 Call control (1)

The menu serves you the dual purposes of cost monitoring and controlling during a call by the settings of "By cost" and "By duration".

(I) Depending on your network operator

Directory.....

5.1 Consulting your directory

To access the **directory** from the main screen, press the O key and The wallpaper is displayed when you switch on your telephone. select the 🛐 icon from the menu.

5.2 Creating a file

Select the directory in which you wish to create a file, press the "Options" softkey, select "Create file" then .

Messages 6.1 Create message

From the main menu select "Messages" to create text message. You can type a message, and you're also able to insert a pre-defined message from "Templates". While writing a message, select "Options" to access all the messaging options. You can save your messages that you send often to "Drafts".

Display (2), Clock, Keys, Dictionary, More settings...

Display (1) 7.1 Wallpaper

You can customise your welcome animation or image that appears when you switch on your phone. You can also customise your OFF screen with an image or animation.

7.3 Brightness

You may adjust black level with respect to LCD display by pressing the

Settings

From the main screen, select the icon menu 🔅 and select the function of your choice in order to customise your telephone: 9.5

7.2 Power On/Off (3)

Tools 9.I Organizer

Once you enter this menu from "Tools", there is a monthly-view calendar for you to keep track of important meetings, appointments, [0.] Game settings etc. Days with events entered will be marked in color.

9.2 Stopwatch

StopWatch is simple application for measuring time with possibility to register several results and suspend/resume measurement.

9.3 Alarm

Your mobile phone has a built-in alarm clock with a snooze feature.

9.4 Calculator

the () key or the left softkey.

Converter Unit converter and Currency converter

9.6 My shortcuts Access the shortcuts already programmed. To programme new shortcuts: select "My shortcuts" if you want to create a quick access to a function, Directory, etc.

Games

Your Alcatel phone may include some games.

It allows you to manage settings, in which you may set background music and vibration alert

Your phone is equipped with an FM radio (2) with RDS functionality. You can use the application as a traditional FM radio with automatic tuning and saved channels or with parallel visual information related to the radio program on the display, if you tune to stations that offer Visual Hold down the ** # / • # key to get the decimal point. Confirm with Radio service. You can listen to it while running other applications.

With this menu, you may personalise ringtones for different events and

(I) Contact your network operator to check service availability.

Latin input mode......

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key Press the key several times until the desired letter is highlighted. When you release the key the highlight character is inserted into the text.
- Predictive with the Zi mode: this mode speeds up the writing of your text. Write the word by pressing a key between and 2 and 9 (1)/ Press the key once and the word will be modified each time you press a key. As you go on, the word will keep changing. Example: For "Tomorrow", press on the following keys:
- 8 TUV, mo 6, mo 6 = Too -> mo 6 -> tomorrow- 0 + key in edit mode Short keypress: access the language list Long keypress: enter zero

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

TCT Mobile Limited. TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

All rights reserved © Copyright 2009

(I) OT-106/OT-203e only

- (2) OT-203e/OT-206 only. (3) Depending on the model.

(I) OT-206 only.

(2) The quality of the radio depends on the coverage of the radio station in that particular area. 10

(I) OT-106/OT-206 only

(2) OT-203e only.

English - CJB30X0ALAAB

12

manufacturer disclaims any liability for damage, which may result as a consequence of temporary and not serious improper use or use contrary to the instructions contained herein.

TRAFFIC SAFETY:

a real risk, even when the hands-free kit is used (car kit, headset...), drivers are

Do not drop, throw or bend your mobile phone. ested to refrain from using their mobile when the vehicle is not parked.

radio. Using a headphone can be dangerous and forbidden in some areas.

- the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that other chargers or batteries. there is no problem:
- do not place your phone on top of the dashboard or within an airbag deployment
- check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from mobile phone RF energy.

CONDITIONS OF LISE

Switch the phone off before boarding an aircraft.

Switch the phone off when you are near gas or flammable liquids. Strictly obey all - Do not play or use a flashing-lights feature if you are tired or need sleep. signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any notentially explosive atmosphere

When the phone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any, To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the "hands-free" mode because the amplified volume might cause hearing damage.

Do not let children use the phone and/or play with the telephone and accessories

When replacing the cover please note that your phone may contain substances that disorders could create an allergic reaction.

Always handle your phone with care and keep it in a clean and dust-free place.

Do not allow your phone to be exposed to adverse weather or environmental • PRIVACY: manufacturer's recommended operating temperature range is -10°C to +55°C. We recommend that you read this chapter carefully before using your phone. The Over 55°C the legibility of the phone's display may be impaired, though this is

> Emergency call numbers may not be reachable on all cellular networks. You should never rely only on your phone for emergency calls.

Do not open, dismantle or attempt to repair your mobile phone yoursel

When driving, do not use your phone and headphone to listen to music or to the Use only batteries, battery chargers, and accessories which are recommer Mobile Limited and its affiliates and are compatible with your phone model. TCT • BATTERY: When switched on, your phone emits electromagnetic waves that can interfere with Mobile Limited and its affiliates disclaim any liability for damage caused by the use of Before removing the battery from your phone, please make sure that the phone is REQUIREMENTS REGARDING EXPOSURE TO RADIO WAVES.

> Remember to make back-up copies or keep a written record of all important. Observe the following precautions for battery use information stored in your phone.

lights, or when playing video games. These seizures or blackouts may occur even if a - Do not burn or dispose of a used battery in household rubbish or store it at These limits are part of a set of requirements and establish authorised radiofrequency. Your telephone is equipped with a built-in antenna. For optimal operation, you should person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your Batteries must be disposed of in accordance with locally applicable env You are advised to switch off the telephone from time to time to optimise its doctor before playing video games on your phone or enabling a flashing-lights feature regulations. Only use the battery for the purpose for which it was designed. Never use safety margin intended to ensure the safety of all, regardless of age or state of health. against your ear. In such circumstances the device will be compliant with the guidelines through our websites: www.alcatel-mobilephones.com.

Parents should monitor their children's use of video games or other features that affiliates Switch the phone off when you are in health care facilities, except in designated areas. incorporate flashing lights on the phones All persons should discontinue use and As with many other types of equipment now in regular use, mobile telephones can consult a doctor if any of the following symptoms occur: convulsion, eye or muscle interfere with other electrical or electronic devices, or equipment using radio twitching, loss of awareness, involuntary movements, or disorientation. To limit the elihood of such symptoms, please take the following safety precautions:

- Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.

If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal

the listener's hearing. Set your phone volume safely. Use only headphones

voices of other people or any of their personal attributes and duplicate or distribute, not work in another jurisdiction. They should be used for this purpose only. them, as this may be considered to be an invasion of privacy. It is the user's sole • RADIO WAVES: responsibility to ensure that prior authorisation be obtained, if necessary in order to Proof of compliance with international standards (ICNIRP) or with European Directive

switched off

- Do not attempt to open the battery (due to the risk of toxic fumes and burns). Some people may suffer epileptic seizures or blackouts when exposed to flashing - Do not puncture disassemble or cause a short-circuit in a battery.
 - temperatures above 60°C.

This symbol on your telephone the battery and the accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centres with specific bins for these items of

They will then be recycled, preventing substances being disposed of in the nent, so that their components can be reused In Furonean Union countries:

These collection points are accessible free of charge

All products with this sign must be brought to these collection points In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if you jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled. CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT

Prolonged exposure to music at full volume on the music player may damage TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

CHARGERS

other jurisdiction(s) where you will use your mobile phone regarding taking. The chargers designed for your mobile phone meet with the standard for safety of While there may be differences between the SAR levels on various phones and at tographs and recording sounds with your mobile telephone. Pursuant to such laws information technology equipment and office equipment use. Due to different various positions, they all meet the relevant International guidelines and EU ulations it may be strictly forbidden to take photographs and/or to record the applicable electrical specifications, a charger you purchased in one jurisdiction may requirements for RF (radio-waves) exposure.

is an essential requirement of these standards or this directive THIS MOBILE PHONE COMPLIES WITH INTERNATIONAL AND EUROPEAN http://www.who.int/peh-emf.

to comply with the radiofrequency (RF) exposure thresholds recommended by a good level of network reception as indicated on the telephone display (4 to 5 bars) international requirements (ICNIRP) (1) and by the Council of the European Union It is also advised to keep the telephone, during communications, away from the belly (Recommendation 1999/519/EC) (2)

levels for the public. These limits were established by independent groups of experts avoid touching it or degrading it. on the basis of regular and detailed scientific assessments. They include a significant As mobile devices offer a range of functions, they can be used in positions other than damaged batteries or those not recommended by TCT Mobile Limited and/or its. The exposure standard for mobile phones is determined by a measurement unit known, when used with headset or usb data cable. If you are using another accessory ensure as the Specific Absorption Rate or "SAR". The SAR limit is set by international that whatever product is used is free of any metal and that it positions the phone at Protection against theft (1) requirements or by the Council of the European Union at 2 watts/kilogram (W/kg) least 2cm away from the body. averaged over 10 grams of body tissue. The tests used to determine SAR levels were • LICENCES carried out on the basis of standard usage modes with the phones transmitting at their maximum power level over the entire range of frequency bands.

Although the SAR was established at the highest certified level, the actual SAR level for the mobile phone during use is generally much lower than the maximum values. In fact, since mobile phones are designed to operate at many different power levels, they only use the minimum level of power required to provide a connection to the network. In theory, the closer you are to a base station antenna, the lower the power level required by the mobile phone.

The ICNIRP requirements are applicable in the following regions Central America (except Mexico), South America, North and South Africa, Pacific Asia (except Korea), Australia

(2) The European recommendation (1999/519/EC) is applicable in the following regions: Europe, Israel.

The highest tested SAR value for this mobile phone for use at the ear and compliance Mains powered chargers will operate within the temperature range of 0°C to 40°C. against the standard is 1.26 W/kg (OT-203e), 1.26 W/kg (OT-206), 1.25 W/kg (OT-106).

The World Health Organisation (WHO) considers that present scientific information does not indicate the need for any special precautions for use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's RF On our Internet site, you will find our FAQ (Frequently Asked 1999/S/EC (R&TTE) is required of all mobile phone models before they can be put on exposure by limiting the length of calls, or using "hands-free" devices to keep mobile the market. The protection of the health and safety for the user and any other person phones away from the head and body (fact sheet no 193). Additional information about electromagnetic fields and public health are available on the following site

Although no danger relating to the use of telephone was ever proved, the World 900 and 1800 MHz bands. Your mobile phone is a radio transmitter/receiver. It was designed and manufactured Health Organisation advises as a precautionary measure to use your telephone with of pregnant women and from the lower abdomen for teenagers.

is a registered trademark of Obigo AB.

eZiText™ and Zi™ are trademarks of Zi Corporation and/or

General information

- Internet address: www.alcatel-mobilephones.com
- Hot Line Number: see "TCT Mobile Services" leaflet or go to our

Questions) section You can also contact us by e-mail to ask any questions you may have.

Your telephone is a transceiver that operates on GSM networks with

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The entire copy of the Declaration of Conformity for your telephone can be obtained

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your telephone by entering * # 0.6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card.

Disclaimer

There may be certain differences between the user manual description and the phone's operation depending on the software release of your telephone or specific operator services.

(I) Contact your network operator for service availability

Telephone warranty

Your phone is warranted against any defect which may occur in conditions of normal use during the warranty period of twelve (12) months (1) from the date of purchase as shown on your original invoice. 2) Connection to any equipment not supplied or not recommended • You are advised to switch off the telephone from time to time to Batteries (2) and accessories sold with your phone are also warranted against any defect which may occur during the first six (6) months (1) from the date of purchase as shown on your original invoice.

In case of any defect of your phone which prevents you from normal use thereof, you must immediately inform your vendor and present your phone with your proof of purchase.

If the defect is confirmed, your phone or part thereof will be either replaced or repaired, as appropriate. Repaired Phone and accessories Your phone will not be repaired in case labels or serial numbers (IMEI) My mobile phone will not switch on are entitled to a one (I) month warranty for the same defect. Repair or have been removed or altered. replacement may be carried out using reconditioned components offering equivalent functionality.

This warranty shall not apply to defects to your phone and/or accessory **Troubleshooting.....**

- 1) Non-compliance with the instructions for use or installation or with technical and safety standards applicable in the geographical
- by TCT Mobile Limited
- 3) Modification or repair performed by individuals not authorised by You are advised to fully charge (iii) the battery for optimal TCT Mobile Limited or its affiliates or your vendor,
- 4) Inclement weather, lightning, fire, humidity, infiltration of liquids or Avoid storing large amounts of data in your telephone as this may foods, chemical products, download of files, crash, high voltage,

This warranty covers the cost of parts and labor but excludes any other other than this printed limited warranty or the mandatory warranty provided by your jurisdiction.

> In no event small real mode earnings of any nature whatsoever including incidental or consequential damages of any nature whatsoever including My screen is difficult to read but not limited commercial loss, to the full extent those damages can be disclaimed by law. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

14

Before contacting the aftersales department, you are advised to follow

- operation
- affect the performance of your telephone.

- Press / Juntil the screen comes on
- Check the battery contacts, remove and reinstall your battery, ther turn your telephone back on

My phone has not responded for several minutes

- Press the 🛶 / 🄰 key

Clean your screen

- conditions of use

- Check that your keypad is locked when you are not using your mobile
- · Check the battery charge level

My mobile phone has a low level of autonomy

- hours)
- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication

My mobile phone will not charge properly

- Make sure that your battery is not completely discharged; the battery

 The caller's name does not appear when a call is received charge indicator can take several minutes and may be accompanied. Check that you have subscribed to this service with your operator by a quiet whistling sound
- Make sure charging is carried out under normal conditions (0°C-+40°C)
- Make sure your battery is inserted. It must be inserted <u>before</u> Check the radio reception icon level ...II
- Make sure you are using an Alcatel battery and charger When abroad, check that the electrical current is compatible

My mobile phone will not connect to a network

- Try connecting in another location
- Verify the network coverage with your operator
- Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually

Try connecting at a later time if the network is overloaded SIM card error

- Make sure the SIM card has been correctly inserted
- Verify with your operator that your SIM card is 3V compatible: the old 5V SIM cards cannot be used
- Make sure the chip on your SIM card is not damaged or scratched

Unable to make outgoing calls

- Make sure you have dialled a valid number and press the / L
- For international calls, check the country and area codes Make sure your mobile phone is connected to a network, and that the network is not overloaded or unavailable
- Check your subscription status with your operator (credit, SIM card valid, etc.)

Unable to receive incoming calls

- Make sure you respected the complete charge timing (minimum 3 . Make sure your mobile phone is switched on and connected to a
 - network (check for overloaded or unavailable network) Check your subscription status with your operator (credit, SIM card valid, etc.)
 - Make sure you have not forwarded incoming calls
 - Make sure that you have not barred certain calls

Your caller has concealed his/her number

The sound quality of the calls is not optimal

- You can adjust the volume during a call by means of the _ key
- I am unable to use the features described in the manual
- · Check with your operator to make sure that your subscription includes this service

Make sure this feature does not require an Alcatel accessory When I select a number from my directory, the number is not

- Make sure that you have correctly recorded the number in your file
- Make sure that you have selected the country prefix when calling a

I am unable to create a file in my directory

- Make sure that your SIM card directory is not full: delete some files or save the files in the product directory (i.e. your professional or personal directories)
- Check the "Call barring" option for "Incoming calls" to be sure that the "All calls except SIM directory" feature is not activated

My callers are unable to leave messages on my voicemail

Contact your network operator to check service availability

22

I cannot access my voicemail

- Make sure your operator's voicemail number is correctly entered in "My numbers'
- · Try later if the network is busy

The icon is displayed on my standby screen

 You have saved too many short messages on your SIM card: delete some of them or archive them in the product memory

"No service" is displayed

Unblocking Key)

You are outside of the network coverage area.

I have already entered 3 incorrect PIN codes Contact your network operator to obtain the PUK code (Personal

(2) The life of a rechargeable mobile phone battery in terms of conversation time standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your phone during the first six months after purchase and for approximately 200 more

(1) The warranty period may vary depending on your country.

- area where your phone is used.

There are no express warranties, whether written, oral or implied,

In no event shall TCT Mobile Limited or any of its affiliates be liable for • Remove the battery and re-insert it, then switch the phone back on

the instructions below

optimise its performance

and carry out the following checks:

- · Check the battery charge level

- Use your mobile phone in accordance with the recommended My mobile phone turns off by itself

Make sure you have not barred outgoing calls