


TWO EYE MULTIFUNCTION 6P25

DATE SETTING

1. Pull crown out to position 2.
2. Turn counter-clockwise to select date.

DAY AND TIME SETTING

1. To set time, pull crown out to position 3.
2. Turn clockwise to set hour and minute hands. The hand showing days of the week will also move with the hour and minute hands. Keep turning until you have reached the desired day.
3. Push crown back to position 1.



THREE EYE VX3J

(1 crown)

DATE SETTING


1. Pull crown out to position 2.
2. Turn clockwise to advance the date hand.
3. Push crown back to position 1.

DAY AND TIME SETTING

1. Pull crown out to position 3.
2. Turn clockwise to advance hour and minute hands. The hand showing days of the week will also move with the hour and minute hands. Keep turning until you have reached the desired day.

24-HOUR SUB-DIAL SETTING

The 24-hour hand moves correspondingly with the hour and minute hands. When setting the time be sure to check that the 24-hour hand is set properly.



CHRONOGRAPH STOPWATCH VD55 (with date - VD57)

(1 crown/2 pushers)

TIME SETTING

1. Pull crown out to position 3.
2. Set time by turning the crown clockwise.
3. Push back to position 1 to start the watch.

USING THE STOPWATCH

1. Press A to start/stop the stopwatch.
2. Press B to control the split time and reset.

STOPWATCH HAND ADJUSTMENT

1. Pull crown out to position 3.
2. Press A to reset the stopwatch 1/10 second hand to the "0" position.
3. Press B to reset the second and minute hands. The hands only move clockwise.
4. With each press of A or B, the hands move one position. They move quickly if the buttons are kept pressed.

Note: If the stopwatch hands function improperly, pull out crown and press A and B at the same time for over 2 seconds. When the buttons are released, the stopwatch second and 1/10 second hands will spin around and return to "0." This will indicate that the internal circuit has been reset.

DATE SETTING (On some models only)

1. Pull crown out to position 2.
2. Turn clockwise until desired date appears in window.
3. Push crown back to position 1.

