

# Adtran

## Quick Start

ADTRAN

SDG-8632 series Service Delivery Gateway

Wi-Fi 6E Mesh AP

P/N: 17600073

### Overview



#### **WARNING!**

*Read all warning, cautions, notes and installation instructions before installing or servicing this equipment.*



#### **ATTENTION!**

*Lisez tous les avertissements et mises en garde avant l'installation de cet équipement ou la réalisation de toute opération de maintenance*

The ADTRAN® SDG-8632 series is a Wi-Fi 6E Mesh AP, built to deliver top-end Wi-Fi 6E Mesh AP performance and advanced service delivery capabilities. This quick start describes how to install ADTRAN's Service Delivery Gateway.

The SDG-8632 series is an indoor WiFi 6E Mesh.

Figure 1 illustrates the front and back of the SDG-8632.

## Product Specifications

### ■ Ethernet

SDG-8632:

1 x 2.5 Gigabit Ethernet RJ-45 WAN interface

1 x 2.5 Gigabit Ethernet RJ-45 LAN interfaces

### ■ WLAN Interface

Compliant with IEEE 802.11 b/g/n/ac/ax

Tri-Band Radios: 2.4 GHz 4x4 / 5.0 GHz 4x4 / 6.0 GHz 4x4

### ■ USB Interface

1 x USB3.0 (TypeA) interface

### ■ Working Environment

41° F – 104° F (5° C – 40° C)

### ■ Dimensions

185mm x 98mm x 98mm (H x W x D)

### ■ Power Supply

AC Input: 100~240 VAC @ 50/60Hz



Figure 1. Front and Back of the SDG-8632 Gateway



#### **WARNING!**

WARNING indicates a hazard which, if not avoided, could result in death, injury or serious property damage.



#### **CAUTION!**

CAUTION indicates a hazard which, if not avoided, could result in service interruption, damage to the equipment, or minor property damage.



#### **NOTE**

NOTES inform the user of additional, but important, information or features.

# Installing the SDG-8632 Gateway

The following are guidelines for basic installation of the gateway.



## NOTE

*Refer to the national, state and local electrical codes for the requirements for power, grounding, wiring, and installation methods.*



## CAUTION!

*The product is intended for indoor use only. Ethernet cables and attached equipment are intended for use within the same building with equipotential bonding, and not intended to be placed in separate buildings or structures. Failure to deploy as described could result in permanent damage from lightning or other electrical events and voids the warranty. Furthermore, all connections from outside of the building, such as old wiring, must be disconnected prior to use.*

## Package Contents

- ADTRAN's WiFi 6E Mech AP
- 15VDC/3A USB type C power adapter
- CAT.5E Ethernet cable

## Prior to Installation

Before installing the equipment, inspect the gateway. If damage has occurred during shipping, file a claim with the carrier, and then contact ADTRAN Customer Support.

## Connecting the Gateway

Figure 2 illustrates the installation (connection) options for the gateway.

The following subscriber connections are available on the rear of the device:

- 1x 2.5Gigabit Ethernet port (RJ-45 Connector) – LAN port
- 1x 2.5Gigabit Ethernet port (RJ-45 Connector) - WAN port
- 1x USB 3.0 (Type A Connector) port

To connect the subscriber Ethernet interfaces, refer to Figure 2 and insert a Category 5E (or better) RJ-45 cable into one of the LAN ports or the 2.5 Gigabit Ethernet port (WAN) until there is an audible “click”.




Figure 2. Gateway Installation

## **Connecting the Power Supply**

1. Connect the end of the power adapter to the Power port on the bottom of the gateway.
2. Plug other end of the power adapter into the wall outlet.
3. Confirm that the power is connected properly. The Power LED should be lit on the gateway.


## **Resetting the Gateway**

A reset button is available if the device needs to be rebooted. To reboot the device, press the Reset button on the rear panel of the gateway for 5 seconds or less. To reset the device to custom defaults, press the Reset button for 5 seconds or more.

# Set up


Connect to <http://192.168.1.1> from web browser, go through the instructions to complete the router mode setup.

1. Click on "Set up a new Intellifi® device".
2. Simply input "12345678" as the password, re-enter the "12345678" again, click on "Set password".
3. Then click on "Continue" to the next page.



Set up a new Intellifi® device

Reset device to default settings



**Welcome to Quickstart**

Let's start by setting your login password so your device can be configured in the future.

Enter password


.....

Re-enter password


.....

Set password

Cancel



Cancel




**Set up your Intellifi device**

First, let's select your device's operating mode and role in your Intellifi network, then we'll configure your WiFi based on the role you have selected.

Continue

- 4. Press Next>, then press Router.
- 5. Type "samplewifi" as SSID, and type "12345678" as password, then press "Continue".




6. Press "Yes, set up Guest WiFi, Then press "Finish" to complete setup.

[← Back](#)


**Do you want to set up Guest WiFi?**

Guest WiFi is a great way to give house guests access to the Internet without sharing your primary WiFi password or access to your network.



Yes, set up Guest WiFi

Not now



[← Back](#)

**Almost done! Let's review.**

**Operating Mode**  
Router


**IntelliFi Mode**  
Controller

**WiFi Name (SSID)**  
samplewifi

**WiFi Password**  
12345678

Finish


Cancel



**Set up complete!**

This window will automatically close in 10 seconds once settings have finished applying to your device.

To manage your device settings in the future, navigate to <http://router.local>





## **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**IMPORTANT NOTE:**  
**Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 32 cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Country Code selection feature to be disabled for products marketed to the US/CANADA

Operation of this device is restricted to indoor use only.

FCC regulations restrict the operation of this device to indoor use only.

The operation of this device is prohibited on oil platforms, cars, trains, boats, and aircraft, except that operation of this device is permitted in large aircraft while flying above 10,000 feet.

Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems

## **Industry Canada statement**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference

(2) This device must accept any interference, including interference that may cause undesired operation of the device

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage;

(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### **Caution:**

(i) the device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

(ii) for devices with detachable antenna(s), the maximum antenna gain permitted for devices in the bands 5250-5350 MHz and 5470-5725 MHz shall be such that the equipment still complies with the e.i.r.p. limit;

(iii) for devices with detachable antenna(s), the maximum antenna gain permitted for devices in the band 5725-5850 MHz shall be such that the equipment still complies with the e.i.r.p. limits as appropriate; and

**Avertissement:**

- (i) les dispositifs fonctionnant dans la bande de 5 150 à 5 250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux;
- (ii) pour les dispositifs munis d'antennes amovibles, le gain maximal d'antenne permis pour les dispositifs utilisant les bandes de 5 250 à 5 350 MHz et de 5 470 à 5 725 MHz doit être conforme à la limite de la p.i.r.e.;
- (iii) pour les dispositifs munis d'antennes amovibles, le gain maximal d'antenne permis (pour les dispositifs utilisant la bande de 5 725 à 5 850 MHz) doit être conforme à la limite de la p.i.r.e. spécifiée, selon le cas;

**Radiation Exposure Statement:**

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 32 cm between the radiator & your body.

**Déclaration d'exposition aux radiations:**

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé. Cet équipement doit être installé et utilisé à distance minimum de 32 cm entre le radiateur et votre corps.

**Operation shall be limited to indoor use only.**

Operation on oil platforms, automobiles, trains, maritime vessels and aircraft shall be prohibited except for on large aircraft flying above 3,048 m (10,000 ft).

Devices shall not be used for control of or communications with unmanned aircraft systems.

**leur utilisation doit être limitée à l'intérieur seulement;**

leur utilisation à bord de plateformes de forage pétrolier, d'automobiles, de trains, de navires maritimes et d'aéronefs doit être interdite, sauf à bord d'un gros aéronef volant à plus de 3 048 m (10 000 pi) d'altitude

Les dispositifs ne doivent pas être utilisés pour commander des systèmes d'aéronef sans pilote ni pour communiquer avec de tels systèmes.

## **EU & UKCA Declaration of Conformity**

Hereby, **Adtran Inc** declares that the radio equipment type **[SDG-8632]** is in compliance with Directive 2014/53/EU. The following test methods have been applied in order to prove presumption of conformity with the essential requirements of the Radio Equipment directive: 2014 / 53 / EU:

The full text of the EU declaration of conformity is available at the internet address:

This device complies with the essential requirements of the Radio Equipment directive: 2014 / 53 / EU and Radio Equipment Regulations 2017 (SI 2017/1206). The following test methods have been applied in order to prove presumption of conformity with the essential requirements of the Radio Equipment directive: 2014 / 53 / EU and the Radio Equipment Regulations 2017(SI 2017/1206):

Radio Equipment directive: 2014 / 53 / EU	Radio Equipment Regulations 2017(SI 2017/1206)
EN 300 328 v2.2.2	EN 300 328 v2.2.2
EN 301 893 V2.1.1	EN 301 893 V2.1.1
ETSI EN 303 687 V1.1.1	ETSI EN 303 687 V1.1.1
	IR 2030 – UK Interface Requirements 2030
EN IEC 62311:2020	BS EN IEC 62311:2020
EN 50385: 2017	BS EN 50385: 2017
EN 50665: 2017	BS EN 50665: 2017
EN 301 489-1 V2.2.3	EN 301 489-1 V2.2.3
EN 301 489-17 V3.2.4	EN 301 489-17 V3.2.4
EN 55032: 2015/ A11 : 2020	BS EN 55032: 2015/ A11 : 2020
EN 55035: 2017+A11: 2020	BS EN 55035: 2017+A11: 2020
EN 62368-1:2014+AC:2015+A11:2017	BS EN 62368-1:2014+A11:2017
EN 50564: 2011	BS EN 50564: 2011

## Wi-Fi

Freq. range	Power
2400MHz ~ 2483.5MHz	20 dBm
5150MHz ~ 5250MHz	23 dBm
5250MHz ~ 5350MHz	23 dBm
5470MHz ~ 5725MHz	29dBm (RED); 28dBm(UKCA)
5725 MHz ~5850MHz	23 dBm
5925MHz ~ 6425MHz	23 dBm


## BT:


Freq. range	Power
2400MHz ~ 2483.5MHz	1 dBm

SW version: 12.2.4.101

The minimum distance between the user and/or any bystander and the radiating structure of the transmitter is 20cm.

5150 ~ 5350 MHz is limited to indoor used in below countries.



	BE	BG	CZ	DK	DE	EE	IE	EL	ES	FR	HR
	IT	CY	LV	LT	LU	HU	MT	NL	AT	PL	PT
	RO	SI	SK	FI	SE	UK(NI)	LI	IS	NO	TR	CH

UK  
CA

